



# Operator's Manual

# ASCO® 5200 SERIES POWER MANAGER Xp




**Note:** The 5200 Series Power Manager Xp is provided with a 7000 Series 7ASLS or 7ASLB usually without the display. Refer to the drawings provided with the switch.

Catalog 5220D Power Manager Display, front view – typical enclosure door mounting.



Rear view – Catalog 5220D Power Manager Transducer attached to the back of the Display.



Catalog 5220T Power Manager Transducer only (without the Display).

### TABLE OF CONTENTS

	section-page
INTRODUCTION	
General Information	1-1
Measurement Conventions	1-3
Measurement Specifications	1-4
Device Ratings	1-5
INSTALLATION	
Mounting	2-1
Connections	2-2
Communication Network Connections	2-3
Control Overview	2-4
Outline Mounting Drawing	627122
Wiring Diagram	629455
INITIAL SETUP	
Password Selection	3-1
Electrical System & Monitored Source	3-2
PT & CT Ratios	3-3
Serial Communication Interfaces	3-4, 3-5
Reset Energy Level	3-8
Reset Maximum Demand Level	3-9
Watt Demand Window Size	3-10
Setpoint Output Relay	3-11
KW Demand High / Low Setpoints and Reset Time Delay	3-12
OPERATING THE POWER MANAGER	
Operation	4-1
INDEX	back page

**⚠ DANGER**

To avoid possible shock, burns, or death, deenergize all electrical sources before making any connections to the Power Manager.

**⚠ CAUTION**

The protection provided by the equipment may be impaired if the Power Manager is used in a manner not specified by ASCO.

## General Information

The ASCO 5200 Series *Power Manager Xp* collects real-time power system information from ASCO Power Control Systems and 7000 Series Automatic Transfer Switch products (which utilize the Group 5 Controller). The Power Manager is available in two forms: Catalog 5220D (Accessory 85 on an ATS) Power Manager (Display and Transducer) for local data monitoring and control; or Catalog 5220T (Accessory 75 on an ATS) Power Manager Transducer without the display transmits data serially to a remote network management product for collection and analysis.

The *Power Manager Xp* includes a backlit 4-line LCD display and membrane controls. All monitoring and control functions can be done from the front of an enclosure for convenience and safety.

The universal potential transformer inputs on the Power Manager can accommodate the following three phase and single phase bus types:

- Three phase – 4 wire WYE system
- Three phase – 3 wire Delta system
- Single phase – 3 wire system
- Single phase – 2 wire system

## Monitored & Calculated Data

Set-up parameters as well as the following computed parameters are available both on the local display and through the serial interface:

- Line-to-neutral voltages ( $V_{AN}$ ,  $V_{BN}$ ,  $V_{CN}$ )
- Line-to-neutral voltage average ( $V_{AVE}$ )
- Line-to-line voltages ( $V_{AB}$ ,  $V_{BC}$ ,  $V_{CA}$ )
- Line-to-line voltage average ( $V_{LAVE}$ )
- Current on each phase ( $I_A$ ,  $I_B$ ,  $I_C$ )
- Current in the neutral conductor ( $I_N$ )
- Average current ( $I_{AVE}$ )
- Active power, KW per phase and total ( $W_A$ ,  $W_B$ ,  $W_C$ ,  $W_T$ )
- Reactive power, KVAR per phase and total  
( $VAR_A$ ,  $VAR_B$ ,  $VAR_C$ ,  $VAR_T$ )
- Apparent power, KVA per phase and total  
( $VA_A$ ,  $VA_B$ ,  $VA_C$ ,  $VA_T$ )
- Watt demand and maximum Watt demand
- KWHours importing, exporting and net  
( $KWH_{IMP}$ ,  $KWH_{EXP}$ ,  $KWH_{NET}$ )
- KVARHours leading, lagging and net  
( $KVARH_{LEAD}$ ,  $KVARH_{LAG}$ ,  $KVARH_{NET}$ )
- KVAHours net ( $KVAH_{NET}$ )
- Power factor (PF)
- Signal frequency (Hz)
- Twelve configurable setpoints for Protective Relaying

## Sense Inputs

- 4 current inputs
- 3 voltage inputs
- frequency input

## Control Inputs & Outputs



- transfer switch position input
- 8 status inputs
- 4 relay outputs

## Cleaning

The exterior of the 5200 Series *Power Manager Xp* should be cleaned by wiping the front panel of the display unit with a soft cloth and cleaning agents that are not alcohol based, and are nonflammable, nonexplosive. All other servicing should be performed by authorized factory personnel.

# Measurement Conventions

The following diagrams show how the 5200 Series *Power Manager Xp* interprets and displays signed (+, -) values for power, power factor and energy parameters. Please note that the polarity of the Watts, VARs, Power Factor, energy import/export, and lag/lead readings can be reversed by reversing the polarity of the CTs connected to the Power Manager.



### DEFINITIONS:

$$\Phi \equiv (\text{phase angle between voltage and current}) = \Phi_V - \Phi_I$$

$$\Phi_V \equiv \text{phase angle of voltage signal}$$

$$\Phi_I \equiv \text{phase angle of current signal}$$

**LAGGING**  $\Phi \equiv (0 < \Phi < 90^\circ)$  for positive power flow. To illustrate this condition, assume  $\Phi_V = 0$  and  $(-90^\circ < \Phi_I < 0)$ . This results in  $(0 < \Phi < 90^\circ)$ , so it would be stated that  $\Phi_I$  LAGS  $\Phi_V$  for positive power flow.

**LEADING**  $\Phi \equiv (-90^\circ < \Phi < 0)$  for positive power flow. To illustrate this condition, assume  $\Phi_V = 0$  and  $(0 < \Phi_I < 90^\circ)$ . This results in  $(-90^\circ < \Phi < 0)$ , so it would be stated that  $\Phi_I$  LEADS  $\Phi_V$  for positive power flow.

## Measurement Specifications

NOTE: The accuracy specifications are subject to change.  
Contact ASCO Power Technologies for more information.

- Temperature : 25 °C / 77 °F
- Frequency : 50.0 Hz or 60.0 Hz
- Current input : 2 % < I<sub>FULL SCALE</sub> < 125 %
- Sensing type: True RMS up to and including the 21<sup>st</sup> harmonic.

Parameter (full scale)		Accuracy (% full scale)	Display	
			Resolution	Range
Current (I)	5.000 A	0.25 %	0.25 %	0 – 29 999 <sup>1</sup>
Voltage (V)	120 V	1.00 %	1.00 %	0 – 59 999 <sup>2</sup>
	600 V	0.25 %	0.25 %	0 – 59 999 <sup>2</sup>
Active Power (KW) (per element)	600 W	1.00 %	0.25 %	0 – 29 999 <sup>3</sup>
	3000 W	0.25 %	0.10 %	0 – 29 999 <sup>3</sup>
Reactive Power (KVAR) (per element)	600 VAR	1.00 %	0.25 %	0 – 29 999 <sup>3</sup>
	3000 VAR	0.25 %	0.10 %	0 – 29 999 <sup>3</sup>
Apparent Power (KVA) (per element)	600 VA	1.00 %	0.25 %	0 – 29 999 <sup>3</sup>
	3000 VA	0.25 %	0.10 %	0 – 29 999 <sup>3</sup>
Active Energy (KWH)		1.00 % of reading	0.10 %	0 – 1 999 999 999
Reactive Energy (KVARH)		1.00 % of reading	0.10 %	0 – 1 999 999 999
Apparent Energy (KVAH)		1.00 % of reading	0.10 %	0 – 1 999 999 999
Power Factor (PF)		1.00 %	0.01 PF	–0.0 to 1.00 to +0,0
Frequency (Hz)		0.25 %	0.1 Hz	40 to 100 Hz

### NOTES:

<sup>1</sup> Reads in KA (i.e., 10.00 KA) for currents over 9,999 A.

<sup>2</sup> Reads in KV (i.e., 10.0 KV) for voltages over 9,999 V.

<sup>3</sup> Reads in MW, MVAR, MVA for readings over 9,999 K.

## FCC Class A Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

## Device Ratings

### Input Signals

- Current (4): 0 to 5 A ac nominal. 4000 V ac isolation, minimum.  
Burden: less than 2mV at 5 A ac input ( 0.01 VA )
- Voltage (3): 0 to 600 V ac nominal, three phase. 3750 V ac isolation minimum.  
Burden: less than 0.1 mA ac at 600 V ac input ( 0.1 VA ).
- Frequency: 40 Hz to 100 Hz fundamental.  
True RMS measurements up to and including the 21<sup>st</sup> harmonic.

Relay outputs (4): Form C dry contact,  
UL/CSA rated 1 A @ 30 V dc, 0.5 A @ 125 V ac resistive load

Status inputs (8): 30 V dc maximum, >10 V dc = active, <1 V dc = inactive  
status input burden = 12 mA @ 24 V dc

### Transfer Switch

Position input: 30 V dc maximum, >10 V dc = active, <1 V dc = inactive

Power Requirements: 24 V dc / 0.3 A maximum / 7.2 VA  
Power supply should be UL Listed.

**CAUTION** Risk of explosion if battery is replaced by an incorrect type.  
Dispose of used batteries according to local ordinances.

Interface (s): External display (J2) – Class 1 DB25 female type  
SCI (J5) – Class 2 DB9 female type  
RS485 (J1) – Isolated RS485 Communications interface

Operating Temp.: –4° F to +140° F (–20° C to +60° C)

Storage Temp.: –67° F to +185° F (–55° C to +85° C)

Installation Category: IC III

Pollution Degree: PD 2

Humidity: Relative humidity 5% to 95%, non-condensing.

### Size:

Catalog 5220T 6" H x 2 ¾" D x 10" W (152 mm H x 70 mm D x 254 mm W)

Catalog 5220D 7" H x 5" D x 12" W (178 mm H x 127 mm D x 304 mm W)

(includes Power Manager Display)

### Weight:

Catalog 5220T 3 lbs. 5 oz (1.50 kg)

Catalog 5220D 5 lbs. 11 oz (2.58 kg)

(includes Power Manager Display)

## Applicable Standards

UL 3111–1 Electrical Measuring and Test Equipment, Part 1: General Requirements

CAN/CSA–C22.2 No. 231–M89 CSA Safety Requirements for Electrical and Electronic Measuring and Test Equipment

## Mounting

The 5200 Series Power Manager Xp must be mounted to a flat surface inside a metal enclosure. For Catalog 5220T (Acc. 75) mount the Power Manager Xp Transducer by using the four slotted mounting locations in the base.

For Catalog 5220D (Acc. 85) mount the Display (Transducer with Display) to the inside of an enclosure door which has a 10" x 6" cutout so that the LCD display and membrane controls are accessible through the door (when closed).

Use a standard nutdriver to mount the Power Manager Xp.  
Tighten all mounting hardware to 10 in-lb maximum.

See Outline & Mounting Drawing 627122 (end of this section)

## Connections

See Wiring Diagram 629455 (end of this section).

Make the appropriate connections as shown on the label on the *Power Manager Xp* Transducer and on the wiring diagrams.

### CAUTION

To prevent damaging the Power Manager deenergize (turn off) all power to the unit before you connect or disconnect the shielded interconnecting cable and all other wiring to the terminal blocks.

## Tightening Torque

Tighten all connection terminals to 10 in-lb maximum.

## Interconnecting Cable

If a *Power Manager Xp* Display is provided be sure that its shielded cable is connected to socket J2 on *Power Manager Xp* Transducer.

## Power Supply Connections Class 1 circuit See CAUTION above!

Use a Class 1 power supply that is UL Listed. Connect the 0.3 amp 24 volt dc power supply to terminal 23 (+) and terminal 24 (com) on terminal block TB3 marked *Control Power* on the *Power Manager Xp* Transducer. Refer to the labeling below terminal block. Use 18 AWG stranded copper wire.



### DANGER

To avoid possible shock, burns, or death, deenergize all electrical sources before making any connections to the *Power Manager Xp*. Lethal voltages can result if current transformers are open circuited while carrying primary current. To avoid injury turn off primary circuit or short out CT secondary circuit.

## CT Connections

Connect the current transformers (CTs) with 5 amp rated secondaries to the appropriate terminals 7–14 marked *Current Inputs* on the *Power Manager Xp* Transducer. Refer to the labeling above terminal block TB2. Note the shorting block connections on the Wiring Diagram. See **DANGER** above!

## Voltage Connections

Connect the system voltage (120 to 600 volts ac) to the appropriate terminals 1–6 marked *Voltage Inputs* on the *Power Manager Xp* Transducer. For system voltages above 600 volts ac use appropriate potential transformers (PTs). Refer to the labeling above terminal block TB1. Note the fusing requirements (1 amp / 600 V) on the Wiring Diagram. See **DANGER** above!

## Transfer Switch Position

If an automatic transfer switch is used, connect an unused auxiliary contact (Feature 14A) on the transfer switch to the appropriate terminals marked *N/E Input* on the *Power Manager Xp* Transducer terminals 13 & 14. Refer to the labeling below terminal block TB3 (lower row). Refer to the ATS Operator's Manual and ATS wiring diagram for the location of Feature 14A contact. This connection to the Power Manager allows it to monitor and display the position of the transfer switch (page 4–1 step 1).

### CAUTION

The transfer switch position indicating auxiliary contact (Feature 14A) must be connected to the Power Manager for proper operation. If not, select *Other* for *Source* to be monitored (page 3–2).



## Status Voltage Input

Connect up to eight status voltage inputs to the appropriate terminals 1–12 marked *Status Inputs* on terminal block TB3 of the *Power Manager Xp* Transducer. Each input can operate either from an external 24 V dc signal or by using external contacts with the internally provided 24 V dc source. The Wiring Diagram shows suggested wiring methods for the Status Inputs. Refer to labeling below terminal block TB3 (upper row). These status inputs are independent of the four relay outputs listed below. The status of the inputs can be monitored on the display (see page 4–2 steps 15 & 16). The status of these inputs can be transmitted serially for remote display. The default display name of *Status Input 1*, or Input 2, etc. can also be changed serially to a unique 15 character name by using ASCO Power Technologies software.

## Relay Output

Connect up to four circuits to the *Power Manager Xp*'s four normally–open relay outputs (each internal contact is rated 1 amp at 30 volts dc, 0.5 amp at 125 volts ac resistive load). Terminals 15–22 are marked *Relay Outputs* on the Power Manager Transducer. Refer to the labeling below terminal block TB3 (lower row). These outputs are independent of the Status Voltage Inputs described above. See page 4–2 step 17 for the display of the outputs. These outputs can then be transmitted serially for display, and remote operation. The default display name of *Relay Output 1*, or output 2, etc. can also be changed serially to a unique 15 character name by using ASCO Power Technologies software.

## Ground Connection

The *Power Manager Xp* is provided with an earth ground screw and a UL Listed insulated ring terminal. The user should properly crimp the terminal lug to UL listed 16 gauge copper wire with 600 V insulation, color coded green with yellow stripes. Use an *AMP* crimp tool number 47387 or UL approved equivalent crimp tool.

When the Power Manager is mounted on a door, a conductive strap must be used between the enclosure and the door. This connection provides proper grounding which does not rely upon the door hinges.

## Communication Network Connections RS–485 (J1) or SCI (J5) Class 2 circuit

See Wiring Diagram 629455 (end of this section).

**RS–485 (Port J1)** – Use the RS–485 interface to connect the Power Manager directly to an RS–485 based communications network. Baud rates of up to 57.6K baud are supported on this interface.

**SCI (Port J5)** – Use the SCI interface to connect to an *ASCO* Accessory 72A Serial Communications Module which provides a gateway onto a RS–485 communications network. Refer to wiring diagram 629455 for connection details. Baud rates of up to 19.2K baud are supported on this SCI/72A interface.

First, use *ASCO* cable 489672 (8 inch) or 489672–001 (4 foot) to connect the unit's serial communications interface connector J5 to the Acc. 72A Serial Communication Module connector J1. Then, use only the recommended communication cable (see below) to connect the Acc. 72A Module to the RS–485 network. Connect the transmit and receive communication cable (twisted pairs) as shown on Wiring Diagram 629455.


### Acceptable Communication Cable

Type of Cable	Acceptable Manufacturer's Numbers
Standard 80° C	Belden 9842, 9829, Alpha 6202C, 6222C
Plenum Rated	Belden 89729, 82729, Alpha 58902

## Control Overview

On the Catalog 5220D Power Manager Xp, which includes the display, six control buttons perform all monitoring and setting functions. Three levels of screens are used. The first (top) level is the *monitoring level* and provides information about the power system. The second (middle) level is the *settings level*. Access to change the settings is password protected (see page 3-1). The third (lower) level is the *setpoints level*. There are twelve user-configurable setpoints for protective relaying, containing two screens per setpoint for parameter selection. A user may configure any combination of these twelve setpoints, including duplicates. Access to these screens is also password protected (see page 3-1).

4-line LCD display



### Left-Right Arrows

The left arrow ◀ and right arrow ▶ keys (*Menu Scroll*) navigate through both levels of screens.

### Enter/Save Settings

The **Enter / Save Settings** key drops from the top level to the lower level settings screens. It also is used to save a new settings.

### Up-Down Arrows




The up arrow ▲ and down ▼ arrow keys (*Increase Value* and *Decrease Value*) modifies a setting (setup parameter) while in the lower level screens.

### Esc key

The Esc key ignores a change and returns to the top level.

DATA MONITOR or POWER MANAGER  
 MONITOR MOUNTING DATA (TYPE 1 ENCLOSURE INSTALLATIONS)  
 (USING THROUGH HOLE MOUNTING METHOD)




D



C

DATA MONITOR or Power Manager  
 MOUNTING DATA (TYPE 3R, 4 & 12 ENCLOSURE INSTALLATIONS)  
 (USING THROUGH HOLE MOUNTING METHOD)

B




A


# DATA MONITOR or POWER MANAGER

## MOUNTING DATA (TYPE 1, 3R, 4 & 12 ENCLOSURE INSTALLATIONS)


### (USING SELF-CLINCHING CAPTIVE STUD MOUNTING METHOD)





CUTOUT DETAIL FOR TYPE 1 ENCLOSURE (USE PEM STUD)



CUTOUT DETAIL FOR TYPE 3R, 12 & 4 ENCLOSURE (USE PEM STUD)



### DATA MONITOR WITHOUT DISPLAY or POWER MANAGER TRANSDUCER MOUNTING DATA




**NOTE:**

1. BEZEL IS REQUIRED FOR TYPE 1 ENCLOSURE WHEN USING DRILL THROUGH MOUNTING METHOD.
2. BEZEL AND GASKET ARE REQUIRED FOR TYPE 1, 3R & 4 ENCLOSURE WHEN USING DRILL THROUGH MOUNTING METHOD
3. GASKET IS REQUIRED FOR TYPE 3R, 12 & 4 ENCLOSURE WHEN USING PEM STUD MOUNTING METHOD.


ALL DIMENSIONS: INCH[mm]

PROJECT NAME:		153736 SC GN 5/98	
MOUNTING DATA		Add Power Manager Info	
DATA MONITOR Cat. No. 214A700, 214A701		150044 YZ SDH 12/98	
POWER MANAGER Cat. No. 5200T, 5200D		ISSUE	
TYPE 1, 3R, 12 & 4		CHANGE LETTER	
DRAWN BY: YZ 12/98		CHK BY: SDH	
CHECKED: SDH 12/98		DATE: 12/98	
APPROVAL: SDH 12/98		SCALE: 6:1	
UNAPPROVED DIMENSIONS TO BE IN ACCORDANCE WITH ASME PROCEDURE B8.1-1983 FOR PLASTIC PARTS SEE B8.1-1983 PROPERTY OF AUTOMATIC SWITCH COMPANY. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR PATENT ARE RESERVED.		COMPUTER GENERATED DRAWING FILE 00	
<b>Automatic Switch Co.</b> PLANNING PARK, NEW JERSEY OFFICE PRINTED IN U.S.A.		DS627122 CHANGE A PART NO. 153736 SHEET 1 OF 1	

2 Wire Single Phase Input Voltage < 600Vac(L-L), no external PTs



3 Wire Single Phase Input Voltage < 600Vac(L-L), no external PTs required



NOTES:

1. A shorting terminal block is recommended at the CT location.
2. Voltage inputs require 1Amp/600V fuses.

C	158167	SRC	WP	7/30
	Add Alt Wiring Info			
B	157106	SRC	WP	4/03/01
	Update Check boxes			
A	156304	SC	WP	12/28/00
	Added 5200 Cat. Info			
-	156297	SC	RS	12/00
	NEW ISSUE			

PROJECT NAME:

WIRING DIAGRAM  
Power Manager Xp




CHANGE LETTER	ECN NO.	BY	APP.	DATE
SUBSIDIARY DISTRIBUTION				
AE	AN	AM	AJ	AL
CH	AV	AA	PS	AR
AG	AP	AC	AS	


BY	DATE	MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-1-003. FOR PLASTIC PARTS SEE MP-1-055	ASSEM. REF. NO.
DRAWN BY	SC 12/00		
CHECKED		PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.	ASCO POWER TECHNOLOGIES, L.P. FLORHAM PARK, NEW JERSEY 07932 U.S.A.
DRAFTING APPROVAL			
FINAL APPROVAL	RS 12/00		

COMPUTER GENERATED DRAWING		
SCALE None	ACAD	FILE _01
SIZE	DWG. NO.	
AS	629455	
CHANGE LETTER C	ECN NO. 158167	SHEET 1 of 6

3 Wire DELTA system Input Voltage < 600Vac(L-L), no external PTs



3 Wire DELTA system w/PTs Input Voltage > 600Vac(L-L), external PTs required




NOTES:

1. A shorting terminal block is recommended at the CT location.
2. Voltage inputs require 1Amp/600V fuses.
3. European convention for phase marking, U, V, W, shown in parenthesis next to A, B, C markings.

PROJECT NAME:				CHANGE LETTER	ECN NO.	BY	APP.	DATE
WIRING DIAGRAM Power Manager Xp				SUBSIDIARY DISTRIBUTION				
				AE <input type="checkbox"/>	AN <input type="checkbox"/>	AM <input type="checkbox"/>	AJ <input type="checkbox"/>	AL <input type="checkbox"/>
				CH <input type="checkbox"/>	AV <input type="checkbox"/>	AA <input type="checkbox"/>	PS <input type="checkbox"/>	AR <input type="checkbox"/>
				AG <input type="checkbox"/>	AP <input type="checkbox"/>	AC <input type="checkbox"/>	AS <input type="checkbox"/>	<input type="checkbox"/>
DRAWN BY: SC, DATE: 12/00				COMPUTER GENERATED DRAWING				
CHECKED: [ ]				SCALE: None		ACAD		FILE: _02
DRAFTING APPROVAL: [ ]				SIZE: AS, DWG. NO.: 629455				
FINAL APPROVAL: RS, 12/00				CHANGE LETTER: C		ECN NO.: 158167		SHEET 2 of 6
MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-1-003. FOR PLASTIC PARTS SEE MP-1-055. PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED. <b>ASCO</b> ASCO POWER TECHNOLOGIES, L.P. FLORHAM PARK, NEW JERSEY 07932 U.S.A.				THIRD ANGLE PROJECTION ASSEMBLY REF. NO.				


4 Wire WYE system



Settings  
System: 3Ø- 4 Wire WYE  
PT Ratio: 120:120

ASCO 5200 SERIES POWER MANAGER  
Cat. No. 5200T Power Manager Transducer  p/n 629168  
Cat. No. 5200D Power Manager with Display  p/n 629169  
Cat. No. 5220T Power Manager Xp Transducer  p/n 629268  
Cat. No. 5220D Power Manager Xp with Display  p/n 629269

4 Wire WYE system w/PTs Input Voltage > 600Vac(L-L), external PTs required






Settings  
System: 3Ø- 4 Wire WYE  
PT Ratio: PRIMARY RATING:120


ASCO 5200 SERIES POWER MANAGER  
Cat. No. 5200T Power Manager Transducer  p/n 629168  
Cat. No. 5200D Power Manager with Display  p/n 629169  
Cat. No. 5220T Power Manager Xp Transducer  p/n 629268  
Cat. No. 5220D Power Manager Xp with Display  p/n 629269

- NOTES:
1. A shorting terminal block is recommended at the CT location.
  2. Voltage inputs require 1Amp/600V fuses.
  3. European convention for phase marking, UVW, shown in parenthesis next to A,B,C markings.


PROJECT NAME:				CHANGE LETTER	ECN NO.	BY	APP.	DATE
WIRING DIAGRAM Power Manager Xp				SUBSIDIARY DISTRIBUTION				
				AE <input type="checkbox"/>	AN <input type="checkbox"/>	AM <input type="checkbox"/>	AJ <input type="checkbox"/>	AL <input type="checkbox"/>
				CH <input type="checkbox"/>	AV <input type="checkbox"/>	AA <input type="checkbox"/>	PS <input type="checkbox"/>	AR <input type="checkbox"/>
				AG <input type="checkbox"/>	AP <input type="checkbox"/>	AC <input type="checkbox"/>	AS <input type="checkbox"/>	<input type="checkbox"/>
MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-1-003. FOR PLASTIC PARTS SEE MP-1-055				COMPUTER GENERATED DRAWING				
BY	DATE	PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.		SCALE		None		ACAD
DRAWN BY	SC	12/00	ASSEM. REF. NO.	SIZE		DWG. NO.		FILE _03
CHECKED				AS		629455		
DRAFTING APPROVAL				CHANGE LETTER		ECN NO.		SHEET 3 of 6
FINAL APPROVAL	RS	12/00	ASCO® ASCO POWER TECHNOLOGIES, L.P. FLORHAM PARK, NEW JERSEY 07932 U.S.A.	C		158167		





SWITCH GEAR  
CHASSIS GROUND  
VIA STUD



OPTIONAL ATS POSITION INPUT



TYPICAL DISCRETE OUTPUT WIRING




TYPICAL DISCRETE INPUT WIRINGS

See sheet 5 of 6

PROJECT NAME:

WIRING DIAGRAM  
Power Manager Xp



CHANGE LETTER	ECN NO.	BY	APP.	DATE
SUBSIDIARY DISTRIBUTION				
AE <input type="checkbox"/>	AN <input type="checkbox"/>	AM <input type="checkbox"/>	AJ <input type="checkbox"/>	AL <input type="checkbox"/>
CH <input type="checkbox"/>	AV <input type="checkbox"/>	AA <input type="checkbox"/>	PS <input type="checkbox"/>	AR <input type="checkbox"/>
AG <input type="checkbox"/>	AP <input type="checkbox"/>	AC <input type="checkbox"/>	AS <input type="checkbox"/>	<input type="checkbox"/>

DRAWN BY	BY	DATE
SC	SC	12/00
CHECKED		
DRAFTING APPROVAL		
FINAL APPROVAL	RS	12/00

MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-I-003. FOR PLASTIC PARTS SEE MP-I-055


PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.

**ASCO** ASCO POWER TECHNOLOGIES, L.P.  
FLORHAM PARK, NEW JERSEY 07932 U.S.A.


COMPUTER GENERATED DRAWING		
SCALE None	ACAD	FILE _04
SIZE	DWG. NO.	
AS	629455	
CHANGE LETTER	ECN NO.	SHEET 4 of 6
C	158167	



Typical wiring of Status Inputs with externally supplied 24VDC signal.



Typical Wiring of Status Inputs using isolated contacts with internal 24VDC power supply.



PROJECT NAME:				CHANGE LETTER	ECN NO.	BY	APP.	DATE
WIRING DIAGRAM				SUBSIDIARY DISTRIBUTION				
Power Manager Xp Serial Data Entry				AE	AN	AM	AJ	AL
				CH	AV	AA	PS	AR
				AG	AP	AC	AS	
MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-1-003. FOR PLASTIC PARTS SEE MP-1-055				COMPUTER GENERATED DRAWING				
DRAWN BY	SC	DATE	12/00	SCALE		None	ACAD	FILE _05
CHECKED	WS	DATE	12/00	SIZE		DWG. NO.		
DRAFTING APPROVAL	SC	DATE	12/00	AS 629455				
FINAL APPROVAL	WP	DATE	12/00	CHANGE LETTER	C	ECN NO.	158167	SHEET 5 of 6
ASCO POWER TECHNOLOGIES, L.P. FLORHAM PARK, NEW JERSEY 07932 U.S.A.				THIRD ANGLE PROJECTION				




Figure 4

Figure 4 Interface Wiring used with ASCO Software p/n 629398 is required to add entries that can not be made through the Keypad. The following data can be read and written to the Power Manager Xp:

- Power Manager Xp Name
- Power Manager Xp Location
- Digital I/O Names [to provide descriptions for input and output connections].

PROJECT NAME:				CHANGE LETTER	ECN NO.	BY	APP.	DATE
<b>WIRING</b> <b>DIAGRAM</b> Power Manager Xp Serial Data Entry				 THIRD ANGLE PROJECTION				
				SUBSIDIARY DISTRIBUTION AE <input type="checkbox"/> AN <input type="checkbox"/> AM <input type="checkbox"/> AJ <input type="checkbox"/> AL <input type="checkbox"/> CH <input type="checkbox"/> AV <input type="checkbox"/> AA <input type="checkbox"/> PS <input type="checkbox"/> AR <input type="checkbox"/> AG <input type="checkbox"/> AP <input type="checkbox"/> AC <input type="checkbox"/> AS <input type="checkbox"/>				
DRAWN BY: SC CHECKED: WS DRAFTING APPROVAL: SC FINAL APPROVAL: WP	BY: SC WS WP	DATE: 12/00 12/00 12/00 12/00	MANUFACTURING TOLERANCES TO BE IN ACCORDANCE WITH ASCO PROCEDURE MP-1-003. FOR PLASTIC PARTS SEE MP-1-055  PROPERTY OF ASCO POWER TECHNOLOGIES. USE PERMITTED FOR OUR WORK ONLY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.	ASSEMBLY REF. NO.	<b>COMPUTER GENERATED DRAWING</b> SCALE None      ACAD      FILE_06 SIZE DWG. NO. <b>AS 629455</b>			
 <b>ASCO</b> ASCO POWER TECHNOLOGIES, L.P. FLORHAM PARK, NEW JERSEY 07932 U.S.A.				CHANGE LETTER: C	ECN NO.: 158167	SHEET 6 of 6		

## Initial Setup

After installing the 5200 Series Power Manager you must set these parameters:

- password (required to change any setting)
- type of electric system (3Ø or 1Ø, 3 or 4 Wire, Wye or Delta)
- source to be monitored (normal, emergency, load, other)
- potential transformer (PT) and current transformer (CT) ratios
- communication parameters (if connected to a PC)
- clear energy parameters (resets base energy level to zero)
- watt demand window size
- nominal settings (KW, volts, amps, frequency)
- setpoint parameters
- date and time















If the Power Manager Xp is preinstalled on the ATS, initial setup has already been done. You should set your password and clear the energy settings, however. Then go to *Operating the Power Manager* on page 4-1.

### Password Selection

Don't forget the password; write it down!

Select a four digit or letter password and record it here \_\_\_\_\_.  
Now change the Power Manager Xp password as follows:

The initial password from the factory is 0000 which is the disabled password state.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until password setup location appears.
4			The <u>first</u> digit is blinking.
5			Press up & down arrow keys until correct <u>first</u> digit is displayed.
6			Repeat steps 5 and 6 for the 2nd, 3rd, & 4th digits.
7			Saves the new password.

Now press the Esc key to return to the top level display.

## Type of Electrical System and Source to Monitor

Select one electrical system type and one source to monitor as follows:

### Electrical System Type

- 3Ø – 4 Wire WYE
- 3Ø – 3 Wire Delta
- 1Ø – 3 Wire
- 1Ø – 2 Wire

















### Source to be Monitored

- Normal
- Emergency
- Load
- Other

## ⚠ CAUTION





The transfer switch position indicating auxiliary contact (Feature 14A) must be connected to the Power Manager for proper operation (page 2-2). If not, select *Other* for Source to be monitored.

If incorrect password is entered you will see;  
Invalid Password

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			This is the system type and source setup location.
3			Enter password as explained in steps 5 & 6 on page 3-1.
4			System type is blinking.
5			Press up & down arrow keys until correct system type is selected.
6			Source is blinking.
7			Press up & down arrow keys until correct source is selected.
8			KW Capacity is blinking.

Select system nominal KW capacity (range: 0 – 24999 KW) to be used for setpoint parameters only;

continued on next page.

9			Press up & down arrow keys until correct value is selected.
10			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Nominal Frequency, Voltage, and Current Settings

Select the nominal system frequency, voltage, and current to be used with the setpoint calculations as follows:

### Nominal Frequency

















- 50 or 60 Hz

### Nominal Voltage

- 115 – 59999 volts

### Nominal Current

- 0 – 29999 amperes

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until nominal settings setup appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			Nom. Frequency is blinking.
6			Press up & down arrow keys until correct frequency is displayed.
7			Repeat steps 6 and 7 for Nom. Voltage and Nom. Current.
8			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## PT and CT Ratios

NOTE: If Power Manager is connected to a communications network via the SCI (J5) port or the RS-485 (J1) port AND *ASCObus I* protocol is selected, then the PT Ratio must be set to the actual system voltage. For example, for a 480 volt system, set the PT ratio to 480:120. See the next page.

Select the appropriate ratios for the potential transformers (PTs) and current transformers (CTs) connected to the Power Manager as follows:

















**PT Ratios** ( based upon system voltage, ratio is \_\_\_ : 120 ) See NOTE.

- up to 600 V direct input use 120:120 (maximum is 28200:120)

**CT Ratios** ( based on typical 7000 Series ATS amp size, ratio is \_\_\_ : 5 )

- 30 amp 50:5
- 70 amp 75:5
- 100 amp 100:5
- 150 amp 150:5
- 260 amp 300:5
- 400 amp 400:5
- 600 amp 600:5
- 800 amp 800:5
- 1000 amp 1200:5
- 1200 amp 1200:5
- 1600 amp 2000:5
- 2000 amp 2000:5
- 3000 amp 3000:5
- 4000 amp 4000:5
- maximum is 24000:5

**CT4 Ratio** ( auxiliary CT for neutral connection, if used )

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until PT & CT setup location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The PT ratio is blinking.
6			Press up & down arrow keys until correct number is displayed.
7			Repeat steps 5 and 6 for the CT and CT4 ratios.
8			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Serial Communication Interface (SCI) port J5

If the Power Manager is connected to a communications network via the SCI (J5) port, select the appropriate protocol, baud rate, and address for the port as follows:

### Protocol

- ASCOBus I** – Enters the Power Manager in an ASCO I/O Module emulation mode when used on ATs with Group 7A Controllers, I/O Modules, and ASCO VPi and PQ2000.
 









*Note: The Power Manager must be connected and configured as a 3Ø – 3 Wire Delta System for this protocol. PT ratios must be set to actual system voltage. For example, for a 480 V system, the PT ratio must be set at 480:120. See the previous page. for this protocol. The I/O Module (Catalog 214A402) uses only a delta system and its PT ratio can only be set by changing transformers.*
- ASCOBus II** – New ASCO serial communications protocol used on all latest devices and software packages such as VPi-SYNCHROPOWER®.
- Modbus RTU** – Choose this selection when the Power Manager is to be used on a network that communicates via the Modbus RTU protocol. Contact ASCO Power Technologies to obtain a document detailing the corresponding Modbus protocol Register map definitions.

### Baud Rate

- off, 9600, or 19.2K











### Address

- 1-239 (unique for each Power Manager)
- Note: ASCOBusI address 0-31 only*

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until baud & address setup appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.



NOTE: If *ASCOBus I* is selected, the *Baud Rate* must be set at 9600.

5			The protocol is blinking.
6			Press up & down arrow keys until correct number is displayed.
7			Repeat steps 5 and 6 for the baud rate (see Note).
8			Repeat steps 5 and 6 for the address.
9			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## RS-485 Serial Communication Interface (J1)

If the Power Manager is connected to a communications network via the RS-485 (J1) port, select the appropriate protocol, baud rate, and address for the port as follows:

### Protocol

- **ASCOBus I** – Enters the Power Manager in an ASCO I/O Module emulation mode when used on ATs with Group 7A Controllers, I/O Modules, and ASCO VPi and PQ2000.

*Note: The Power Manager must be connected and configured as a 3Ø – 3 Wire Delta System for this protocol.*

*PT ratios must be set to actual system voltage.*

*For example, for a 480 V system, the PT ratio must be set at 480:120. See the previous page.*

*for this protocol. The I/O Module (Catalog 214A402) uses only a delta system and its PT ratio can only be set by changing transformers.*

- **ASCOBus II** – New ASCO serial communications protocol used on all latest devices and software packages such as VPi-SYNCHROPOWER®.
- **Modbus RTU** – Choose this selection when the Power Manager is to be used on a network that communicates via the Modbus RTU protocol. Contact ASCO Power Technologies to obtain a document detailing the corresponding Modbus protocol Register map definitions.









### Baud Rate

- off, 9600, 19.2K, 38.4K, 57.6K











### Address

- 1-239 (unique for each Power Manager)

*Note: ASCOBusI address 0-31 only*

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until baud & address setup appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.

NOTE: If *ASCOBus I* is selected, the *Baud Rate* must be set at 9600.

5			The protocol is blinking.
6			Press up & down arrow keys until correct number is displayed.
7			Repeat steps 5 and 6 for the baud rate (see Note).
8			Repeat steps 5 and 6 for the address.
9			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Reset Energy Level, Reset Event Log, Set Backlighting

### Reset Energy Level

















- Energy registers are updated approximately once per second and stored into non-volatile (EEPROM) storage once every 15 minutes. This screen allows the user to clear the Power Manager Xp's non-volatile memory for base energy level.






### Reset Event Log

- The Event Log records setpoint activity (parameter, cause, time/date stamp) and holds a maximum of 100 most recent events. This screen allows the user to manually clear this log.

### Backlighting

- The Backlighting setting determines the length of time the LCD backlight stays active when the unit is unattended. You can select OFF, ON (continuous), or 1-1999 minutes.





















Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until the clear energy location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The Clear Energy word <u>NO</u> is blinking.
6			Press up & down arrow keys until the word <u>YES</u> appears.
7			Clears energy register to 0. Changes back to NO.
8			The Clear Event Log word <u>NO</u> is blinking.

9		<pre> &lt;&lt;&lt; SETTINGS &gt;&gt;&gt; Clear Energy?    NO Clear Event Log? <u>YES</u> Backlighting:   10 min </pre>	Press up & down arrow keys until the word <u>YES</u> appears.
10		<pre> &lt;&lt;&lt; SETTINGS &gt;&gt;&gt; Clear Energy?    NO Clear Event Log? <u>NO</u> Backlighting:   10 min </pre>	Clears event log. Changes back to NO.
11		<pre> &lt;&lt;&lt; SETTINGS &gt;&gt;&gt; Clear Energy?    NO Clear Event Log? <u>NO</u> Backlighting:   10 min </pre>	The backlighting <u>minutes</u> is blinking.
12		<pre> &lt;&lt;&lt; SETTINGS &gt;&gt;&gt; Clear Energy?    NO Clear Event Log? <u>YES</u> Backlighting:   <u>10 min</u> </pre>	Press up & down arrow keys until the desired minutes appears.
13		<pre> &lt;&lt;&lt; SETTINGS &gt;&gt;&gt; Clear Energy?    NO Clear Event Log? NO Backlighting:   10 min </pre>	Saves the new settings. Nothing is blinking.

Now press the Esc key to return to the top level display.

## Reset Maximum Demand Level



















The maximum watt demand register stores the largest instantaneous watt demand value since last power-up or manual reset. Manual reset is accomplished by the following procedure:

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until the <i>Clear Max Demand</i> location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The word <u>NO</u> is blinking.
6			Press up & down arrow keys until the word <u>YES</u> appears.
7			Clears max demand to 0. Changes back to NO.
8			Window Size is blinking.
9			SP-Output is blinking.
10			Saves the new setting. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Watt Demand Window Size

The integration time period for the watt demand calculation is user selectable from one to fifteen minutes in one minute increments. It is recommended that the user selects this option to be one-third of the billing interval. Set this option as follows:

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until the <i>Clear Max Demand</i> location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The word <u>NO</u> is blinking.
6			Window Size is blinking.
7			Press up & down arrow keys until correct number is displayed.
8			SP-Output is blinking.
9			Saves the new setting. Nothing is blinking.

Now press the Esc key to return to the top level display.

## Setpoint Configuration















Twelve user-configurable setpoints are available. The operator can select any combination of parameters from the following list:

- KW overload prealarm
- KW overload alarm
- over voltage
- under voltage
- over frequency
- under frequency
- reverse power
- reverse VARS
- reverse over current
- negative sequence over current
- negative sequence voltage

Additionally, the 8 digital inputs and switch-position input can be used as setpoints. Each setpoint allows the user to select:

- the parameter
- the trip level
- the reset level
- the trip time delay
- the reset time delay
- the digital output

The user can select any combination of the four available digital outputs and choose whether an acknowledgment is required to reset a tripped setpoint.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until Setpoints setup location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			First setpoint screen 'A'.
6			Press right arrow key. Second setpoint screen 'B'.
7			Saves the settings. Nothing is blinking.















Now press the **Esc** key to return to the top level display.



## Device 86 Configuration

The Device 86 feature, when enabled, latches output relay 1 closed whenever any setpoint configured to output relay 1 is tripped. The latch is only released by a user acknowledgement which can only occur if the condition causing the trip has met reset conditions. Device 86 is reset by the user at the Device 86 status screen on top level of display (see page 4-1).

The Device 86 configuration screen allows the user to enable or disable the feature.



















Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until Device 86 setup location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The word <b>NO</b> is blinking.
6			Press up or down arrow keys to change the setting.
7			Saves the settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## KW Setpoint Configuration

The *Power Manager Xp* provides the user with a dedicated programmable setpoint based on Watt Demand. With this setpoint function, the user can program the Power Manager to control one of the four built-in relays. When the watt demand register exceeds the SP-KWDemand Hi setting, the selected relay closes, and stays closed until the Watt Demand register falls below the SP-KWDemand Lo setting for a preset amount of time determined by the SP-Reset TD setting, upon which the relay opens (or releases).\* Select the output relay to be used for the setpoint function (choices include, DO1, DO2, DO3, DO4, or NOT USED) as follows:

\* Note that the selected relay will remain closed if another setpoint is configured to use it and if it is tripped.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until the <i>Clear Max Demand</i> location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The word <u>NO</u> is blinking.
6			Window Size is blinking.
7			SP-Output is blinking.
8			Press up & down arrow keys until correct output relay is displayed.
9			Saves the new setting. Nothing is blinking.

Now press the Esc key to return to the top level display.

## KW Demand High/Low Setpoints and Reset Time Delay

Selects the limits at which the SP-Output relay closes and opens. Refer to page 3-10. Set the Power Manager Xp's KW demand setpoints and reset time delay as follows (software prevents the *Hi* point from being set below the *Lo* point and it prevents the *Lo* point from being set above the *Hi* point):

**High Setpoint** ( *SP-KWDemand Hi* ) relay closes

















- Range                    maximum: 32,000 Kilowatts  
                                  minimum: SP-KWDemand Lo setpoint + 1 Kilowatt

**Low Setpoint** ( *SP-KWDemand Lo* ) relay opens

- Range                    maximum: SP-KWDemand Hi setpoint – 1 Kilowatt  
                                  minimum: 1 Kilowatt

**Reset Time Delay** ( *SP-Reset TD* ) delay on relay opening after a low

















- 0 to 99 minutes (in 1 minute increments)                    condition is met.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until <i>SP-KW Demand</i> location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The Hi setpoint is blinking.
6			Press up & down arrow keys until correct number is displayed.
7			Repeat steps 5 & 6 for the Lo setpoint and reset time delay value.
8			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Date and Time Setting









Set the current date and time. This setting is also used as a time stamp when recording log events and maximum watt demand.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until <i>Date and Time</i> appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The Day is blinking.
6			Press up & down arrow keys until correct day is displayed.
7			Repeat steps 5 & 6 for the rest of the date and time.
8			Saves the new settings. Nothing is blinking.

Now press the **Esc** key to return to the top level display.

## Event Log









The *Power Manager Xp* contains an event log which records up to 100 events as configured by the setpoints. The events are numbered 0 – 99 with event 0 being the most recent event. When more than 100 events occur, the oldest events are removed to record the newer events.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until <i>Event Log</i> appears.
4			Press up & down arrow keys to scroll through all recorded events.

Now press the **Esc** key to return to the top level display.

## Setup Log



















The *Power Manager Xp* contains a setup log which records up to 50 entries. This feature keeps track of changes made by the User to the Setpoints settings or to the Nominal settings. It records a description of the value being changed, the Time & Date stamp of the event, and the Old and New values. The events are numbered 0 – 49 with event 0 being the most recent event. When more than 50 events occur, the oldest events are removed to record the newer events.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until <i>Setup Log</i> appears.
4			Press up & down arrow keys to scroll through all recorded events.

Now press the **Esc** key to return to the top level display.

## Reset (clear) Setup Log

This screen allows the user to manually reset or clear the Setup Log which is described on page 3-20.

Step	Press	Display Shows	Comment
1			Brings you to top level if not already there.
2			
3			Press left & right arrow keys until clear setup log location appears.
4			Enter password as explained in steps 5 & 6 on page 3-1.
5			The Enable Device 86 word <u>NO</u> is blinking.
6			The Clear Setup Log word <u>NO</u> is blinking.
7			Press up & down arrow keys until the word <u>YES</u> appears.
8			Clears setup log. Changes back to NO.
9			Saves the new settings. Nothing is blinking.

Now press the Esc key to return to the top level display.

# Operation















From the top level display the 5200 Series *Power Manager Xp* can show the following information about the electrical power system:

- system totals (kW, kVAR, kVA, PF, Hz, position of ATS)
- current & voltage (line-to-neutral & line-to-line) – all phases
- power (kW), kVARs, kVA, & PF (power factor) – all phases
- Watt demand and maximum Watt demand, and time stamp
- average current & voltage (line-to-neutral & line-to-line)
- unbalance % amps & voltage (line-to-neutral & line-to-line)
- neutral current (if neutral is connected to Power Manager)
- kW hours (imp, exp, net) for Normal & Emergency sources
- kVAR hours (lag, lead, net) for Normal & Emergency sources
- 8 inputs and 4 relay outputs
- active alarms based upon setpoint configurations
- Device 86 status
- ID screen

Data is updated approximately every half second.

These are the screens for a 3 Ø, 4-wire wye system and monitored source is Load. Screens may be different for other electrical systems or other monitored sources.

These screens vary depending on the type of system selected.












Step	Press	Display Shows	Comment
1			Shows totals for kW, kVARs, kVA, PF, frequency, and position of the ATS.
2			Shows current & voltage (line-to-neutral, line-to-line) all phases.
3			Shows power (kW), kVAR, & VA on all phases.
4			Shows power (kW), kVAR, & power factor on all phases.
5			Shows Watt demand (instantaneous and maximum) and time stamp.
6			Shows average current & voltage (line-to-neutral & line-to-line) .
7			Shows neutral current if neutral is connected to Data Monitor.

Not used for 1 Ø systems.

Not used for 3 Ø, 3-wire or 1 Ø, 2-wire systems.

(continued on next page)



Shown only if monitored source is Normal.	8		<div style="border: 2px solid black; padding: 5px;">                 KWattHour – Normal                  IMP = 860                  EXP = 0                  NET = 861             </div>	Shows normal power usage (kWH) imported, exported, & total.
Shown only if monitored source is Emergency.	9		<div style="border: 2px solid black; padding: 5px;">                 KWattHour–Emergency                  IMP = 0                  EXP = 0                  NET = 0             </div>	Shows emergency power usage (kWH) imported, exported, & total.
Shown only if monitored source is Normal.	10		<div style="border: 2px solid black; padding: 5px;">                 KVARHour – Normal                  LAG = 0                  LEAD = 0                  NET = 0             </div>	Shows normal VAR usage (kVARHours) lag, lead, & total.
Shown only if monitored source is Emergency.	11		<div style="border: 2px solid black; padding: 5px;">                 KVARHour–Emergency                  LAG = 0                  LEAD = 0                  NET = 0             </div>	Shows emergency VAR usage (kVARHours) lag, lead, & total.
Only used if monitored source is Load.	12		<div style="border: 2px solid black; padding: 5px;">                 KVAHour – Normal                  NET = 874                  KVAHour–Emergency                  NET = 0             </div>	Shows normal & emergency kVA usage (kVA-Hours) totals.
	13		<div style="border: 2px solid black; padding: 5px;">                 ALARM STATUS                  No Active Alarms             </div>	Shows status of alarms as configured by setpoints.
	14		<div style="border: 2px solid black; padding: 5px;">                 DEVICE 86 STATUS                  Disabled                  Normal             </div>	Shows status of Device 86.
	15		<div style="border: 2px solid black; padding: 5px;">                 Status Input 1:INAC                  Status Input 2:INAC                  Status Input 3:ACTV                  Status Input 4:INAC             </div>	Shows the status of inputs 1–4 (INAC=off, ACTV=on).*
	16		<div style="border: 2px solid black; padding: 5px;">                 Status Input 5:INAC                  Status Input 6:INAC                  Status Input 7:INAC                  Status Input 8:INAC             </div>	Shows the status of inputs 5–8 (INAC=off, ACTV=on).*
	17		<div style="border: 2px solid black; padding: 5px;">                 Relay Output 1:CLSD                  Relay Output 2:CLSD                  Relay Output 3:OPEN                  Relay Output 4:OPEN             </div>	Shows status of relay outputs 1–4 (OPEN=off, CLSD=on).*
	18		<div style="border: 2px solid black; padding: 5px;">                 Power Manager Xp                  ASCO Power Technologies LP                  Copyright © 2000                  www.asco.com             </div>	Shows the ID screen.

Now press the **Esc** key to return to the top level display.

\* Power Manager Xps that are connected to PC devices display user– definable status input names, relay labels (15 characters), status (4 characters), name (8 characters), and location (20 characters).

# INDEX

## A

accessory numbers, 1-1  
accuracy, 1-4  
address, 3-6, 3-8  
ASCOBus I & ASCOBusII, 3-6, 3-8  
auxiliary contact, 2-2

## B

backlighting, 3-10  
baud rate, 3-6, 3-7, 3-8

## C

cable, communication, 2-3  
catalog numbers, cover  
cleaning, 1-2  
clear energy, 3-10  
clear max demand, 3-12  
clear setup log, 3-21  
connections, 2-2  
  **CAUTION** statement, 2-2  
  communication network, 2-3  
  current transformers, 2-2  
  ground, 2-3  
  output relays, 2-3  
  potential transformers, 2-2  
  power supply, 2-2  
  status input, 2-3  
  tightening torque, 2-2  
  transformer connections, 2-2  
communication, 3-6, 3-8  
control power, 2-2  
current inputs, 2-2  
current levels, 4-1  
current transformers, 2-2, 3-3  
  **DANGER** statement, 2-2

## D

date and time setting, 3-18  
Device 86 configuration, 3-15  
Display Catalog 5220D, cover, 1-1, 1-5

## E

electrical system type, 3-2  
energy level, reset, 3-10  
event log, 3-19

## F

frequency, 1-4, 1-5, 4-1

## H

Hi setpoint, KW demand, 3-17

## I

initial setup, 3-1  
inputs, 1-2, 1-5, 2-2, 4-2  
introduction, 1-1  
  general information, 1-1  
  measurement conventions, 1-3  
  measurement specifications, 1-4  
  device ratings, 1-5

## K

KW demand high / low setpoints  
and reset time delay, 3-17

KW setpoint configuration, 3-16

## L

labeling, 2-2  
Lo setpoint, KW demand, 3-17

## M

measurement conventions, 1-3  
measurement specifications, 1-4  
Modbus RTU, 3-6, 3-8  
mounting, 2-1

## O

operation, 4-1

## P

password selection, 3-1  
potential transformers, 2-2, 3-3  
power factor, 4-1  
power levels, 4-1  
power supply, 2-2  
power system total, 4-1  
protocol, 3-6, 3-8

## R

ratings, 1-5  
relay outputs, 2-3, 4-2  
reset energy level, 3-10  
reset event log, 3-10  
reset maximum demand level, 3-12  
reset time delay, KW demand, 3-17  
RS-485 Serial Communication  
Interface, 3-8

## S

serial communication interface, 3-6, 3-8  
servicing, 1-2  
setpoint, KW demand, 3-17  
setpoint configuration, 3-14  
setpoint output relay, 3-16  
setup log, 3-20  
SP-KW Demand, 3-17  
SP-Output, 3-16  
SP-Reset TD, 3-17  
source to monitor, 3-2  
status inputs, 2-3  
settings  
  communication, 3-6, 3-8  
  ct ratios, 3-5  
  electrical system type, 3-2  
  pt ratios, 3-5  
  reset energy level, 3-10  
  source to be monitored, 3-2

## T

Transducer Catalog 5220T, cover, 1-1, 1-5  
transfer switch position, 2-2, 4-1  
  **CAUTION** statement, 2-2

## U

usage, 4-1

## V

voltage inputs, 2-3  
voltage levels, 4-1

## W

watt demand, 1-1, 3-13, 4-1