



# GeneratorJoe

## STANDBY GENERATOR SET INSTALLATION, OPERATION, & MAINTENANCE MANUAL



### GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

Phone: **707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



## INDEX

Introduction	(Pages 2-4 are blank)
Safety	Pages 6 – 15
Installation	Pages 16-18
Exhaust	Pages 19-24
Cooling System	Pages 25-39
Ventilation	Pages 40-43
Fuel System	Pages 44-49
Electrical Installation	Pages 50-60
Operation	Page 61
Maintenance & Service	Pages 62-63
Troubleshooting	Page 64
Warranty	Pages 65-66



# GeneratorJoe

**GeneratorJoe**  
4723 Muirfield Court  
Santa Rosa, CA 95405  
**Phone: 707-539-9003**  
Fax: 707 539-5212  
Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)  
Web: [www.generatorjoe.net](http://www.generatorjoe.net)

# GeneratorJoe

## SAFETY!

PLEASE REVIEW THE FOLLOWING BEFORE PROCEEDING WITH INSTALLATION OR OPERATION OF YOUR **GENERATORJOE** GENERATOR SET.

Think Safety first at all times and when in doubt call GENERATORJOE and get additional information before performing installation, operation, service or testing of the generator set. Each section of this manual will have **caution!** and **warning!** information, which should be regarded with the utmost care. Repairs should only be done by properly trained personnel and under no circumstances should anyone proceed with a repair when they are not sure of proper procedure. This manual is not intended to be all that is required to properly operate this unit but is merely an aid to performing basic service to keep the unit in proper operating condition. Included with the unit should be an engine operator's guide and a generator operators guide to assist a generator technician in maintaining the unit.

Installation of the unit should be done in compliance with the installation section of this manual. Proper installation in accordance with the National Electric Code, Occupational Safety and Health Administration (OSHA) and local safety codes must be strictly complied with. Proper grounding is essential in preventing possible electrical shock and even death. Remember, safety begins with the owner/operator of the unit. Make sure to keep fingers, hair, jewelry and clothing away from the revolving parts of the generator set such as belts, fan blade and generator rotor fan

Operation of the unit should be first done by **GENERATORJOE** authorized start up personnel so that they make sure the unit was properly installed and is functioning properly with the load system being applied to the unit. The start up personnel will instruct the owner on basic procedures and will answer any questions the owner may have on general operation and maintenance.

Before performing routine maintenance, disconnect the unit from the load and disable the control system as discussed in the maintenance section, **Disabling the System**. Proper maintenance is the primary method of assuring the unit will operate when it is needed.

Review each of the sections before proceeding with installation or operation of the **GENERATORJOE** generator set. The following page lists some of the safety dos and don'ts that everyone should remember.



## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)

## Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

### DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

### WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

### CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**

### NOTE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

## Accidental Starting

### WARNING



**Accidental starting.**  
**Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

## Battery

### WARNING



**Sulfuric acid in batteries.**  
**Can cause severe injury or death.**

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

### WARNING



**Explosion.**  
**Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.**

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

**Battery gases. Explosion can cause severe injury or death.** Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove wristwatch, rings, and other jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

**Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death.** Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.



# Generator Joe


**Battery short circuits. Explosion can cause severe injury or death.**

Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove wristwatch, rings, and other jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

**Battery acid cleanup. Battery acid can cause severe injury or death.**

Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

**Engine Backfire/Flash Fire**


<b>⚠ WARNING</b>

<b>Fire.</b> <b>Can cause severe injury or death.</b> Do not smoke or permit flames or sparks near fuels or the fuel system.

**Servicing the fuel system. A flash fire can cause severe injury or death.**

Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

**Servicing the air cleaner. A sudden backfire can cause severe injury or death.** Do not operate the generator set with the air cleaner removed.

**Exhaust System**

<b>⚠ WARNING</b>

<b>Carbon monoxide.</b> <b>Can cause severe nausea, fainting, or death.</b> The exhaust system must be leakproof and routinely inspected.

**Copper tubing exhaust systems.**

**Carbon monoxide can cause severe nausea, fainting, or death.** Do not use copper tubing in diesel exhaust systems. Sulfur in diesel exhaust causes rapid deterioration of copper tubing exhaust systems, resulting in exhaust leakage.

**Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death.**

Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building unless the exhaust gas is piped safely outside. Never operate the generator set where exhaust gas could accumulate and seep back inside a potentially occupied building.


**Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death.**

Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea

If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

**Fuel System**

<b>⚠ WARNING</b>

<b>Explosive fuel vapors.</b> <b>Can cause severe injury or death.</b> Use extreme care when handling, storing, and using fuels.

**Draining the fuel system. Explosive fuel vapors can cause severe injury or death.**

Spilled fuel can cause an explosion. Use a container to catch fuel when draining the fuel system. Wipe up spilled fuel after draining the system.

**LP liquid withdrawal fuel leaks. Explosive fuel vapors can cause severe injury or death.**

Fuel leakage can cause an explosion. Check the LP liquid withdrawal gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to at least 90 psi (621 kPa). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.



# Generator Joe



**The fuel system. Explosive fuel vapors can cause severe injury or death.** Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

**Explosive fuel vapors can cause severe injury or death.** Take additional precautions when using the following fuels:

**Gasoline**—Store gasoline only in approved red containers clearly marked GASOLINE.

**Propane (LP)**—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

**Natural Gas**—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

**Fuel tanks. Explosive fuel vapors can cause severe injury or death.** Gasoline and other volatile fuels stored in day tanks or subbase fuel tanks can cause an explosion. Store only diesel fuel in tanks.

**Gas fuel leaks. Explosive fuel vapors can cause severe injury or death.** Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

### Hazardous Noise

**CAUTION**



**Hazardous noise. Can cause hearing loss.**

Never operate the generator set without a muffler or with a faulty exhaust system.

### Hazardous Voltage/ Electrical Shock

**DANGER**



**Hazardous voltage. Will cause severe injury or death.**

Disconnect all power sources before opening the enclosure.

*(over 600 volts)*

**DANGER**



**Hazardous voltage. Will cause severe injury or death.**

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

*(over 600 volts)*

**WARNING**



**Hazardous voltage. Can cause severe injury or death.**

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

*(600 volts and under)*

**WARNING**



**Hazardous voltage. Can cause severe injury or death.**

Disconnect all power sources before opening the enclosure.

*(600 volts and under)*

**WARNING**



**Hazardous voltage. Moving rotor. Can cause severe injury or death.**

Operate the generator set only when all guards and electrical enclosures are in place.

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

Phone: 707-539-9003


Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

<b>⚠ WARNING</b>

<p><b>Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.</b></p> <p>If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.</p>

**Grounding electrical equipment. Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Installing the battery charger. Hazardous voltage can cause severe injury or death.** An ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

**Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death.** Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

**Servicing the day tank. Hazardous voltage can cause severe injury or death.** Service the day tank electrical control module (ECM) as prescribed in the equipment manual. Disconnect the power to the day tank before servicing. Press the day tank ECM OFF pushbutton to disconnect the power. Notice that line voltage is still present within the ECM when the POWER ON light is lit. Ensure that the generator set and day tank are electrically grounded. Do not operate the day tank when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Short circuits. Hazardous voltage/current can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

**Engine block heater. Hazardous voltage can cause severe injury or death.** The engine block heater can cause electrical shock. Remove the engine block heater plug from the electrical outlet before working on the block heater electrical connections.

**Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death.** Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause serious injury or death to utility personnel working on power lines.

**Installing accessories to the transformer assembly. Hazardous voltage can cause severe injury or death.** To prevent electrical shock disconnect the harness plug before installing accessories that will be connected to the transformer assembly primary terminals on microprocessor logic models. Terminals are at line voltage.

**Making line or auxiliary connections. Hazardous voltage can cause severe injury or death.** To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

**Servicing the transfer switch. Hazardous voltage can cause severe injury or death.** Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**


Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

<b>⚠ WARNING</b>

<p><b>Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.</b></p> <p>If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.</p>

**Grounding electrical equipment. Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set, transfer switch, and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Installing the battery charger. Hazardous voltage can cause severe injury or death.** An ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

**Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death.** Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

**Servicing the day tank. Hazardous voltage can cause severe injury or death.** Service the day tank electrical control module (ECM) as prescribed in the equipment manual. Disconnect the power to the day tank before servicing. Press the day tank ECM OFF pushbutton to disconnect the power. Notice that line voltage is still present within the ECM when the POWER ON light is lit. Ensure that the generator set and day tank are electrically grounded. Do not operate the day tank when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Short circuits. Hazardous voltage/current can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove wristwatch, rings, and jewelry before servicing the equipment.

**Engine block heater. Hazardous voltage can cause severe injury or death.** The engine block heater can cause electrical shock. Remove the engine block heater plug from the electrical outlet before working on the block heater electrical connections.

**Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death.** Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause serious injury or death to utility personnel working on power lines.

**Installing accessories to the transformer assembly. Hazardous voltage can cause severe injury or death.** To prevent electrical shock disconnect the harness plug before installing accessories that will be connected to the transformer assembly primary terminals on microprocessor logic models. Terminals are at line voltage.

**Making line or auxiliary connections. Hazardous voltage can cause severe injury or death.** To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

**Servicing the transfer switch. Hazardous voltage can cause severe injury or death.** Deenergize all power sources before servicing. Open the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove rings, wristwatch, and jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)





# GeneratorJoe




Servicing the transfer switch controls and accessories within the enclosure. Hazardous voltage can cause severe injury or death. Disconnect the transfer switch controls at the inline connector to deenergize the circuit boards and logic circuitry but allow the transfer switch to continue to supply power to the load. Disconnect all power sources to accessories that are mounted within the enclosure but are not wired through the controls and deenergized by inline connector separation. Test circuits with a voltmeter to verify that they are deenergized before servicing.


### Heavy Equipment

<b>⚠ WARNING</b>

<p><b>Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.</b></p> <p>Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid.</p>

<b>⚠ WARNING</b>

<p><b>Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.</b></p> <p>Use adequate lifting capacity. Never leave the transfer switch standing upright unless it is securely bolted in place or stabilized.</p>

### Hot Parts



<b>⚠ WARNING</b>

<p><b>Hot coolant and steam. Can cause severe injury or death.</b></p> <p>Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.</p>


<b>⚠ WARNING</b>

<p><b>Hot engine and exhaust system. Can cause severe injury or death.</b></p> <p>Do not work on the generator set until it cools.</p>

**Servicing the exhaust system. Hot parts can cause severe injury or death.** Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

**Checking the coolant level. Hot coolant can cause severe injury or death.** Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise to the first stop. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank if the generator set has a coolant recovery tank.

### Moving Parts

<b>⚠ WARNING</b>	
	
<p><b>Hazardous voltage. Moving rotor. Can cause severe injury or death.</b></p> <p>Operate the generator set only when all guards and electrical enclosures are in place.</p>	

<b>⚠ WARNING</b>

<p><b>Rotating parts. Can cause severe injury or death.</b></p> <p>Operate the generator set only when all guards, screens, and covers are in place.</p>

**Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death.** Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

Phone: 707-539-9003

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

**SAFETY DO'S AND DON'TS DO PRACTICE SAFETY; The life you save may be your own**

---

**DO**

- Do perform your tasks carefully, without undue haste.
- Do provide fire extinguishers (rated ABC).
- Do provide a First Aid Kit (for burns and abrasions). Obtain medical attention.
- Do use the correct tools for the job you are doing
- Do make sure that all fasteners are secure.
- Do use extreme care while making adjustments on the generator set while it is running.
- Do keep your hands away from moving parts.
- Do remember - Horseplay is for horses! It has no place around machinery
- Do disconnect batteries before starting work on generator set.
- Do use screwdrivers, pliers, diagonal pliers, etc. with insulated handles.
- Do remember to keep one hand in your pocket if it is necessary to work on live circuits. To do so will prevent passage of electricity into one hand and out the other, which passes current across the heart.

**DON'T**

- Don't allow inexperienced personnel to work on the generator or electrical equipment.
- Don't remove plastic guards or protective devices.
- Don't wear loose clothing or jewelry in the vicinity of moving parts. These can get in machinery, with disastrous results. Don't wear jewelry while working on electrical equipment. If your hair is long, wear a head covering. Hair caught in a drill press, fan belt, or other moving parts can cause serious injury.
- Don't stand on a wet floor while working on electrical equipment. Use rubber insulated mats placed on dry wood plat forms
- Don't lunge after a dropped tool. To do so may place you in a position of extreme danger.
- Don't commence any operation until you have taken all the necessary steps to ensure that you are in complete safety.

**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**

## Low Voltage

Control circuits utilized by the generator set are D.C. voltage. This voltage potential is not considered dangerous, but the large amount of current available (over 300 amps) can cause severe burns if shorted to ground.

1. Disconnect the negative terminal of the battery if possible when working on the generator set. Disconnect the cable end that is away from the battery.
2. Do not wear jewelry, watches, or rings. These items can short out and cause severe burns to the wearer.

## General Safety Precautions

1. Use extreme caution if holes are drilled into the generator set. Holes drilled into an electrical wire can cause fire, explosion, or shock hazard.
2. Be sure all mounting screws are tight and are the correct length.
3. Keep tools and equipment clean and in good working condition. Accidents occur when you attempt procedures without the proper tools.



### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

## Safety Precautions

### Rotating Hazards

Keep your hands, clothing and tools clear of the fan and water pump belt when the generator set is running.

If it's necessary to run the generator with the end cover removed, be very careful with tools or meters being used in that area to avoid contacting the rotor.

### Battery Hazards

Few people realize just how dangerous a battery can be.

The electrolyte in a lead acid battery is dilute sulphuric acid (H<sub>2</sub>SO<sub>4</sub>). During charge or discharge functions of a battery, a chemical change takes place within the individual cells that causes the bubbling we see through the filler hole. This gas bubbling is hydrogen and oxygen, and it is EXPLOSIVE. If, during this gassing action, a means of ignition is present, an explosion could occur. A defective battery may suddenly explode even while standing idle. Added to this danger, consider a fall out of highly corrosive sulphuric acid caused by the explosion. A rubber blanket or other cover can be used to reduce the risk from possible explosion.

### Precautions

Always wear eye protection when servicing batteries. If electrolyte is splashed on the skin or in the eyes, flush immediately under running water. Obtain medical help as soon as possible.

When charging batteries, do not remove the vent caps.

When disconnecting or reconnecting the generator set battery, make sure the on-off switch is in the off position to prevent an arc, which could cause the battery to explode. Disconnect the ground cable first, preferably at a point away from the battery. Reconnect the ground cable last, again away from the battery.

### Electrical Hazards

#### High Voltage

When servicing or repairing a generator set, the possibility of serious or even fatal injury from electrical shock exists. Extreme care must be used when working with an operating generator. Lethal voltage potentials can exist on connections that are in the exciter control box.

#### Precautions

When working on high voltage circuits on the generator set, do not make any rapid moves. If a tool drops do not grab for it. People do not contact high voltage wires on purpose. It normally occurs from an unplanned movement.

Make sure of your footing. If you slip you will instinctively grab for support. This can be lethal around a generator set. Work on rubber mats or dry wood if possible.

Use tools with insulated handles that are in good condition. Never hold metal tools in your hand if exposed, energized conductors are within reach

Treat all wires and connections as high voltage until a meter and wiring diagram show otherwise.

IMMEDIATE action must be initiated after a person has received an electric shock

Obtain expert medical assistance if available.

The source of shock must be immediately removed by either shutting down the generator power or removing the victim from the source. If it is not possible to shut off the generator set, the wire should be cut with either an insulated instrument such as a wooden handled axe or cable cutters with heavy insulated handles, or a rescuer wearing insulated gloves. Whichever method is used, do not look at the wire while it is being cut. The ensuing flash can cause blindness. Remember that insulated gloves are manufactured for protection from liquids. If the victim has to be removed from live circuitry, knock him off. **DO NOT TOUCH HIM**, you could receive a shock from current flowing through his body. After separating the victim and power source, check immediately for respiration and presence of a pulse. If a pulse is present, respiration can be restored by mouth-to-mouth resuscitation.

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

Phone: 707-539-9003

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

## Installation

---

### MOUNTING

The foundation, floor or roof must be able to support the weight of the generator set and its accessories (such as a sub-base fuel tank), resist dynamic loads and not transmit objectionable noise and vibration. See the generator set Specification Sheet or outline drawing for the weight of the generator set and its mounting points.

### Vibration Isolators


Figure 19 illustrates a steel spring vibration isolator of the type required for mounting the larger

**GENERATORJOE** generator sets even those models which have rubber vibration isolators between the skid and the engine-generator assembly. Steel spring isolators of this type can provide up to 98 percent reduction in the force of the vibration transmitted. Locate the isolators as shown on the generator set outline drawing referenced on the Specification Sheet. The outline drawing may show configurations involving 4, 6, 8, or 12-point mounting. Also, when the generator set is mounted on top of a sub-base fuel tank, the vibration isolators must be installed between the generator set and the fuel tank.

Bolting these generator sets directly to the floor or foundation will result in excessive noise and vibration and possible damage to the set, the floor, and other equipment.

Smaller **GENERATORJOE** generator sets have rubber vibration isolators located between the skid and the engine-generator assembly. They may be bolted directly to the foundation, floor or sub-structure.

**FIGURE 19**  
**TYPICAL STEEL SPRING VIBRATION ISOLATOR**





## Mounting on a Slab Floor

When a generator set is mounted on a concrete slab floor, a concrete pad should be poured on top of the floor. The pad should be reinforced concrete with a 28 day compressive strength of at least 2500 psi (173 kPa). It should be at least 6 inches (150 mm) deep and extend at least 6 inches (150 mm) beyond the skid on all sides. Type J or L bolts should be used to anchor the skid or vibration isolators to the pad.

## Mounting on a Sub-Base Fuel Tank

When a generator set is mounted on a sub-base fuel tank, the vibration isolators must be installed between the generator set and the fuel tank. The fuel tank must be able to support the weight of the set and resist the dynamic loads. It is recommended that the tank be mounted such that an air space is included between the bottom of the tank and the floor underneath to reduce corrosion and permit visual inspections for leaks.

## Mounting on a Vibration Isolating Foundation

When a generator set is mounted on a foundation to reduce the transmission of vibrations to the building, the weight (W) of the foundation should be at least 2 times the weight of the set itself to resist dynamic loading. (The weight of fuel in a sub-base fuel tank should not be considered as contributing to the weight required of a vibration isolating foundation.) Figure 20 illustrates a typical vibration isolating foundation. Consider the following:

- The foundation should extend at least 6 inches (150 mm) beyond the skid on all sides. This determines the length (L) and width (W) of the foundation.
- Calculate the height (H) of the foundation necessary to obtain the required weight (W) by using the following formula:

$$H = \frac{W}{D \times L \times W}$$

Where (D) is the density of concrete, typically 145 lbs / ft<sup>3</sup> ( 2322 kg / m<sup>3</sup> ).

- The foundation should extend at least 6 inches (150 mm) above the floor to make service and maintenance of the generator set easier.
- The foundation must extend below the frost line to prevent heaving.
- The foundation should be reinforced concrete with a 28 day compressive strength of at least 2500 psi (173 kPa).
- The total weight (TW) of the generator set, fuel and foundation usually results in a soil bearing load (SBL) of less than 2000 lbs/ft<sup>2</sup> (96 kPa). Although this is within the load bearing capacity of most soils, always find out the allowable soil bearing load by checking the local code and the soil analysis report for the building. Calculate the soil bearing load by using the following formula:

$$SBL = \frac{TW}{L \times W}$$

Where L and W are the length and width of the foundation.



# Generator Joe

- Type J or L bolts should be used to anchor the skid or vibration isolators to the foundation.




FIGURE 20  
TYPICAL VIBRATION ISOLATING FOUNDATION



**GeneratorJoe**

## EXHAUST SYSTEM

The function of the exhaust system is to convey engine exhaust safely to the out-of-doors and to disperse the exhaust fumes, soot and noise away from people and buildings. See Figure 21. Consider the following (also review Location and Noise under Application):

- Flexible, corrugated stainless steel exhaust tubing at least 24 inches (610 mm) long must be connected to the engine exhaust outlet(s) to take up thermal expansion and generator set movement and vibration whenever the set is mounted on steel spring isolators of the type shown in Figure 19. Smaller sets that are bolted directly to the floor must be connected by corrugated stainless steel exhaust tubing at least 18 inches (457 mm) long. Flexible tubing must not be used to form bends or to compensate for misaligned piping.
- To reduce corrosion due to condensate, a muffler should be installed as close as practical to the engine so that it heats up quickly.
- Mufflers and piping must be supported by non-combustible hangers or supports—not by the engine exhaust outlet. Weight on the engine exhaust outlet can cause damage to the engine exhaust manifold or reduce the life of a turbocharger.
- Schedule 40 black iron pipe is recommended for exhaust piping.




FIGURE 21. TYPICAL EXHAUST SYSTEM



# Generator Joe

- Pipe bend radii should be as long as practical.
- It is recommended that, as far as is possible and consistent with the exhaust back pressure limitations of the engine, exhaust tubing and piping of the same nominal diameter as the engine exhaust outlet be used throughout the exhaust system. **Piping of smaller diameter than the exhaust outlet must never be used.** Piping that is larger than necessary is more subject to corrosion due to condensate than smaller pipe and reduces the exhaust gas velocity available for dispersing the exhaust gases up and into the outdoor wind stream. Also, as a rule, the fewer pipe diameter changes in the exhaust system, the less friction loss.
- It is recommended that all exhaust piping and mufflers be thermally insulated to prevent burns from accidental contact, prevent activation of tire detection devices and sprinklers reduce corrosion due to condensate and reduce the amount of heat radiated to the generator room. **Engine exhaust manifolds and turbocharger housings, unless water cooled, must never be insulated.** Doing so can result in material temperatures that can destroy the manifold and turbocharger.
- Exhaust piping must be routed at least 9 inches (229 mm) from combustible construction. Use approved thimbles where exhaust piping must pass through combustible walls or ceilings.
- Exhaust pipe (steel) expands approximately 0.0076 inches per foot of pipe for every 100° F rise in exhaust gas temperature above room temperature (1.14mm per meter per 100° C rise). It is recommended that flexible, corrugated stainless steel tubing be used to take up expansion in long, straight runs of pipe.
- Horizontal runs of exhaust piping should slope downwards, away from the engine, to the out-of-doors or to a condensate trap.
- A condensate drain trap and plug should be provided where piping turns to rise vertically.
- The exhaust system must terminate out-of-doors at a location where engine exhaust will disperse away from buildings and building air intakes and not blacken walls and windows with soot. It is highly recommended that the exhaust system be carried up as high as practical on the downwind side of buildings and that it discharge straight up to maximize dispersal.

*Some codes specify that the exhaust outlet terminate at least 10 feet from the Property line, 3 feet from an exterior wall or roof, 10 feet from openings into the building and at least 10 feet above the adjoining grade.*

- A rain cap should be provided if the exhaust outlet points up.
- A generator set should not be connected to an exhaust system serving other equipment, including other generator sets. Soot, corrosive condensate and high exhaust gas temperatures can damage idle equipment served by a common exhaust system.



## **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# **GeneratorJoe**

- Exhaust backpressure must not exceed the allowable back pressure on the generator set Specification Sheet. Excessive exhaust backpressure reduces engine power and engine life and may lead to high exhaust temperatures and smoke. Engine exhaust back pressure should be estimated before the layout of the exhaust system is finalized and it should be measured at the exhaust outlet under full-load operation before the set is placed in service

**Example Calculation:** The layout of an exhaust system similar to that shown in Figure 21 calls for a 5-inch diameter by 24-inch long flexible tube at the engine exhaust outlet, a critical grade muffler with a 6-inch diameter inlet, 20 feet of 6-inch diameter pipe and one 6-inch diameter long radius elbow. The generator set Specification Sheet indicates that the engine exhaust gas flow is 2,715 cfm (cubic feet per minute) and that the maximum allowable exhaust backpressure is 41 inches WC (Water Column).

*This procedure involves determining the exhaust backpressure caused by each element (flexible tubes, mufflers, elbows and pipes) and then comparing the sum of the backpressures with the maximum allowable backpressure.*

- Determine the exhaust backpressure caused by the muffler. Figure 22 is a graph of exhaust backpressures for mufflers made available by **GeneratorJoe**. If the muffler is from another source, it will be necessary to obtain equivalent data from the muffler manufacturer. To use Figure 22:
  - Find the cross-sectional area of the muffler inlet using Table 7 (0.1963 ft<sup>2</sup> in this example).
  - Find exhaust gas velocity in feet per minute (fpm) by dividing exhaust gas flow (cfm) by the area of the muffler inlet, as follows:

$$\text{Gas Velocity} = \frac{2,715 \text{ cfm}}{0.1963 \text{ ft}^2} = 13,831 \text{ fpm}$$

- In this example, the dashed lines in Figure 22 show that the critical grade muffler will cause a backpressure of approximately 21.5 inches W.C.

**TABLE 7. CROSS-SECTIONAL AREAS OF OPENINGS OF VARIOUS DIAMETER**

DIAMETER OF MUFFLER INLET (INCHES)	AREA OF MUFFLER INLET (FT <sup>2</sup> )	DIAMETER OF MUFFLER INLET (INCHES)	AREA OF MUFFLER INLET (FT <sup>2</sup> )
2	0.0218	5	0.1363
2.5	0.0341	6	0.1963
3	0.0491	8	0.3491
3.5	0.0668	10	0.5454
4	0.0873	12	0.7854

**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**






FIGURE 22. TYPICAL MUFFLER EXHAUST BACK PRESSURE VS. GAS VELOCITY



**GeneratorJoe**

- Find the equivalent lengths of all fittings and flexible tube sections by using Table 8.

**TABLE 8. EQUIVALENT LENGTHS OF PIPE FITTINGS (FEET)**

TYPE OF FITTING	NOMINAL DIAMETER (INCHES)									
	2	2.5	3	3.5	4	5	6	8	10	12
STANDARD ELBOW	5.3	6.4	8.1	9.6	11	14	16	21	26	32
MEDIUM RADIUS ELBOW	4.6	5.4	6.8	8	9	12	14	18	22	26
LONG RADIUS ELBOW	3.5	4.2	5.2	6	7	9	11	14	17	20
45° ELBOW	1.5	2	2.3	2.6	3	4	4.5	6	8	9
STANDARD TEE	13	14	17	19	22	27	34	44	56	67
18 INCH FLEXIBLE TUBE	3	3	3	3	3	3	3	3	3	3
24 INCH FLEXIBLE TUBE	4	4	4	4	4	4	4	4	4	4

- Find the backpressure at the given exhaust flow per unit length of pipe for each nominal pipe diameter used in the system. In this example, 5 inch and 6 inch nominal pipe is used. Following the dashed lines in Figure 23, 5 inch pipe causes a backpressure of approximately 0.35 inches WC (Water Column) and 6 inch pipe approximately 0.145 inches WC.
- Add the back pressures for all elements of the example, as follows:

Muffler .....	21.5
One 5 Inch Flexible Tube—0.35 x 4 ft.....	1.4
20 Feet of 6-Inch Pipe—0.145 x 20 ft.....	2.9
One 6-Inch, Long Radius Elbow—0.145 x 11 ft.....	1.6
<b>TOTAL EXHAUST BACK PRESSURE (Inches WC).....</b>	<b>27.4</b>

- The calculation indicates that the piping layout is adequate in terms of exhaust backpressure since the sum of the backpressures is less than the maximum allowable backpressure of 41 Inches WC.



**GeneratorJoe**  
 4723 Muirfield Court  
 Santa Rosa, CA 95405  
**Phone: 707-539-9003**  
 Fax: 707 539-5212  
 Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)  
 Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe




FIGURE 23. EXHAUST BACK PRESSURE IN NOMINAL INCH (mm) PIPE DIAMETERS



# GeneratorJoe

## ENGINE COOLING

Liquid-cooled engines are cooled by pumping coolant (a mixture of water and anti-freeze) through passages in the engine cylinder block and head(s) by means of an engine-driven pump. The engine, pump and radiator or liquid-to-liquid heat exchanger form a closed, pressurized cooling system. The most common generator set configuration has a mounted radiator and engine-driven fan to cool the coolant and ventilate the generator room. Alternative methods for cooling the coolant include a mounted liquid-to-liquid heat exchanger, a remote radiator or a remote liquid-to-liquid heat exchanger.



### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)




# GeneratorJoe

## Factory-Mounted Radiator

A generator set with a factory-mounted radiator (Figure 24) is an integral cooling and ventilating system. This is the recommended configuration involving the least amount of auxiliary equipment, piping, control wiring and coolant. A primary consideration for installations of this type is the necessity of moving large quantities of air through the generator room. See Ventilation in this section.

FIGURE 24. FACTORY-MOUNTED RADIATOR COOLING



# Generator Joe



## Factory-Mounted Heat Exchanger

- The engine, pump and liquid-to-liquid heat exchanger form a closed, pressurized cooling system. The engine coolant and raw cooling water do not mix, Consider the following:
- The installation will require a powered ventilating system. See Ventilation in this section.
- To obtain the net power available from the generator set, add the fan load indicated on the generator set Specification Sheet to the power rating of the set and subtract the power consumed by the remote radiator fan, ventilating fans, coolant pumps and other accessories required for the set to run.
- A pressure-reducing valve must be provided if water source pressure exceeds the heat exchanger pressure rating on the generator set Specification Sheet.
- The heat exchanger and water piping must be protected from freezing if the ambient temperature can fall below 32° F (0° C).
- Recommended options include a thermostatic water valve (non-electrical) to modulate water flow in response to coolant temperature and a normally closed (NC) battery-powered shut off valve to shut off the water when the set is not running.
- There must be sufficient raw water flow to remove the Heat Rejected To Coolant indicated on the generator set Specification Sheet. Note that a gallon of water absorbs approximately 8 Btu each 1° F rise in temperature (specific heat). Also, it is recommended that the raw water leaving the heat exchanger not exceed 140° F (60° C). Therefore:

If a set  
19,200  
minute and the raw water inlet temperature is 80° F, allowing a water temperature rise of 60° F:

$$\text{Raw Water Required (gpm)} = \frac{\text{Heat Rejected (Btu/Min)}}{\text{Temp. Rise } (\Delta \text{ } ^\circ\text{F}) \times \text{Specific Heat (8 Btu/}^\circ\text{F-Gallon)}} \text{ rejects Btu per}$$

$$\text{Raw Water Required} = \frac{19,200}{60 \times 8} = 40\text{gpm}$$

## Remote Heat Exchanger

Remote heat exchanger systems can become very complex, taking a variety of configurations, especially if a secondary cooling system, such as a radiator, is used to cool the heat exchanger. Most of the considerations above and on the following pages discussing remote radiator systems apply. Careful design is required to ensure reliable, adequate cooling.



### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe




FIGURE 25. FACTORY-MOUNTED HEAT EXCHANGER COOLING

**GeneratorJoe**

4723 Muirfield Court  
 Santa Rosa, CA 95405

Phone: **707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**

## Remote Radiator

Application of a remote radiator to cool the engine requires careful design. Figures 26, 28 and 29 illustrate typical applications. Consider the following:

- It is recommended that the radiator and fan be sized on the basis of a maximum radiator top tank temperature of 200° F (93° C) and a 115 percent cooling capacity to allow for fouling. The generator set Specification Sheet indicates the Heat Rejected To Coolant and Coolant Flow Rate necessary for radiator sizing according to the radiator manufacturer's instructions.
- The capacity of the radiator top tank or auxiliary tank must be equivalent to at least 15 percent of the total volume of coolant in the system to provide a coolant "drawdown capacity" (10 percent) and space for thermal expansion (5 percent). Drawdown capacity is the volume of coolant that can be lost by slow, undetected leaks and the normal relieving of the pressure cap before air is drawn into the coolant pump. Space for thermal expansion is created by the fill neck when a cold system is being filled. See Figure 27.
- To reduce radiator fin fouling, radiators having a more open fin spacing (nine fins or less per inch) should be considered for dirty environments.
- Coolant friction head external to the engine (pressure loss due to pipe, fitting and radiator friction) and coolant static head (height of liquid column measured from crankshaft centerline) must not exceed the maximum allowable values on the generator set Specification Sheet. See the example calculation below for a method of calculating coolant friction head.

Excessive coolant static head (pressure) can cause the coolant pump shaft seal to leak.

Excessive coolant friction head (pressure loss) will result in insufficient engine cooling.

- Radiator hose 6 to 18 inches (152 to 457mm) long, complying with SAE 20R1, or equivalent standards, should be used to connect coolant piping to the engine to take up generator set movement and vibration.
- It is highly recommended that the radiator hoses be clamped with two premium grade "constant-torque" hose clamps at each end to reduce the risk of sudden loss of engine coolant due to a hose (which is under pressure) slipping off. Major damage can occur to an engine if it is run without coolant in the block just a few seconds.
- A drain valve should be located at the lowest part of the system
- Depending on the amount of coolant in the system, ball or gate valves (globe valves are too restrictive) are recommended to isolate the engine so that the entire system does not have to be drained before servicing the engine.
- To obtain the net power available from the generator set, add the fan load indicated on the generator set Specification Sheet to the power rating of the set and subtract the power consumed by the remote radiator fan, ventilating fans, coolant pumps and other accessories required for the set to run.

### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe




FIGURE 26. REMOTE RADIATOR COOLING (DEAERATION TYPE SYSTEM, SEE FIGURE 27)



# Generator Joe

**Deaeration Type Remote Radiator System:** A deaeration type of radiator top tank (also known as a sealed top tank) or auxiliary tank must be provided for 150 kW and larger generator sets. In this system, a portion of the coolant flow (approximately 5 percent) is routed to the radiator top tank, above the baffle plate, where air in the coolant can separate from the coolant before the coolant returns to the system. Consider the following:

- Engine and radiator vent lines must rise without any dips or traps that will collect coolant and prevent air from venting when the system is being filled. Rigid steel or high density polystyrene tubing is recommended for long runs, especially if they are horizontal, to prevent sagging between supports.
- The fill/makeup line should also rise without any dips from the lowest point in the piping system to the connection at the radiator top tank or auxiliary tank. No other piping should be connected to it. This arrangement allows the system to be filled from bottom up without trapping air and giving a false indication that the system is full. With proper vent and fill line connections, it should be possible to fill the system at a rate of at least 5 gpm (19 L/Min) (approximately the flow rate of a garden hose).



**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**






FIGURE 27. DEAERATION TYPE OF RADIATOR TOP TANK



**GeneratorJoe**

**Remote Radiator with Auxiliary Coolant Pump:** A remote radiator with an auxiliary coolant pump (Figure 28) can be used if coolant friction exceeds the allowable value on the generator set Specification Sheet. In addition to the considerations under Remote Radiators, consider the following:

- An auxiliary pump and motor must be sized for the coolant flow indicated on the generator set Specification Sheet and develop enough head (pressure) to overcome the excess coolant friction head calculated by the method shown in the example above.

One foot of pump head (pump manufacturer's data) is equivalent to 0.43 PSI of coolant friction head (pressure loss) or one foot of coolant static head (height of liquid column).

- A bypass gate valve (globe valves are too restrictive) must be plumbed in parallel with the auxiliary pump, for the following reasons:
  - To allow adjustment of the head developed by the auxiliary pump (the valve is adjusted to a partially-open position to recirculate some of the flow back through the pump).
  - To allow operation of the generator set under partial load if the auxiliary pump fails (the valve is adjusted to a fully open position).
- Coolant pressure at the inlet to the engine coolant pump, measured while the engine is running at rated speed, must not exceed the maximum allowable static head shown on the generator set Specification Sheet. Also, for deaeration type cooling systems (150 kW and larger generator sets), auxiliary pump head must not force coolant through the make-up line into the radiator top tank or auxiliary tank. In either case, the pump bypass valve must be adjusted to reduce pump head to an acceptable level.
- To obtain the net power available from the generator set, add the fan load Indicated on the generator set Specification Sheet to the power rating of the set and subtract the power consumed by the remote radiator fan, ventilating fans, coolant pumps and other accessories required for the set to run.



**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**




FIGURE 28. REMOTE RADIATOR WITH AUXILIARY COOLANT PUMP AND AUXILIARY TANK



# GeneratorJoe

**Remote Radiator with Hot Well:** A remote radiator with a hot well (Figure 29) can be used if the elevation of the radiator above the crankshaft centerline exceeds the allowable coolant static head on the generator set Specification Sheet. In a hot well system, the engine coolant pump circulates coolant between engine and hot well and an auxiliary pump circulates coolant between hot well and radiator. A hot well system requires careful design. In addition to the considerations under Remote Radiator, consider the following:

- The bottom of the hot well should be above the engine coolant outlet.
- Coolant flow through the hot well/radiator circuit should be approximately the same as coolant flow through the engine. The radiator and the auxiliary pump must be sized accordingly. Pump head must be sufficient to overcome the sum of the static and friction heads in the hot well/radiator circuit.
- One foot of pump head (pump manufacturer's data) is equivalent to 0.43 PSI of coolant friction head (pressure loss) or one foot of coolant static head (height of liquid column).
- The liquid holding capacity of the hot well should not be less than the sum of the following volumes:
  - 1/4 of the coolant volume pumped per minute through the engine (eg., 25 gallons if the flow is 100 gpm), plus
  - 1/4 of the coolant volume pumped per minute through the radiator (eg., 25 gallons if the flow is 100 gpm), plusVolume required to fill the radiator and piping, plus  
Five percent of total system volume for thermal expansion
- Careful design of the inlet and outlet connections and baffles is required to minimize coolant turbulence, allow free deaeration and maximize blending of engine and radiator coolant flows.
- Coolant must be pumped to the bottom tank of the radiator and returned from the top tank otherwise the pump will not be able to completely fill the radiator.
- The auxiliary pump must be lower than the low level of coolant in the hot well so that it will always be primed.
- The radiator should have a vacuum relief check valve to allow drain down to the hot well.
- The hot well should have a high volume breather cap to allow the coolant level to fall as the auxiliary pump fills the radiator and piping.
- To obtain the net power available from the generator set, add the fan load indicated on the generator set Specification Sheet to the power rating of the set and subtract the power consumed by the remote radiator fan, ventilating fans, coolant pumps and other accessories required for the set to run.

**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**




FIGURE 29. REMOTE RADIATOR WITH HOT WELL AND AUXILIARY COOLANT PUMP



**Example Pipe Sizing Calculations for Remote Radiator/Heat Exchanger Systems:**

The preliminary layout of piping for a remote radiator cooling system similar to the one shown in Figure 26 calls for 60 feet of 3-inch diameter pipe, three long sweep elbows, two gate valves to isolate the radiator for engine servicing and a tee to connect the fill/makeup line. The generator set Specification Sheet indicates that coolant flow is 123 GPM and that the allowable friction head is 5 PSI.

This procedure involves determining the pressure loss (friction head) caused by each element and then comparing the sum of the pressure losses with the maximum allowable friction head.

1. Determine the pressure loss in the radiator by referring to the radiator manufacturer’s data. For this example, assume the pressure loss is 1 psi at a flow of 123 gpm.
2. Find the equivalent lengths of all fittings and valves by using Table 9 and add to the total run of straight pipe.

Three Long Sweep Elbows-3 x 5.2 .....	15.6
Two Gate Valves (Open)0-2 x 1.7.....	3.4
Tee (Straight Run).....	5.2
60 Feet Straight Pipe.....	<u>60.0</u>
<b>EQUIVALENT LENGTH OF PIPE (FEET).....</b>	<b>84.2</b>

3. Find the backpressure at the given flow per unit length of pipe for the nominal pipe diameter used in the system. In this example, 3 inch nominal pipe is used. Following the dashed lines in Figure 30, 3 inch pipe causes a pressure loss of approximately 1.65 psi per 100 foot of pipe.
4. Calculate the pressure loss in the piping as follows:

$$\text{Piping Loss} = 84.2 \text{ feet} \times \left( \frac{1.65 \text{ psi}}{100 \text{ feet}} \right) = 1.39 \text{ psi}$$

5. The total system loss is the sum of the piping and radiator losses:

$$\text{Total Pressure Loss} = 1.39 \text{ psi (piping)} + 1.00 \text{ psi (radiator)} = 2.39 \text{ psi}$$

6. The calculation for this example indicates that the layout of the remote radiator cooling system is adequate in terms of coolant friction head since it is not greater than the allowable friction head. If a calculation indicates excessive coolant friction head, repeat the calculation using the next larger pipe size. Compare the advantages and disadvantages of using larger pipe with that of using an auxiliary coolant pump.

**GeneratorJoe**  
 4723 Muirfield Court  
 Santa Rosa, CA 95405  
**Phone: 707-539-9003**  
 Fax: 707 539-5212  
 Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)  
 Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**

TABLE 9. EQUIVALENT LENGTHS OF PIPE FITTINGS AND VALVES (FEET)

TYPE OF FITTING	NOMINAL DIAMETER (INCHES)						
	1.5	2	2.5	3	4	5	6
90° ELBOW	4.4	5.5	6.5	8	11	14	16
45° ELBOW	-	2.5	3	3.8	5	6.3	7.5
LONG SWEEP ELBOW	2.8	3.5	4.2	5.2	7	9	11
CLOSE RETURN BEND	-	13	15	18	24	31	37
TEE, STRAIGHT RUN	-	3.5	4.2	5.2	7	9	11
TEE, SIDE INLET OR OUTLET	9.3	12	14	17	22	27	33
GLOBE VALVE, FULLY OPEN	-	55	67	82	110	140	-
ANGLE VALVE, FULLY OPEN	-	27	33	41	53	70	-
GATE VALVE, FULLY OPEN	-	1.2	1.4	1.7	2.3	2.9	3.5
GLOBE VALVE, HALF OPEN	-	27	33	41	53	70	100




FIGURE 30. FRICTIONAL PRESSURE LOSSES FOR INCH (mm) DIAMETER PIPES

## Coolant Treatment

Antifreeze (ethylene or propylene glycol base) and water are mixed to lower the freezing point of the cooling system and to raise the boiling point. Refer to Table 10 to determine the concentration of ethylene or propylene glycol necessary for protection against the coldest ambient expected. Antifreeze/water mixture percentages in the range of 30/70 to 60/40 are recommended for most applications.

Propylene glycol based antifreeze is less toxic than ethylene based antifreeze, offers superior liner protection and eliminates some fluid spillage and disposal reporting requirements.

Diesel generator sets may be equipped with replaceable coolant filtering and treating elements to minimize coolant system fouling and corrosion. They are compatible with most antifreeze formulations. For smaller sets, the antifreeze should contain a corrosion inhibitor.

TABLE 10. FREEZING AND BOILING POINTS VS. CONCENTRATION OF ANTIFREEZE

MIXTURE BASE		MIXTURE PERCENTAGES (ANTIFREEZE/WATER)					
		0/100	30/70	40/60	50/50	60/40	95/5
ETHYLENE GLYCOL	FREEZING POINT	32° F (0° C)	4° F (-16° C)	-10° F (-23° C)	-34° F (-36° C)	-65° F (-54° C)	8° F (-13° C)
	BOILING POINT	212° F (100° C)	220° F (104° C)	222° F (106° C)	226° F (108° C)	230° F (110° C)	345° F (174° C)
PROPYLENE GLYCOL	FREEZING POINT	32° F (0° C)	10° F (-12° C)	-6° F (-21° C)	-27° F (-33° C)	-56° F (-49° C)	-70° F (-57° C)
	BOILING POINT	212° F (100° C)	216° F (102° C)	219° F (104° C)	222° F (106° C)	225° F (107° C)	320° F (160° C)

## Coolant Heaters

Thermostatically controlled engine coolant heaters are usually required for starting. For Level 1 emergency power systems, NFPA 110 requires that engine coolant be kept at a minimum of 90°F (32°C).

Engine coolant heaters must be connected to the normal power source.



### GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

Phone: **707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

## VENTILATION

Ventilation of the generator room is necessary to remove the heat and fumes dissipated by the engine, generator and its accessories and to provide combustion air.

### Factory-mounted Radiator Ventilation

In this configuration (Figure 31), the fan draws air over the set and pushes it through the radiator; which has flanges for connecting a duct to the out-of-doors. Consider the following:

- See the generator set Specification Sheet for the design airflow through the radiator, allowable airflow restriction and minimum air inlet and outlet opening areas. The allowable airflow restriction must not be exceeded. The static pressure (air flow restriction) should be measured as shown in Figures 31 and 32 to confirm, before the set is placed in service, that the system is not too restrictive, especially when ventilating air is supplied and discharged through long ducts, restrictive grilles, screens and louvers.
- Refer to the ASHRAE (American Society of Heating, Refrigeration and Air Conditioning Engineers) publications for recommendations on duct design if air ducts are required for the application. Note that the inlet duct must handle combustion airflow (see the Specification Sheet) as well as ventilating airflow and must be sized accordingly.




FIGURE 31. FACTORY-MOUNTED RADIATOR COOLING

- Louvers and screens over air inlet and outlet openings restrict airflow and vary widely in performance. A louver assembly with narrow vanes, for example, tends to be more restrictive than one with wide vanes. The effective open area specified by the louver or screen manufacturer should be used.
- The airflow through the radiator is usually sufficient for generator room ventilation. See the example calculation for a method of determining the airflow required to meet room air temperature rise specifications, if any.
- Because the radiator fan will cause a slight negative pressure in the generator room, it is highly recommended that combustion equipment such as the building heating boilers not be located in the same room as the generator set. If this is unavoidable, it will be necessary to determine whether there will be detrimental effects, such as back draft, and to provide means (extra large room inlet openings and/or ducts, pressurizing fans, etc.) to reduce the negative pressure to acceptable levels.
- In colder climates, automatic dampers should be used to close off the inlet and outlet air openings to keep the generator room warm when the set is not running. And, a thermostatic damper should be used to re-circulate a portion of the radiator discharge air to reduce the volume of cold air that is pulled through the room when the set is running. The inlet and outlet dampers must fully open when the set starts. The re-circulating damper should close fully at 60°F (16°C).
- Other than re-circulating radiator discharge air into the generator room in colder climates, all ventilating air must be discharged directly to the out-of-doors. It must not be used to heat any space other than the generator room.
- A flexible duct connector must be provided at the radiator to take up generator set movement and vibration and prevent transmission of noise.
- Ventilating air inlet and discharge openings should be located or shielded to minimize fan noise and the effects of wind on airflow.




FIGURE 32. RECOMMENDED INSTRUMENTATION FOR MEASURING AIR FLOW RESTRICTION



# Generator Joe



## Heat Exchanger Or Remote Radiator Ventilation

A heat exchanger or remote radiator cooling system might be selected because of noise considerations or because the airflow restriction through long ducts would be greater than that allowed for the engine-driven radiator fan. Consider the following:

- Ventilating fans must be provided for the generator room. The ventilating fans must have the capacity of moving the required flow of ventilating air against the airflow restriction. See the following example calculation for a method of determining the airflow required for ventilation.
- A remote radiator fan must be sized primarily to cool the radiator. Depending on its location, it might also be used to ventilate the generator room.
- The fan and air inlet locations must be such that the ventilating air is drawn forward over the set.
- To obtain the net power available from the generator set, add the fan load indicated on the generator set Specification Sheet to the power rating of the set and subtract the power consumed by the remote radiator fan, ventilating fans, coolant pumps and other accessories required for the set to run.




FIGURE 33. VENTILATION FOR A HEAT EXCHANGER COOLING SYSTEM

### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

**Example Ventilating Air flow Calculation:** The generator set Specification Sheet indicates that the heat radiated to the room from the generator set (engine and generator) is 4,100 BTU/min. The muffler and 10 feet of 5-inch diameter exhaust pipe are also located inside the generator room. Determine the airflow required to limit the air temperature rise to 30° F.

1. Add the heat inputs to the room from all sources. Table 11 indicates that the heat loss from 5-inch exhaust pipe is 132 BTU per m per foot of pipe and 2,500 BTU per m from the muffler. Add the heat inputs to the room as follows:

Heat from Generator Set .....	4,100
Heat from Exhaust Pipe-10 x 132.....	1,320
Heat from Muffler.....	<u>2,500</u>
<b>TOTAL HEAT TO GENERATOR ROOM (BTU/Min.).....</b>	<b>7,920</b>

2. The required airflow is proportional to the total heat input divided by the allowable room air temperature rise:

$$\text{Required Air Flow} = \frac{58 \times \text{Total Heat (Btu/min.)}}{\text{Temp. Rise } (\Delta \text{ } ^\circ\text{F})} = \frac{58 \times 7,920}{30} = 15,312 \text{ cfm}$$

TABLE 11. HEAT LOSSES FROM UNINSULATED EXHAUST PIPES AND MUFFLERS

PIPE DIAMETER INCHES (mm)	HEAT FROM PIPE BTU/MIN-FOOT (kJ/Min-Metre)	Heat From Muffler BTU/MIN (kJ/Min-Metre)
1.5 (38)	47 (162)	297 (313)
2 (51)	57 (197)	490 (525)
2.5 (64)	70 (242)	785 (828)
3 (76)	84 (291)	1,100 (1,160)
3.5 (98)	96 (332)	1,408 (1,485)
4 (102)	108 (374)	1,767 (1,864)
5 (127)	132 (457)	2,500 (2,638)
6 (152)	156 (540)	3,550 (3,745)
8 (203)	200 (692)	5,467 (5,768)
10 (254)	249 (862)	8,500 (8,968)
12 (305)	293 (1,014)	10,083 (10,638)

**GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



**GeneratorJoe**

## FUEL SUPPLY

### Diesel Fuel

The following should be considered when installing a diesel fuel supply system:

- Fuel supply tank construction, location, installation, venting, piping, testing and inspection must comply with applicable codes. See NFPA Standards No. 30 and No. 37.
- Fuel supply tanks must be adequately vented to prevent pressurization, have provisions for manually draining or pumping out water and sediment, and have at least a five percent expansion space to prevent fuel spillage when the fuel heats up and expands.
- The fuel lift pump, day tank transfer pump or float valve seat should be protected from fuel supply tank debris by a pre-filter or sediment bowl with a 100 to 120 mesh element.
- The supply tank must hold enough fuel to run the set for the prescribed number of hours (NFPA No. 110 Class designation) without refueling. Tank sizing calculations can be based on the hourly fuel consumption rates on the generator set Specification Sheet. Other considerations for tank sizing include the duration of expected power outages vs. availability of fuel deliveries and the “shelf life” of the fuel. The shelf life for diesel fuel is 1-1/2 to 2 years.
- For emergency power systems, codes might not permit the fuel supply to be used for any other purpose, or may specify a draw-down level for other equipment that guarantees the fuel supply for emergency power use.
- The Cetane rating of No. 2 heating oil is not high enough for dependable starting of diesel engines in cold weather. Therefore, separate supply tanks for emergency power and building heating systems might have to be provided.
- Approved flexible fuel hose must be used for connections at the engine to take up generator set movement and vibration.
- Diesel fuel lines should be black iron pipe. Cast iron and aluminum pipe and fittings must not be used because they are porous and can leak fuel. Galvanized fuel lines, fittings and tanks should not be used because the galvanized coating is attacked by the sulfuric acid that forms when the sulfur in the fuel combines with tank condensate, resulting in debris that can clog fuel pumps and filters. Although copper has been used for diesel fuel lines for many years, black iron pipe is preferred. Diesel fuel polymerizes (thickens) in copper tubing during long periods of standby, with the result that fuel injectors can clog.



### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

- The generator set Specification Sheet indicates the maximum fuel inlet and return restrictions, the maximum fuel flow and the fuel consumption. Table 12 indicates minimum hose and pipe sizes for connections to a supply tank or day tank that is relatively close to the set and at approximately the same elevation. Hose and pipe size should be based on the maximum fuel flow rather than on the fuel consumption. (The maximum fuel flow is approximately twice the full-load fuel consumption on **GeneratorJoe** generator sets rated 200/175 kW and larger.) It is highly recommended that the fuel Inlet and return restrictions be checked before the set is placed in service.

TABLE 12. MINIMUM FUEL SUPPLY HOSE AND PIPE SIZES

MAXIMUM GPH	FUEL SUPPLY LINE				FUEL RETURN LINE			
	0-10 FEET (0-3 METRES)		10-50 FEET (3-15 METRES)		0-10 FEET (0-3 METRES)		10-50 FEET (3-15 METRES)	
	FLEX HOSE SIZE	PIPE I.D. INCHES (MM)	FLEX HOSE SIZE	PIPE I.D. INCHES (MM)	FLEX HOSE SIZE	PIPE I.D. INCHES (MM)	FLEX HOSE SIZE	PIPE I.D. INCHES (MM)
0-15	NO. 6	5/16 (7.9)	NO. 6	13/32 (10.3)	NO. 4	3/16 (4.8)	NO. 6	5/16 (7.9)
15-20	NO. 8	13/32 (10.3)	NO. 8	1/2 (12.7)	NO. 4	3/16 (4.8)	NO. 6	5/16 (7.9)
20-80	NO. 10	1/2 (12.7)	NO. 10	5/8 (15.9)	NO. 8	13/32 (10.3)	NO. 10	1/2 (12.7)
80-100	NO. 12	5/8 (15.9)	NO. 16	7/8 (22.3)	NO. 8	13/32 (10.3)	NO. 10	1/2 (12.7)
100-160	NO. 16	7/8 (22.3)	NO. 16	7/8 (22.3)	NO. 10	1/2 (12.7)	NO. 12	5/8 (15.9)
160 >	NO. 16	7/8 (22.3)	NO. 16	7/8 (22.3)	NO. 12	5/8 (15.9)	NO. 12	5/8 (15.9)

Based on four straight fittings, two 90° fittings and minimal fuel lift height.

- Separate fuel return lines to the day tank or supply tank must be provided for each generator set in a multiple-set installation to prevent the return lines of idle sets from being pressurized. Also, a fuel return line must not include a shutoff device. Engine damage will occur if the engine is run when the line is shut off.
- A day tank is required whenever pipe friction and/or supply tank elevation, either below the fuel pump inlet or above the fuel injectors, would cause an excessive fuel inlet or return restriction. Some generator set models are available with an integral skid- mounted or sub-base day tank.

*For critical start applications, where generator sets are paralleled or must satisfy emergency start-time requirements, it is recommended that a fuel tank or reservoir be located such that the lowest possible fuel level is not less than 6 inches (150mm) above the fuel pump inlet. This will prevent air from accumulating in the fuel line while the set is in standby, eliminating the period during startup when it has to be purged.*

## GeneratorJoe

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

- Day tank fuel temperature might need to be considered in some high ambient applications when the warm fuel from the engine is returned to the day tank. Call the **GeneratorJoe** distributor concerning inlet fuel temperature limits for specific generator set models. As fuel temperature increases, fuel density and lubricity decrease, reducing maximum power output and lubrication of fuel handling parts such as pumps and injectors. One solution might be to pipe the fuel back to the supply tank rather than to the day tank.
- The day tank fuel transfer pump capacity and supply piping should be sized on the basis of the maximum fuel flow indicated on the generator set Specification Sheet.

## Gaseous Fuel

Figure 34 illustrates the typical gas line components in an automatic-transfer, dual-fuel system (natural gas and LPG). It is also representative of single fuel systems and the natural gas or LPG fuel components used when the alternate fuel is gasoline. When natural gas or LPG is used in combination with gasoline, the gas-air mixer is mounted on the air horn of the gasoline carburetor. Not shown is the LPG vaporizer supplied with **GeneratorJoe** generator sets equipped for liquid withdrawal of LPG (engine-mounted on outdoor sets only). The service pressure regulator(s), dry gas filter(s) and manual shutoff valve(s) are typically provided by the installer.

Natural gas generator sets are tested and rated using natural gas having a heating value of approximately 1,000 Btu/ft<sup>3</sup> (3724 MJ/m<sup>3</sup>). With proper fuel mixture adjustments (see the generator set Service Manual), fuel gases of lower heating value can be used with good results but with less maximum power output. Depending on the fuel, deratings will be necessary.

The following should be considered when installing a natural gas and/or LPG fuel system:

- Gaseous-fuel supply system design, materials, components, fabrication, assembly, installation, testing, inspection, operation and maintenance must comply with the applicable codes. See NFPA Standards No. 30, No. 37, No.54 and No. 58.
- The layout and sizing of the gas supply piping must be adequate for supplying the volume of gas required at full load as indicated on the generator set Specification Sheet while maintaining at least the minimum required supply pressure, typically 10 Inches (254 mm) WC (water column). See the example pipe sizing calculation below and associated pipe sizing tables (Tables 14 and 15). Final determination of pipe sizes must, however, be based upon the method approved by the authority having jurisdiction (see NFPA No. 54).
- Most installations will require a service gas pressure regulator. Typically gas supply pressure should not exceed 20 inches (508 mm) WC at the Inlet to the generator set. Depending on distribution gas pressure, more than one stage of pressure regulation may be required. High-pressure gas piping is not permitted inside buildings. Gas pressure regulators must be vented to the out-of-doors according to code.
- Approved flexible fuel hose must be used for connections at the engine to take up generator set movement and vibration. Some **GeneratorJoe** generator set models are equipped with flexible hoses that are connected to bulkhead fittings on the skid where solid pipe connections can be made by the installer.
- Most codes require both manual and electric (battery-powered) shutoff valves ahead of the flexible fuel hose(s). The manual valve should be of the indicating type.
- A dry fuel filter should be installed in each line as shown in Figure 34 to protect the sensitive pressure regulating components and orifices downstream from harmful foreign substances carried along in the gas stream (rust, scale, etc.).
- An LPG fuel supply system must be dedicated for the emergency power system if it is the required alternate fuel.



# GeneratorJoe






FIGURE 34. TYPICAL GASEOUS FUEL SYSTEM



# Generator Joe


- An LPG vaporizer heated by engine coolant is factory installed on **GeneratorJoe** generator sets equipped for a liquid-withdrawal of LPG. Because high pressure gas piping (liquid or vapor) is not permitted inside buildings, generator sets equipped for liquid withdrawal of LPG must not be installed inside the building. Weather protective housings for outdoor installation are available for most models.
- Ambient temperature affects the rate of vaporization in an LPG supply tank. In colder climates, a way to compensate for the reduced rate of vaporization is to install a larger supply tank. Table 13 can be used as a quick reference for sizing the propane tank to account for expected low ambient temperatures.
- The required rate of vaporization can also be obtained by means of a burner-type or engine coolant-type LPG vaporizer located just outside the building.

TABLE 13. MINIMUM PROPANE TANK SIZE IN GALLONS (LITERS) FOR REQUIRED VAPORIZATION

WITHDRAWAL RATE (Tank must be at least half full)	LOWEST AVERAGE WINTER TEMPERATURE					
	32°F (0°C)	20°F (-7°C)	10°F (-12°C)	0°F (-1°C)	-10°F (-23°C)	-20°F (-29°C)
100 cfh (3 m <sup>3</sup> /hr)	100 (378)	150 (568)	200 (757)	250 (946)	400 (1514)	650 (2461)
200 cfh (6 m <sup>3</sup> /hr)	250 (946)	300 (1136)	400 (1514)	600 (2271)	1000 (3785)	2000 (7571)
300 cfh (9 m <sup>3</sup> /hr)	400 (1514)	600 (2271)	700 (2650)	1100 (4164)	1800 (6814)	3600 (13,627)
400 cfh (11 m <sup>3</sup> /hr)	600 (2271)	900 (3407)	1200 (4542)	1700 (6435)	2700 (10,221)	4500 (17,034)
500 cfh (14 m <sup>3</sup> /hr)	900 (3407)	1300 (4921)	1600 (6057)	2500 (9464)	3600 (13,627)	7500 (28,931)
600 cfh (17 m <sup>3</sup> /hr)	1100 (4164)	1600 (6057)	2000 (7571)	3000 (11,356)	5000 (18,927)	10,000 (37,854)
700 cfh (20 m <sup>3</sup> /hr)	1500 (5678)	2000 (7571)	2500 (9464)	4000 (20,820)	6000 (22,712)	13,000 (49,210)

**Example Gas Pipe Sizing Calculations:** An application calls for two natural gas generator sets. The sets could be run concurrently. The full-load fuel consumption indicated on the generator set Specification Sheet for the model selected is 890 cfh (cubic feet per hour). The two sets will be supplied by a service pressure regulator adjusted to maintain 14 inches (356 mm) WC (water column). The service pressure regulator will not serve any other load. Figure 35 illustrates the gas piping arrangement.

FIGURE 35. GAS PIPING LAYOUT FOR A TWO-GENERATOR INSTALLATION



# GeneratorJoe

Determine minimum pipe sizes as follows:

1. Add up the length of pipe to the generator set farthest from the source, which is generator set B.  

$$\text{Total length of pipe for Set B} = 150 \text{ ft} + 40 \text{ ft} + 10 \text{ ft} = 200 \text{ ft}$$
2. The length of pipe to the farthest set will be the only length used when referring to Tables 14 and 15. In this case, refer to the 200 ft column in Table 14 (natural gas).
3. The 50 foot length of pipe serving generator set B alone, supplies 890 cfh of gas. This section will therefore have to be 2-1/2 inch pipe.
4. The 10 foot length of pipe serving generator set A alone, supplies 890 cfh of gas. This section will also have to be 2-1/2 inch pipe.
5. The 150 foot length of pipe serving both generator sets supplies 1780 cfh of gas. This section will therefore have to be 3 inch pipe.
6. When piping is sized on this basis, the pressure loss should not be more than 0.5 inches (13 mm) WC.

*This procedure can be used when other types of equipment, such as the building heating boilers, are also supplied by the service pressure regulator supplying the generator sets. Note that Tables 14 and 15 cover gas supply pressures not greater than 1/2 psig. See NFPA 54 for gas pipe capacity tables for higher gas supply pressures (1, 5, 10, 20 and 50 psig).*

TABLE 14. NATURAL GAS PIPE CAPACITY—CUBIC FEET OF GAS PER HOUR

NOMINAL IRON PIPE SIZE (INCHES)	LENGTH OF PIPE IN FEET													
	10	20	30	40	50	60	70	80	90	100	125	150	175	200
3/4	360	250	200	170	151	138	125	118	110	103	93	84	77	72
1	680	465	375	320	285	260	240	220	205	195	175	160	145	135
1-1/4	1400	950	770	660	580	530	490	460	430	400	360	325	300	280
1-1/2	2100	1460	1180	990	900	810	750	690	650	620	550	500	460	430
2	3950	2750	2200	1900	1680	1520	1400	1300	1220	1150	1020	950	850	800
2-1/2	6300	4350	3520	3000	2650	2400	2250	2050	1950	1850	1650	1500	1370	1280
3	11000	7700	6250	5300	4750	4300	3900	3700	3450	3250	2950	2650	2450	2280

Based on 0.5 inch (13 mm) WC pressure drop, 0.60 specific gravity gas and nominal 1/2 psig (3.4 kPa) pressure

TABLE 15. LPG GAS PIPE CAPACITY—CUBIC FEET OF GAS PER HOUR

NOMINAL IRON PIPE SIZE (INCHES)	LENGTH OF PIPE IN FEET											
	10	20	30	40	50	60	70	80	90	100	125	150
3/4	227	157	126	107	95	87	78	74	69	65	58	53
1	428	293	236	201	179	164	151	138	129	123	110	101
1-1/4	882	598	485	416	365	333	308	289	207	252	230	204
1-1/2	1323	920	743	624	567	570	472	434	409	390	346	315
2	2488	1732	1386	1197	1058	958	882	819	768	724	642	598

Based on 0.5 inch (13 mm) WC pressure drop and nominal 11 inch (280mm) WC pressure at inlet



# Generator Joe

# Electrical Installation

## ENGINE STARTING SYSTEMS


### Battery Starting Systems

- Battery starting systems for generator sets are usually 12 volt or 24 volt. Figure 36 illustrates typical battery-starter connections. Consider the following:
- Batteries must have enough capacity to provide the cranking motor current indicated on the generator set Specification Sheet. The batteries may be either lead-acid or nickel-cadmium. They must be designated for this use and may have to be approved by the authority having jurisdiction.
- A high output engine-driven alternator and automatic voltage regulator are provided to recharge the batteries during operation.
- For emergency power systems, a float-type battery charger, powered by the normal power source, must be provided to keep the batteries fully charged during standby.
- Codes usually specify a maximum battery charging time. The following rule-of-thumb can be used to size battery chargers:

$$\text{Required Battery Charging Amps} = \frac{1.2 \times \text{Battery Amp-Hours}}{\text{Charging Hours}}$$

- Local codes may require battery heaters to maintain a minimum battery temperature of 50° F (10° C) if the set is subject to freezing temperatures.
- Standard sets include skid mounted battery racks and battery cables.
- Battery cable resistance must not result in a voltage drop between the battery and the starter motor of more than 1 volt for 12 volt systems or more than 2 volts for 24 volt systems. See the following example calculation.

FIGURE 36. TYPICAL ELECTRIC STARTER MOTOR CONNECTIONS



**Example Calculation:** A generator set has a 24 VDC starting system to be powered by two 12 volt batteries connected in series (Figure 36). Total cable length is 375 inches, including the cable between the batteries. There are six cable connections. The generator set Specification Sheet indicates that cranking motor current is 565 amps. Calculate the required cable size as follows:


1. Assume a resistance of 0.0002 ohms for the starter solenoid contact.
2. Assume a resistance of 0.00001 ohms for each cable connection (six).
3. Based on the formula that:

$$R \text{ (ohms)} = \frac{E \text{ (volts)}}{L \text{ (amperes)}}$$

$$\begin{aligned} \text{Allowable Cable Resistance} &= \frac{\text{Allowable Voltage Drop}}{\text{Cranking Amps}} - \text{Sum of Other Resistance} \\ &= \frac{2}{565} - (0.0002 + (6 \times 0.00001)) = 0.00328 \text{ ohms} \end{aligned}$$

4. Refer to Figure 37 for AWG (American Wire Gauge) cable resistances. In this example, as shown by the dashed lines, #0 AWG is the smallest cable size that can be used.

FIGURE 37. RESISTANCE vs. LENGTH FOR VARIOUS AWG CABLE SIZES





## Air Starting Systems

Figure 38 shows a piping arrangement for a typical air starter. The following items should be considered when installing an air starter system:

- The engine manufacturer should be consulted for recommendations regarding air hose size and the minimum tank volume required for each second of cranking. Tank size will depend on the minimum cranking time required. All of the starters available from **GeneratorJoe** have a maximum pressure rating of 150 psig (1035 kPa).
- Air tanks (receivers) should be fitted with a drain valve of the screw-out, tapered-seat type (other types are unreliable and a common source of air leaks). Moisture can damage starter components.
- All valves and accessories in the system should be designed for diesel air starting service.
- Pipe fittings should be of the dry seal type and should be made up with thread sealant Teflon tape is not recommended as it does not prevent thread loosening and can be a source of debris that can clog valves.




FIGURE 38. TYPICAL PIPING ARRANGEMENT FOR AN AIR STARTER

# GeneratorJoe

## ELECTRICAL CONNECTIONS

### General

Installation of electrical wiring should follow the requirements of the applicable electrical code and be done by qualified persons.


### AC Power Conductors

If the generator set is not factory-supplied with a main-line circuit breaker, the ampacity of the field-installed AC phase conductors from the generator output terminals to the first over-current device should be at least equal to 115 percent of the generator full-load current. See Table 16 and Schematics (a) and (b) in Figure 39. The length of run for generator tap conductors to the first overcurrent device should be kept as short as possible (generally not more than 25 feet).

*If the generator is supplied with leads, the size of the leads may be smaller than required for field-installed conductors because generator leads have type CCXL insulation rated 125° C.*

If the generator set is factory-equipped with a main-line circuit breaker, the ampacity of the field-installed AC phase conductors connected to the load terminals of the circuit breaker should be equal to or greater than the circuit breaker rating. See Schematic (c) in Figure 39.

FIGURE 39. FEEDER AMPACITY



# Generator Joe

The ampacity of the neutral conductor is generally permitted to be equal to or greater than the calculated maximum single-phase unbalance of the load. Where a significant portion of the load is non-linear, the neutral should be full size.

The generator neutral supplied by **GeneratorJoe** is equal in ampacity to the phase conductors.

Flexible metal conduit and stranded conductors must be used for connections to the generator set to take up generator set movement and vibration. The flexible conduit should be at least 18 inches (460 mm) long.

Medium voltage cable must be installed and terminated exactly as recommended by the cable manufacturer, by persons who have learned the procedures through training and practice under close supervision.

**TABLE 16. THREE-PHASE AC GENERATOR AMPERAGE AT 80 % POWER FACTOR**

KW	KVA	208V	220V	240V	380V	440V	480V	600V	2400V	3300V	4160V
20	25	69	66	60	38	33	30	24	-	-	-
35	44	122	115	105	67	57	53	42	-	-	-
40	50	139	131	120	76	66	60	48	-	-	-
45	56	156	148	135	86	74	68	54	-	-	-
50	63	174	164	151	95	82	75	60	-	-	-
60	75	208	197	181	114	99	90	72	-	-	-
65	81	226	213	196	124	107	98	78	-	-	-
70	88	243	230	211	133	115	105	84	-	-	-
75	94	261	246	226	143	123	113	90	-	-	-
80	100	278	263	241	152	131	120	96	-	-	-
100	125	347	328	301	190	164	151	120	-	-	-
125	156	434	411	376	238	205	188	151	-	-	-
150	188	521	493	452	285	246	226	181	-	-	-
175	219	608	575	527	333	287	263	211	-	-	-
200	250	695	657	602	380	328	301	241	-	-	-
230	288	799	755	692	437	378	346	277	-	-	-
250	313	868	821	753	475	411	376	301	-	-	-
275	344	955	903	828	523	452	414	331	-	-	-
300	375	1042	985	903	570	493	452	361	-	-	-
350	438	1216	1150	1054	666	575	527	421	-	-	-
400	400	1390	1314	1204	761	657	602	482	-	-	-
450	563	1563	1478	1355	856	739	677	542	-	-	-
500	625	1737	1642	1505	951	821	753	602	151	109	87
600	750	2084	1971	1806	1141	985	903	723	181	131	104
750	938	2605	2463	2258	1426	1232	1129	903	226	164	130
800	1000	2779	2627	2408	1521	1314	1204	963	241	175	139
900	1125	3126	2956	2710	1711	1478	1355	1084	271	197	156
1000	1250	3474	3283	3011	1901	1642	1505	1204	301	219	174
1100	1375	-	-	-	2092	1806	1656	1325	331	241	191
1200	1500	-	-	-	2282	1971	1806	1445	361	263	208
1250	1563	-	-	-	2377	2053	1882	1505	376	274	217
1500	1875	-	-	-	2852	2463	2258	1806	452	328	261



# GeneratorJoe

## Electrical Connections

Several electrical connections must be made between the generator set and other components of the system for proper operation. Because of the large number of accessories and possible combinations, this manual does not address specific applications. Refer to the submittal catalog accessory drawings and wiring diagrams for connection and location. Most field-installed accessory kits include installation instructions.

For customer-supplied wiring, select the wire temp. rating in chart below based on the following criteria:

- Select row 1, 2, 3, or 4 if the circuit rating is 110 amperes or less or requires #1 AWG (42.4 mm<sup>2</sup>) or smaller conductors.
- Select row 3 or 4 if the circuit rating is greater than 110 amperes or requires #1 AWG (42.4 mm<sup>2</sup>) or larger conductors.

Comply with applicable national and local codes when installing a wiring system.

Row	Temp. Rating	Copper (Cu) Only	Cu/Aluminum (Al) Combinations	Al Only
1	60°C (140°F) or 75°C (167°F)	Use No. * AWG, 60°C wire or use No. * AWG, 75°C wire	Use 60°C wire, either No. * AWG Cu, or No. * AWG Al or use 75°C wire, either No. * AWG Cu or No. * AWG Al	Use 60°C wire, No. * AWG or use 75°C wire, No. * AWG
2	60°C (140°F)	Use No. * AWG, 60°C wire	Use 60°C wire, either No. * AWG Cu or No. * AWG Al	Use 60°C wire, No. * AWG
3	75°C (167°F)	Use No. *† AWG, 75°C wire	Use 75°C wire, either No. *† AWG Cu or No. *† AWG Al	Use 75°C wire, No.*† AWG
4	90°C (194°F)	Use No. *† AWG, 90°C wire	Use 90°C wire, either No. *† AWG Cu or No. *† AWG Al	Use 90°C wire, No.*† AWG

\* The wire size for 60°C (140°F) wire is not required to be included in the marking. If included, the wire size is based on ampacities for the wire given in Table 310-16 of the National Electrical Code®, in ANSI/NFPA 70, and on 115% of the maximum current that the circuit carries under rated conditions. The National Electrical Code® is a registered trademark of the National Fire Protection Association, Inc.


† Use the larger of the following conductors: the same size conductor as that used for the temperature test or one selected using the guidelines in the preceding footnote.

Terminal Markings for Various Temperature Ratings and Conductors

## Load Lead Connections

Load leads being brought into the generator can enter in a number of different areas.

The most common entry point is to stub up below the main line circuit breaker enclosure. In some other cases it may be necessary to enter the main line circuit breaker box from the top or side using flexible conduit. In either case it is best to contact the factory to get an as built dimensional drawing of your generator set for more detailed information.



Typical Load Lead Connection



# Generator Joe

## Terminal Connector Torque

Use the torque values shown in the chart below for terminal connectors. Refer to UL-486A, UL-486B, and UL-486E for information on terminal connectors for aluminum and/or copper conductors. See previous chart on Electrical Connections, for information on the temperature rating of customer-supplied wire. Comply

with applicable national and local codes when installing a wiring system.

**Note:** If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values provided in the chart below.

Wire Size for Unit Connection AWG, kcmil (mm <sup>2</sup> )	Tightening Torque, Nm (in. lb.)			
	Slot Head 4.7 mm (No. 10) or Larger*		Hexagonal Head—External Drive Socket Wrench	
	Slot Width <1.2 mm (0.047 in.) Slot Length <6.4 mm (0.25 in.)	Slot Width >1.2 mm (0.047 in.) Slot Length >6.4 mm (0.25 in.)	Split-Bolt Connectors	Other Connections
18-10 (0.82-5.3)	2.3 (20)	4.0 (35)	9.0 (80)	8.5 (75)
8 (8.4)	2.8 (25)	4.5 (40)	9.0 (80)	8.5 (75)
6-4 (13.3-21.2)	4.0 (35)	5.1 (45)	18.6 (165)	12.4 (110)
3 (26.7)	4.0 (35)	5.6 (50)	31.1 (275)	16.9 (150)
2 (33.6)	4.5 (40)	5.6 (50)	31.1 (275)	16.9 (150)
1 (42.4)	—	5.6 (50)	31.1 (275)	16.9 (150)
1/0-2/0 (53.5-67.4)	—	5.6 (50)	43.5 (385)	20.3 (180)
3/0-4/0 (85.0-107.2)	—	5.6 (50)	56.5 (500)	28.2 (250)
250-350 (127-177)	—	5.6 (50)	73.4 (650)	36.7 (325)
400 (203)	—	5.6 (50)	93.2 (825)	36.7 (325)
500 (253)	—	5.6 (50)	93.2 (825)	42.4 (375)
600-750 (304-380)	—	5.6 (50)	113.0 (1000)	42.4 (375)
800-1000 (406-508)	—	5.6 (50)	124.3 (1100)	56.5 (500)
1250-2000 (635-1016)	—	—	124.3 (1100)	67.8 (600)

\* For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.

**Note:** If a connector has a clamp screw such as a slotted, hexagonal head screw with more than one means of tightening, test the connector using both applicable torque values.

Tightening Torque for Screw-Type Pressure Wire Connectors

Socket Size Across Flats, mm (in.)	Tightening Torque, Nm (in. lb.)
3.2 (1/8)	5.1 (45)
4.0 (5/32)	11.4 (100)
4.8 (3/16)	13.8 (120)
5.6 (7/32)	17.0 (150)
6.4 (1/4)	22.6 (200)
7.9 (5/16)	31.1 (275)
9.5 (3/8)	42.4 (375)
12.7 (1/2)	56.5 (500)
14.3 (9/16)	67.8 (600)

**Note:** For values of slot width or length not corresponding to those specified, select the largest torque value associated with the conductor size. Slot width is the nominal design value. Slot length is to be measured at the bottom of the slot.

Tightening Torque for Pressure Wire Connectors with Internal-Drive Socket-Head Screws



**GeneratorJoe**  
4723 Muirfield Court  
Santa Rosa, CA 95405  
**Phone: 707-539-9003**  
Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)  
Web: [www.generatorjoe.net](http://www.generatorjoe.net)

# GeneratorJoe



## Grounding

**System Grounding:** As shipped, the neutral terminal of a **GeneratorJoe** generator is not grounded. If the generator is a separately-derived power source (i.e. 4-pole transfer switch) then the neutral will have to be connected to a grounding electrode system by the installing electrician.

If the generator neutral interconnects with a service-supplied grounded neutral, typically at the neutral block of a 3-pole transfer switch, then the generator neutral should not be grounded at the generator. The electrical code may require a sign to be placed at the service supply indicating that the generator neutral is grounded at that location.

**Equipment Grounding:** A grounding terminal is provided on the skid of the generator set. If a set-mounted circuit breaker is provided, a grounding terminal may be provided inside the circuit breaker enclosure. The electrical code may require a grounding conductor so that the section of flexible conduit (required because of vibration) is not relied on as a means for equipment grounding.

## Control Wiring

AC and DC control wiring (to the transfer switch and remote annunciators) must be run in separate conduit from the power cables. Stranded conductors and a section of flexible conduit must be used for connections at the set.

## Accessory Branch Circuits

Branch circuits must be provided for all accessory equipment necessary for operation of the generator set. These circuits must be fed either from the load terminals of an automatic transfer switch or from the generator terminals. Examples of accessories include the fuel transfer pump, coolant pumps for remote radiators, and motorized louvers for ventilation.

Branch circuits, fed from the normal power panel board, must be provided for the battery charger and coolant heaters, if used. See Figure 40.



**GeneratorJoe**  
4723 Muirfield Court  
Santa Rosa, CA 95405  
**Phone: 707-539-9003**  
Fax: 707 539-5212  
Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)  
Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe




FIGURE 40. TYPICAL GENERATOR SET CONTROL AND ACCESSORY WIRING



# Generator Joe

## Allowable Single-Phase Load Unbalance

Single-phase loads should be distributed as evenly as possible between the three phases of a three-phase generator set in order to fully utilize the rated capacity (kVA and kW) of the set and to limit voltage unbalance. Figure 41 can be used to determine the maximum permissible percentage of unbalanced single-phase load, as illustrated by the example calculation.

Single phase power can be taken up to 67 percent of the three-phase rating on **GeneratorJoe** generator sets not larger than 175 kW. (Note that this will result in line currents for Y-connected generators that will exceed nameplate ratings by approximately 15 percent.)

Generally, the larger the generator set, the lower the percentage of single-phase power that can be taken. Figure 41 includes single-phase percentage lines for **GeneratorJoe** intermediate- size Frame-4 and Frame-5 generators. Confirm the frame size by referring to the applicable Alternator Data Sheet referenced by the generator set Specification Sheet. For generator sets rated more than 500kW, load unbalance should not exceed 10 percent.

**Example Calculation:** Find the maximum single-phase load that can be powered in conjunction with a total three-phase load of 62 kVA by a generator set rated 100kW /125 kVA.

1. Find the three-phase load as a percentage of the generator kVA rating:

$$\text{Three Phase Load Percentage} = \frac{62 \text{ kVA}}{125 \text{ kVA}} \times 100\% = 50\%$$

2. Find the percentage of allowable single-phase load, as shown by the arrows in Figure 41. In this case, it is approximately 34 percent of the three-phase rating.
3. Find the maximum single-phase load:

$$\text{Maximum Single Phase Load} = \frac{125 \text{ kVA} \times 34\%}{100\%} = 42.5 \text{ kVA}$$

4. Note, as follows, that the sum of the three-phase and maximum permissible single- phase loads is less than the kVA rating of the generator set:

$$62 \text{ kVA (3 Phase Load)} + 42.5 \text{ kVA (1 Phase Load)} = 104.5 \text{ kVA}$$

and

$$104.5 \text{ kVA} < 125 \text{ kVA (Rating of the Generator Set)}$$

*Unbalanced loading of a generator set causes unbalanced phase voltages. The levels of load unbalance anticipated by these guidelines should not result in harm to the generator set itself. The corresponding levels of voltage unbalance, however, may not be acceptable for loads such as three-phase motors.*

*Because of unbalanced phase voltages, critical loads should be connected to the phase, which the voltage regulator uses as the reference voltage (L1 –L2 as defined in the generator set schematic) when only one phase is used as a reference. (All three phases are used for voltage reference on **GeneratorJoe** PMG-excited generators) with 3 phase sensing option.*

### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe




FIGURE 41. ALLOWABLE UNBALANCED SINGLE-PHASE LOAD



# Generator Joe

## OPERATION

### **WARNING! BE SURE PROPER START UP HAS BEEN PERFORMED ON YOUR GENERATORJOE GENERATOR SET BEFORE ATTEMPTING TO OPERATE THE UNIT ON YOUR OWN.**

If proper start up has taken place, then the following events have already occurred.

- 1) The start up technician has reviewed the installation and has tested the unit by applying the load and making sure all generator installation requirements have been met.
- 2) The start up technician has reviewed the overall requirements for the **SAFE** operation of the unit with the personnel assigned to the daily inspection and operation of the unit.
- 3) The warranty forms and documentation are being processed and the unit is ready for operation.

The following should occur before any witnessed start of the unit.

- 1) Check fluid levels such as radiator water level, engine oil level, fuel level and battery fluid level. Correct any that may appear either too high or too low. Refer to the engine manufacturers guide for assistance in determining these proper levels.
- 2) Inspect the unit for any noticeable loose connections or leaks. Refer to the applicable manual for remedy of the problem or call **GeneratorJoe** service department for assistance.

The unit has a manual position that will start the unit as soon as the switch is placed in the manual position. There will be a slight time delay through the control module and then the starter will engage and crank the engine over. If everything is in proper running condition the engine will accelerate to rated no load speed and run until the switch is returned to the 'OFF' position or the 'AUTO' position. The unit will not start in the 'AUTO' position unless the automatic transfer switch is requiring it to start. If the unit starts when the control switch is placed in the 'AUTO' position then it means that the utility is no longer supplying the transfer switch. This is an unusual occurrence and therefore will not likely happen on testing the unit. The unit, once running, will operate at rated speed, which is generally 1800 RPM plus the droop setting if the unit load is not applied. Initial readings on oil pressure and water temperature should be monitored to make sure they appear to be working properly. Also, monitor the frequency and voltage on the AC meters to verify that the generator is producing voltage at the proper level. If any of the observations appear abnormal according to the respective operator guides, then make note of the apparent discrepancy and turn the unit to the 'OFF' position. Tag the unit as out of service and call **GeneratorJoe** service department for assistance.

If the unit is operating satisfactorily, then you may apply the load if you wish in your normal prescribed method. Some units may have a manual means of applying the load and some may have an automatic transfer switch which may have a with or without load test Selector switch. The start up technician will have set the automatic exercise clock if the unit was purchased with one. This feature starts the generator set and applies the load once a month or sometimes once a week depending on the type of transfer switch ordered.

If the transfer switch has the test with load feature, witness of this test should be done periodically to verify the exercise period is occurring and keeping the unit battery charged up. Some units may also have a battery charger hooked up which is powered by the utility system to assist in maintaining the battery in a properly charged condition. A battery charger is recommended in automatic standby operation of a **GeneratorJoe** generator set. Always replace the control switch back in the automatic position when completing an inspection of the unit so that the automatic transfer switch can start the unit if a utility power failure occurs. When an inspection of the unit detects any unusual meter readings, noises or vibrations notify an authorized **GeneratorJoe** Dealer to correct the problem.

For further information regarding the Generator Set Control Panel refer to the Generator Set Controller Instruction Manual.



# GeneratorJoe



# **Maintenance and Service**

---

## **GENERAL**

A well-planned program of preventive maintenance and service should be integral to the design of an on-site power system. Failure of a standby generator set to start and run could lead to loss of life, personal injury, property damage and loss of business income. Failure to start and run due to low battery charge because of careless maintenance is the most common type of failure. A comprehensive program carried out on a scheduled basis by qualified persons can prevent such failures and their possible consequences. The maintenance and service programs most generator set distributors offer on a contract basis should be considered. Typically, they include performance of scheduled maintenance, repairs, parts replacement and service documentation.

## **SCHEDULED MAINTENANCE**

The maintenance schedule for prime power sets should be on the basis of running time, as published by the manufacturer. Since standby sets run infrequently, the maintenance schedule is usually in terms of daily, weekly, monthly, semi-annual and annual tasks. See the manufacturer's instructions for details; but scheduled maintenance should include at least:

### **Daily**

- Checking for oil, coolant and fuel leaks.
- Checking operation of the engine coolant heater(s). If the block is not warm, the heaters are not working and the engine might not start.
- Checking to see that the switchgear is in the AUTOMATIC position.

### **Weekly**

- Checking engine oil and coolant levels.
- Checking the battery charging system.

### **Monthly**

- Checking for air cleaner restrictions.
- Exercising the generator set by starting it and running it for at least 30 minutes under not less than one-half rated load and checking for unusual vibrations, noises and exhaust, coolant and fuel leaks while the set is running. (Regular exercising keeps engine parts lubricated, improves starting reliability, prevents oxidation of electrical contacts and consumes fuel before it deteriorates and has to be disposed of.)
- Checking for radiator restrictions, coolant leaks, deteriorating hoses, loose and deteriorating fan belts, non-functioning motorized-louvers and concentration of engine coolant conditioner.
- Checking for holes, leaks and loose connections in the air cleaner.
- Checking fuel level and fuel transfer pump operation.
- Checking for exhaust system leaks and restrictions and draining the condensate trap.
- Checking all meters, gauges and Indicator lamps for proper operation.
- Checking the battery cable connections and recharging the batteries if specific gravity is less than 1.260.
- Checking for ventilation restrictions in the inlet and outlet openings of the generator.
- Checking that all required service tools are readily available.

### **Semi-Annually**

- Changing engine oil and the full-flow and the by-pass oil filters.
- Changing the filter(s) in the coolant conditioner circuit
- Cleaning or replacing the crankcase breather filter(s).
- Changing the fuel filter(s), draining sediment from fuel tanks, checking flexible fuel hoses for cuts and abrasions and checking the governor linkage.

- Checking electrical safety controls and alarms.
- Cleaning up accumulations of grease, oil and dirt on the set.
- Checking power distribution wiring, connections, circuit breakers and transfer switches.
- Simulating a utility power outage. This should test the ability of the set to start and assume rated load and check operation of the automatic transfer switches, related switchgear and controls and all other components in the standby power system.

## Annually

- Checking the fan hub, pulleys and water pump.
- Changing the day tank breather.
- Tightening the exhaust manifold and turbocharger capscrews.
- Tightening the set mounting hardware.
- Cleaning the generator power output and control boxes, checking for and tightening all loose wiring connectors, measuring and recording generator winding Insulation resistances, checking operation of the generator heater strips and greasing bearings.
- Checking operation of the main generator circuit breaker (if used) by manually operating it and testing the trip unit according to the manufacturer's instructions.
- Running the set for at least three hours, with one hour at near rated load, if the set is normally exercised at no-load or carries only light loads.
- Generator Insulation tests should be conducted annually throughout the life of a generator set. The initial tests should be done before final load connections are made to serve as benchmarks for the annual tests. These tests are mandatory for medium voltage generator sets. ANSI/IEEE Standard 43, *Recommended Practice for Testing Insulation Resistance of Rotating Machinery* should be referenced.



## **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe

## TROUBLESHOOTING

What are some of the most often found reasons for a failure of a generator set to start? Below is a list of some of the areas overlooked when maintaining a generator set.

1. **Battery Cables!** A battery cable often looks as if it is in good condition but in fact may be the cause of a non-start of the generator set. Corrosion often starts on the inside of the cable insulation and is not visible from the outside without testing the resistance value from one end to the other. Battery cable checks are listed in most operator guides and in order to keep the units running properly the cables must be kept clean and free from corrosion.
2. **Bad Fuel!** Fuel systems are the second highest cause for failure to start or fail during an outage without being able to supply power for the full period of the outage. The major factor is usually algae or water in the fuel tank, which develops from not exchanging the fuel regularly or not adding algae or water preventive additives to prevent this contamination. There are test substances, which allow testing of the tank to see if water is present and this should be performed quarterly.
3. **Corrosion!** Electrical connections are subject to corrosion even though **GeneratorJoe** units are treated at the factory to help prevent corrosion from occurring. Check terminal connections periodically.
4. **Operator adjustments-** Often times there is a problem with personnel adjusting units without checking the proper method in the operator guides which lead to an unsuccessful start attempt and damage to property or worse injury or death to personnel. **DO NOT** adjust the generator set controls without the proper training in performance of the work.
5. **Rodent/pest contamination-** Insulation on electrical wires is often a treat for rodents which can lead to a failure to start of the generator set. Another problem is rodent or pest nesting which can lead to plugging of the air cleaner or radiator (cap left off!). Inspect the unit carefully for rodent or pest contamination.
6. **Improperly maintained coolant heater-** The coolant heater is an integral part of an automatic starting system and is often overlooked when checking out a unit. Generally this occurs because the unit is turned off in the summer time and is merely left off after winter comes. The diesel unit will not start properly when the coolant heater is turned off and the air temperature falls below 80 degrees Fahrenheit.
7. **Dead battery-** This is the most unfortunate reason for a failure to start and can be prevented if proper maintenance is performed on a scheduled basis.

Other troubleshooting is provided in each of the operator guides supplied with the unit and should be reviewed for other problem solving



### **GeneratorJoe**

4723 Muirfield Court  
Santa Rosa, CA 95405

**Phone: 707-539-9003**

Fax: 707 539-5212

Email: [sales@generatorjoe.NET](mailto:sales@generatorjoe.NET)

Web: [www.generatorjoe.net](http://www.generatorjoe.net)



# GeneratorJoe



# GeneratorJoe

## GeneratorJoe Generator Sets

**GeneratorJoe MANUFACTURER'S LIMITED WARRANTY** extends to the original purchaser of goods for use, the following warranty covering goods manufactured or supplied by **GeneratorJoe**, subject to the qualifications indicated in this document.

There is no other express warranty. This document covers warranties on products only and any other matters concerning sales or rentals of equipment or products supplied by **GeneratorJoe** shall be governed by **GeneratorJoe's** policies as posted on [www.generatorjoe.net](http://www.generatorjoe.net), which is subject to change without notice at any time.

Implied warranties including merchantability and fitness for a particular purpose, are limited to periods of warranty set forth below and to the extent permitted by law, any and all implied warranties are excluded.

In no event is **GeneratorJoe** liable for incidental or consequential damages.

NOTE: Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply in every instance.

1. **GeneratorJoe** warrants to original purchaser for the period set forth below that goods manufactured or supplied by it will be free from defects in workmanship and material, provided such goods are installed, operated, and maintained in accordance with **GeneratorJoe's** instructions, and further provided, that installation inspection and initial start-up on commercial-Industrial generator sets or installations are conducted by a **GeneratorJoe's** authorized distributor or its designated service representative.

### Warranty Periods

a) **Emergency or Standby Duty**

Standby generators must be permanently installed, properly enclosed and ventilated, or mobile application and used as back up to the normal power source.

The warranty period is 60 months from the date of installation by the first owner/user, or 60 months after date of shipment by **GeneratorJoe** whichever is shorter, or 5000 hours of operation, limited to a maximum of 1000 hours per year, for 5 years, whichever is shorter.

b) **Continuous or Prime Duty**

Continuous or prime power service describes operation in a permanent or mobile application where no other source of power is generally available. Rental sets, and specific products for irrigation and refrigeration meet this criteria. Cogeneration and peak shaving installations are considered prime power.

The warranty period is 12 months from date of start-up by the first owner/user, or 18 months after date of shipment by **GeneratorJoe** or 3000 hours of operation.

To be covered by this warranty your purchase must be registered within (30) days of initial Start-up, warranty registration form to be provided and completed by seller.

2. **GeneratorJoe's** liability and purchaser's sole remedy for a failure of goods under this warranty and for any and all other claims arising out of the purchase and use of goods, including negligence on the part of the manufacturer, shall be limited to the repair of the product by the repair or replacement, at **GeneratorJoe's** option, of parts that do not conform to this warranty, provided that the

product or parts are returned as requested to **GeneratorJoe's** factory as shown on the **GeneratorJoe** website or to a GeneratorJoe's authorized distributor or its designated service representative, transportation pre-paid. For generators that have been permanently mounted, travel shall be allowed up to a maximum of 300 miles round trip and a maximum of 7 hours travel time. In the event warranty repairs are not performed by a **GeneratorJoe** authorized distributor or its designated service representative, said warranty repair claim will be administered through **GeneratorJoe's** Warranty Department and claimant will be reimbursed labor expenses at the rate of thirty (30) U.S. dollars per hour for the time allowed for applicable repair or for the actual labor expense, whichever is less. Parts will be reimbursed at **GeneratorJoe's** current list price, less the applicable discount from the parts depot in the local geographic area, plus 5% for handling. **GeneratorJoe** will provide replacement parts to claimant's location within the continental United States. If claimant is located outside the continental United States, all parts shipments are f.o.b. point of debarkation. In the event warranty repairs are affected outside the boundaries of the United States of America, **GeneratorJoe** is not responsible for any duties, taxes, or associated charges as may be applicable in accordance with the regulations of the country where such warranty repair is performed.

3. All claims must be brought to the attention of **GeneratorJoe** or an authorized distributor or its designated service representative within thirty (30) days after the discovery that goods or parts fail to meet this warranty.
4. Engine manufacturers warranty  
The engine manufacturer issues its own separate warranty covering the engines performance and parts. In the event of an engine related failure, **GeneratorJoe** can refer you to an engine authorized service center.
5. This warranty does not apply to:
  - a. Cost of maintenance, adjustments, installation and start-up.
  - b. Failures due to accident, misuse, abuse, negligence or improper replacement.
  - c. Damage due to faulty repairs not performed by an authorized service representative.
  - d. Products which are altered or modified in a manner not authorized by manufacturer in writing.
  - e. Failure of goods caused by defects in the system or application in which the goods are installed.
  - f. Failure caused by operations at speeds, load or conditions contrary to published specifications or recommendations.
  - g. Negligent maintenance such as:
    - 1). Failure to perform scheduled maintenance.
    - 2). Failure to provide sufficient lubricating oil.
    - 3.) Failure to provide sufficient cooling.
    - 4.) Failure to keep air intake and cooling fins clean.
    - 5.) Failure to properly service air cleaner.
    - 6.) Use of other than factory supplied or approved, repair parts and/or procedures.
  - h. Telephone, Telegraph, Teletype or other communication expenses.
  - i. Living and travel expenses of person performing service.
  - j. Rental equipment used while warranty repairs are being performed.
  - k. Overtime labor.
  - l. Batteries (Batteries are warranted by the battery manufacturer).
  - m. Starters and battery charging alternators (Warranted by Component Manufacturer).
  - n. Consumable items including, but not restricted to:
    - 1). Engine oil
    - 2). Grease and lubricants
    - 3). Fuel
    - 4). Filters and filter elements
    - 5). Injector nozzles
    - 6). Glow plugs
    - 7). Cleaning materials
    - 8). Belts
    - 9). Light bulbs and fuses
    - 10). Antifreeze coolant

No person is authorized to give any other warranties or to assure any other liabilities on **GeneratorJoe's** behalf, unless made or assumed in writing by an officer of **GeneratorJoe**, and no person is authorized to give any warranties or assume any other liability on behalf of seller unless made or assumed in writing by seller.

6. This warranty gives the user specific rights, and the user may also have other rights which vary from state to state.
7. Check component manufacturer's warranties to determine if their coverage exceeds **GeneratorJoe's** warranty coverage.