

# Connectivity to the ASCO® Power Manager Xp & 7000 Series Group 5 Controller via Modbus®

---

This design specification describes the *Modbus* communications protocol as supported by the *ASCO Power Manager Xp* and 7000 Series Group 5 Controller. It includes instructions on how to pass information into and out of the either device via the Modbus network. This publication should be used by individuals wishing to integrate either device into their facility by developing software to communicate with either device. Additional information can be found in *Power Manager Xp Operator's Manual 381333-199* and *Group 5 Controller User's Guide 381333-126*.

## Modbus Protocol

### Implementation Basics

The following rules define the Modbus slave implementation of the devices:

- The devices operate as slaves only (communication must be initiated by the master).
- The maximum number of bytes contained within one packet of communications is 64.

### Transmission Format

Although the Modbus protocol supports both ASCII and RTU modes of transmission, only the RTU mode is implemented. Within the RTU mode, the ASCO devices support the following communication parameters:

- 8 data bits
- no parity
- 1 stop bit

### Modbus RTU Packet Format

Every Modbus Packet consists of the following fields:

- Device Address Field
- Function Code Field
- Data Field
- Error Check Field

**Device Address Field.** This is the first byte of each Modbus RTU transmission. The device address is a number limited to the range of 0 - 247 and is associated with a single device configured with a matching address. Only the slave device whose address matches the value in this field will respond to the specified command. Device address

0 indicates a broadcast command. This means that every slave on the network will act on the command, but it will not issue any responses.

**Function Code Field.** This is a second byte of each transmission and represents the commanded action to the slave device (for queries from the master) or the action that was taken by the slave device (for responses from the slave). Codes between 1 and 127 are defined as Modbus RTU functions. The function codes supported by the Power Manager Xp are detailed on page 4. The function codes supported by the Group 5 Controller are detailed on page 10.

**Data Field.** The data field varies in length depending on whether the message is a request or a response packet. This field typically contains information required by the slave device to perform the command specified in a request packet or data being passed back by the slave device in a response packet.

**Error Check Field.** The error check field consists of a 16 bit (2 byte) Cyclical Redundancy Check (CRC16). It allows the receiving device to detect a packet that has been corrupted with transmission errors. Refer to *CRC-16 Algorithm* on page 2 for details.

### Packet Framing and Timing

Because the Modbus RTU protocol does not define any explicit packet synchronization bytes, synchronization is accomplished implicitly with the use of silent intervals. According to the Modbus RTU standard, all messages must start with a silent interval of at least 3.5 character times. This means that every byte within a packet must precede the previous byte by fewer than 3.5 character times based on the baud rate. And every new packet of data must begin at least 3.5 character times or more after the packet that had preceded it.

In summary, the three timing intervals associated with the ASCO devices are as follows:

- Maximum time between two consecutive bytes within a packet < 3.5 character times.
- Minimum time between two consecutive packets is > 3.5 character times.
- Maximum response time from a Master request to a slave response is < 50 milliseconds.

## CRC-16 Algorithm

**Procedure.** The algorithm essentially treats the entire data packet (less the start, stop, and, if used, parity bits) as one continuous binary number. Since we are doing a 16-bit CRC calculation, the binary number (entire packet) is multiplied by  $2^{16}$  and then divided by the generator polynomial. In the case of the Modbus protocol, the generator polynomial is  $x^{16} + x^{15} + x^2 + 1$ . The 16-bit remainder of the division, which is the 16-bit CRC checksum, is then appended to the end of the packet. The resulting data packet including the 16-bit CRC checksum, when divided by the same Generator Polynomial at the receiver, will give a zero remainder if no transmission errors have occurred.

The binary value of the Generator Polynomial is **A001** hex. This is obtained by first dropping the most-significant-bit of the polynomial and then reversing the bit order. This yields 1010000000000001 or A001h.

The steps for generating the 16-bit CRC checksum are as follows:

1. Initially, load the 16-bit CRC register with the value FFFF hex.
2. Exclusive OR the 16-bit CRC register with the first data byte of the packet and store the result in the 16-bit CRC register.
3. If the Least Significant Bit (LSB) of the 16-bit CRC register is equal to one, then shift the 16-bit CRC register to the right by one bit and then Exclusive OR the result with the generator polynomial, A001 hex. Otherwise, just shift the 16-bit CRC register to the right by one bit.
4. Repeat step 3 until eight right shifts have been performed.
5. Exclusive OR the 16-bit CRC register with the next data byte of the packet.
6. Repeat steps 3-5 until all the bytes of the data packet have been used in step 5.
7. The 16-bit CRC register contains the new checksum to be appended to the end of the packet, Least Significant Byte first.

**CRC-16 Pseudocode.** Below is the pseudocode for generating the 16-bit CRC checksum. XOR is the Exclusive-OR function:

```
CRC16REG = FFFF hex
GENPOLY = A001 hex
```

```
FOR X = 1 to number of bytes in packet
  BEGIN
  XOR CRC16REG with the Xth data byte
  FOR Y = 1 to 8
    BEGIN
    IF [(the least-significant-bit of CRC16REG) = 1] THEN
      SHIFT CRC16REG one bit to the RIGHT
      XOR CRC16REG with GENPOLY
    OTHERWISE
      SHIFT CRC16REG one bit to the RIGHT
    END
  NEXT Y
END
NEXT X
```

The resulting **CRC16REG** contains the 16-bit CRC checksum

**CRC-16 C Programming Language Example.** **CRC16\_checksum** is a C language function that calculates and returns the 16-bit CRC checksum of a string of characters. This is the brute force method as it consumes a lot of processing power performing numerous bit shifts. A table look-up method based on this function would be more suitable for embedded systems where processing power is at a premium. The following four parameters are passed as part of the function

1. pointer to string
2. length of string (in bytes)
3. initial CRC value
4. desired Generator polynomial

Included to make this CRC-16 function generic for any generator polynomial

*continued on next page*

The following C-language type definitions (typedef's) are assumed:

1. typedef unsigned int uint;
2. typedef unsigned char uchar;

The function is defined as follows:

```
uint CRC16_checksum(uchar *Buffer, uint Length, uint CRC, uint Genpoly) {
    uint index;

    While (Length--) {          /* for each data byte in string */
        CRC = CRC ^ (uint) *Buffer++;    /* exclusive OR data byte */

        For (index = 0; index < 8; index++) {    /* for each of the 8 bits */
            If ((CRC & 0x0001) == 1) CRC = (CRC >> 1) ^ Genpoly;
            Else (CRC = CRC >> 1);

        } /* for statement */
    } /* while statement */

    return(CRC);
}
```

**An ASCO Example.** Let's assume the transmitting device desired to send the ASCII string "ASCO". Using an ASCII character look-up table, we have the following hexadecimal codes for each of the ASCO letters:

A = 0x65  
S = 0x83  
C = 0x67  
O = 0x79

The transmitter would determine the 16-bit CRC checksum as follows (in C, both methods are equivalent):

**CRC16\_checksum("ASCO", 4, 0xFFFF, 0xA001) which returns CRC = 0xCD94**  
**CRC16\_checksum("\x65\x83\x67\x79", 4, 0xFFFF, 0xA001) which returns CRC = 0xCD94**

Before sending the string, the transmitter would append the CRC checksum (in byte reverse order) to the string as follows:

"ASCO\x94\xCD" or the equivalent in hexadecimal notation "\x65\x83\x67\x79\x94\xCD"

If the receiving device received the string without any transmission errors, then doing the 16-bit CRC checksum on the entire received string would yield (again, both methods are equivalent):

**CRC16\_checksum("ASCO\x94\xCD", 4, 0xFFFF, 0xA001) which returns CRC = 0x0000**  
**CRC16\_checksum("\x65\x83\x67\x79\x94\xCD", 4, 0xFFFF, 0xA001) which returns CRC = 0x0000**

Since the CRC checksum is equal to **zero**, the transmission is deemed valid.

Had an error been induced during the transmission, such as the ASCII character 'A' being inadvertently changed to the character 'B' (which is hexadecimal 0x66), the receiving device would determine the new checksum as:

**CRC16\_checksum("BSCO\x94\xCD", 4, 0xFFFF, 0xA001) which returns CRC = 0x3300**  
**CRC16\_checksum("\x66\x83\x67\x79\x94\xCD", 4, 0xFFFF, 0xA001) which returns CRC = 0x3300**

Since the CRC is **NON-ZERO (0x3300)**, the receiver would assume an error had occurred and discard the packet.

## Supported Function Codes for Power Manager Xp

### Function # 03 (03h) – Read Holding Registers

This function code allows the master to read one or more consecutive data registers from the Power Manager Xp. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 12 for details about the data register definitions of the Power Manager Xp.

The following example shows the format of a transmission between a master requesting device and the responding Power Manager Xp (slave device) at address 24. The master desires to read the four values of current,  $I_A$ ,  $I_B$ ,  $I_C$ ,  $I_{AVE}$ , beginning at Holding register location 40021 (which is a “Data starting address” of 20 decimal or 14 hexadecimal).

#### Master Transmission

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 03               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | 14               |
| Number of registers (high byte)   | 00               |
| Number of registers (low byte)    | 04               |
| CRC16 (low byte)                  | 06               |
| CRC16 (high byte)                 | 04               |

#### Slave Response

| Packet Format            | Example (in hex) |
|--------------------------|------------------|
| Slave address            | 18               |
| Function code            | 03               |
| Byte count               | 08               |
| Data word #1 (high byte) | 04               |
| Data word #1 (low byte)  | CE               |
| Data word #2 (high byte) | 04               |
| Data word #2 (low byte)  | D3               |
| Data word #3 (high byte) | 04               |
| Data word #3 (low byte)  | D3               |
| Data word #4 (high byte) | 04               |
| Data word #4 (low byte)  | CE               |
| CRC16 (low byte)         | 36               |
| CRC16 (high byte)        | 7F               |

The Power Manger Xp supports the following Read Holding Register addresses-decimal: 11-26, 31-48, 51-64, 71-84, 87-94, 96-125, 127-128, 130-137, 149-159. The Type of those Registers is defined as RO (Read only).

### Function # 06 (06h) – Preset Single Register

This function code allows the master device to modify the contents of a single configuration register within the Power Manager Xp. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 12 for details

about the about the data register definitions of the Power Manager Xp.

The Power Manager Xp currently supports the following Preset Single register addresses. If a Function #06 command is issued without one of these register addresses, the Power Manager Xp will respond with an invalid address range Exception Response (see *Exception Responses* on page 5).

| Address | Address (in hex notation) | Description                                 |
|---------|---------------------------|---|
| 40095   | 005E                      | Relay outputs (DO1-DO4)                     |
| 40200   | 00C7                      | System type                                 |
| 40201   | 00C8                      | Source mode                                 |
| 40202   | 00C9                      | Potential transformer ratio (PTR)           |
| 40203   | 00CA                      | Current transformer ratio (CTR)             |
| 40204   | 00CB                      | Neutral current transformer ratio (CT4R)    |
| 40205   | 00CC                      | SCI comm. port (J5) protocol                |
| 40206   | 00CD                      | SCI comm. port (J5) baud rate               |
| 40207   | 00CE                      | SCI comm. port (J5) device address          |
| 40208   | 00CC                      | 485 comm. Port (J1) protocol                |
| 40209   | 00CD                      | 485 comm. Port (J1) baud rate               |
| 40210   | 00CE                      | 485 comm. port (J1) device address          |
| 40211   | 00CF                      | Menu language selection                     |
| 40212   | 00D0                      | Demand window size (in minutes)             |
| 40213   | 00D1                      | Demand subinterval size (fixed at 1 minute) |
| 40214   | 00D2                      | Reset inst. & max. demand registers         |
| 40215   | 00D3                      | Reset energy registers                      |

The following example shows the format of a transmission between a master device and the responding Power Manager Xp (slave device) at address 24. The master desires to set the System Type (Holding register 40200) to a Single Phase – 3 Wire system (data value 02). See *System Type* on page 7 for details.

#### Master Transmission

| Packet Format            | Example (in hex) |
|--------------------------|------------------|
| Slave address            | 18               |
| Function code            | 06               |
| Data address (high byte) | 00               |
| Data address (low byte)  | C7               |
| Data word (high byte)    | 00               |
| Data word (low byte)     | 02               |
| CRC16 (low byte)         | BB               |
| CRC16 (high byte)        | FF               |

## Slave Response

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 06               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | C7               |
| Number of registers (high byte)   | 00               |
| Number of registers (low byte)    | 02               |
| CRC16 (low byte)                  | BB               |
| CRC16 (high byte)                 | FF               |

The Power Manger Xp supports the following Preset Single Register addresses -decimal: 65-68, 95, 148, 160, and 200-215.

## Function # 16 (10h) – Preset Multiple Registers

This function code allows the master device to modify the contents of consecutive configuration registers within the Power Manager Xp. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 12 for details about the data register definitions of the Power Manager Xp.

The Power Manager Xp currently supports the following Preset Multiple register ranges. If a Function #16 command is issued without one of these corresponding register ranges, the Power Manager Xp will respond with an invalid address range Exception Response (see *Exception Responses* on page 6).

| Address |       | Register Count | Description             | Command String (in Hex)   |
|---------|-------|----------------|-------------------------|---|
| Start   | End   |                |                         |   |
| 40141   | 40146 | 6              | PM Date & Time          | ADDR 10 00 8C 00 06 0C ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40200   | 40213 | 14             | General Settings        | ADDR 10 00 C7 00 0E 1C ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40230   | 40235 | 6              | Setpoint Settings       | ADDR 10 00 E5 00 06 0C ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40326   | 40333 | 8              | S1 Status Input #1 name | ADDR 10 01 45 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40334   | 40341 | 8              | S2 Status Input #2 name | ADDR 10 01 4D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40342   | 40349 | 8              | S3 Status Input #3 name | ADDR 10 01 55 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40350   | 40357 | 8              | S4 Status Input #4 name | ADDR 10 01 5D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40358   | 40365 | 8              | S5 Status Input #5 name | ADDR 10 01 65 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40366   | 40373 | 8              | S6 Status Input #6 name | ADDR 10 01 6D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40374   | 40381 | 8              | S7 Status Input #7 name | ADDR 10 01 75 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40382   | 40389 | 8              | S8 Status Input #8 name | ADDR 10 01 7D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40390   | 40397 | 8              | Relay Output #1 name    | ADDR 10 01 85 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40398   | 40405 | 8              | Relay Output #2 name    | ADDR 10 01 8D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40406   | 40413 | 8              | Relay Output #3 name    | ADDR 10 01 95 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |
| 40414   | 40421 | 8              | Relay Output #4 name    | ADDR 10 01 9D 00 08 10 ..data.. CRC <sub>LO</sub> CRC <sub>HI</sub> |

The following example shows the format of a transmission between a master requesting device and the responding Power Manager Xp (slave device) at address 24. The master desires to configure Setpoint #1 (Holding Registers 40230 – 40235).

## Slave Response

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 10               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | E5               |
| Number of registers (high byte)   | 00               |
| Number of registers (low byte)    | 06               |
| CRC16 (low byte)                  | 53               |
| CRC16 (high byte)                 | F5               |

The Power Manger Xp supports the following Preset Single Register addresses -decimal: 141-146, 200-213, 230-235, 236-319, 322-325, 326-421, and 422-433.

## Master Transmission

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 10               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | E5               |
| Number of registers (high byte)   | 00               |
| Number of registers (low byte)    | 06               |
| Byte count                        | 0C               |
| Data word #1 (high byte)          | 00               |
| Data word #1 (low byte)           | 01               |
| Data word #2 (high byte)          | 03               |
| Data word #2 (low byte)           | E8               |
| Data word #3 (high byte)          | 00               |
| Data word #3 (low byte)           | 00               |
| Data word #4 (high byte)          | 03               |
| Data word #4 (low byte)           | 20               |
| Data word #5 (high byte)          | 00               |
| Data word #5 (low byte)           | 05               |
| Data word #6 (high byte)          | 00               |
| Data word #6 (low byte)           | 02               |
| CRC16 (low byte)                  | D1               |
| CRC16 (high byte)                 | 91               |

## Exception Responses

If the Modbus master device sends an unsupported command, attempts to read an invalid holding register, or attempts to write invalid data, the Power Manager Xp (Modbus slave) issues an exception response. The format for the exception response is as follows:

1. SLAVE ADDRESS
2. FUNCTION CODE\*  
(with the most-significant-bit set to a 1)
3. ERROR CODE
4. CRC16 – low order byte
5. CRC16 – high order byte

\* Note: The high order bit of the function code has been set to one to indicate an exception response has been generated.

The following table is a list of the exception codes supported by the Power Manager Xp.

### Exception Response Error Codes

| Error code | Error name           | Power Manager Xp implementation  |
|------------|----------------------|--|
| 01         | Illegal function     | The slave does not support the function code contained in the master query packet.                               |
| 02         | Illegal data address | The slave does not support the Holding Register address referenced in the data field of the master query packet. |
| 03         | Illegal data value   | The slave does not support the data referenced in the data field of the master query packet.                     |
| 04         | Device failure       | The addresses slave is unable to perform the action requested due to an internal failure or malfunction.         |

The following example shows the format of a transmission between a master device and the responding Power Manager Xp (slave device) at address 24. The master device attempts to write an invalid data value (04) to the System Type holding register 40200. The Power Manager Xp slave device responds with Error code 03.

### Master Transmission

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 06               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | C7               |
| Data (high byte)                  | 00               |
| Data (low byte)                   | 04               |
| CRC16 (low byte)                  | 3B               |
| CRC16 (high byte)                 | FD               |

### Slave Response

| Packet Format     | Example (in hex) |
|-------------------|------------------|
| Slave address     | 18               |
| Function code     | 86               |
| Error code        | 03               |
| CRC16 (low byte)  | D3               |
| CRC16 (high byte) | A6               |

The following example shows the format of a transmission between a master device and the responding Power Manager Xp (slave device) at address 24. The master device attempts to write to an invalid address, 40216 (0x00D7). The Power Manager Xp slave device responds with Error code 02.

### Master Transmission

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 06               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | D7               |
| Data (high byte)                  | 00               |
| Data (low byte)                   | 03               |
| CRC16 (low byte)                  | 7B               |
| CRC16 (high byte)                 | FA               |

### Slave Response

| Packet Format     | Example (in hex) |
|-------------------|------------------|
| Slave address     | 18               |
| Function code     | 86               |
| Error code        | 02               |
| CRC16 (low byte)  | 12               |
| CRC16 (high byte) | 66               |

## Configuration Register Details

### System Type – Holding Register no. 40200

The system type register defines the type of system to which the Power Manager Xp is connected.

| Binary value | Label     | Description                  |
|--------------|-----------|------------------------------|
| 0 (00h)      | 4W_WYE    | 3 Phase, 4 wire WYE system   |
| 1 (01h)      | 3W_DELTA  | 3 Phase, 3 wire DELTA system |
| 2 (02h)      | 3W_1PHASE | Single phase, 3 wire system  |
| 3 (03h)      | 2W_1PHASE | Single phase, 2 wire system  |

### Source Mode – Holding Register no. 40201

The source mode register defines the source bus, to which the Power Manager Xp is connected. The Energy register display window changes according to the bus defined. The user can specify a normal bus connection, an emergency bus connection, a connection to the load side of the bus or no specific designation.

| Binary value | Label     | Description   |
|--------------|-----------|---|
| 0 (00h)      | NORMAL    | Normal power bus  |
| 1 (01h)      | EMERGENCY | Emergency power bus                                       |
| 2 (02h)      | LOAD      | Load power bus  |
| 3 (03h)      | OTHER     | Any power bus with no designation on the Energy registers |

When the LOAD selection is chosen, the Power Manager Xp uses the N/E INPUT status input to determine ATS switch position. Two sets of Energy registers are used; Normal energy registers & Emergency energy registers.

### Potential Transformer Ratio – Holding Register no. 40202

This register defines the full-scale voltage input value for the three phases of voltage. This is based on the ratio of the external voltage transformers (PTs) connected between the Power Manager Xp and the power bus.

| Range         |
|---------------|
| 120 to 28,200 |

The value of 28,200 is the ratio 235:1 (120 \* 235 = 28,200). Note that if external voltage transformers are not required and subsequently not used, the ratio should be set to 120, which is 1:1.

### Current Transformer Ratio – Holding Register no. 40203

This register defines the full-scale current input value for the three phases of current. This is based on the ratio of the external current transformers (CTs) connected between the Power Manager Xp and the power bus.

| Range       |
|-------------|
| 5 to 24,000 |

### 4<sup>th</sup> Current Input Transformer Ratio – Holding Register no. 40204

This register defines the full-scale current input value for the 4<sup>th</sup> or neutral current input. This is based on the ratio of the external current transformer (CT) connected between the Power Manager Xp and the power bus.

| Range       |
|-------------|
| 5 to 24,000 |

### SCI Communications Port (J5) Protocol – Holding Register no. 40205

Defines the protocol of the SCI communications port.

| Binary value | Label     | Description        |
|--------------|-----------|--------------------|
| 0 (00h)      | ASCOBusI  | ASCOBusI protocol  |
| 1 (01h)      | ASCOBusII | ASCOBusII protocol |
| 2 (02h)      | ModbusRTU | ModbusRTU protocol |

### SCI Communications Port (J5) Baud Rate – Holding Register no. 40206

Defines the baud rate of the SCI communications port.

| Binary value | Label  | Description |
|--------------|--------|-------------|
| 1 (01h)      | _9600  | 9600 bps    |
| 2 (02h)      | _19_2K | 19200 bps   |

### SCI Communications Port (J5) Device Address – Holding Register no. 40207

Defines the Power Manager Xp address of the SCI communications port.

| Protocol  | Allowable address range |
|-----------|-------------------------|
| ASCOBusI  | 0-31                    |
| ASCOBusII | 1-239                   |
| ModbusRTU | 1-239                   |

### 485 Communications Port (J1) Protocol – Holding Register no. 40208

Defines the protocol of the dedicated RS-485 communications port, if present on Power Manager Xp. ‡

| Binary value | Label     | Description        |
|--------------|-----------|--------------------|
| 0 (00h)      | ASCOBusI  | ASCOBusI protocol  |
| 1 (01h)      | ASCOBusII | ASCOBusII protocol |
| 2 (02h)      | ModbusRTU | ModbusRTU protocol |

### 485 Communications Port (J1) Baud Rate – Holding Register no. 40209

Defines the baud rate of the dedicated RS-485 communications port, if present on Power Manager Xp. ‡


| Binary value | Label | Description |
|--------------|-------|-------------|
| 1 (01h)      | 9600  | 9600 bps    |
| 2 (02h)      | 19 2K | 19200 bps   |
| 3 (03h)      | 38 4K | 38400 bps   |
| 4 (04h)      | 57 6K | 57600 bps   |

### 485 Communications Port (J1) Device Address – Holding Register no. 40210

Defines the Power Manager Xp address of the dedicated RS-485 communications port, if present on Power Manager Xp. ‡

| Protocol  | Allowable address range |
|-----------|-------------------------|
| ASCOBusI  | 0-31                    |
| ASCOBusII | 1-239                   |
| ModbusRTU | 1-239                   |

‡ Power Managers with Transducers part # 629168 (Catalog 5200T) support the RS-485 com port J1.  
Data Monitors with Electronic Access Module part # 607607 Rev E or higher support the RS-485 com port J1.



Part no.  
629168  
or  
607607  
Rev. E

### Language – Holding Register no. 40211

Defines the Language displayed on the liquid crystal display (LCD) interface.

| Binary value | Label   | Description       |
|--------------|---------|-------------------|
| 0 (00h)      | ENGLISH | English language* |

\* Currently only the English language is available.

### Demand Window Size – Holding Register no. 40212

Defines the length of the demand period, in minutes, used in calculating the sliding window demand values.

| Range   |
|---------|
| 1 to 15 |

### Subinterval Size – Holding Register no. 40213

Defines the length of the subinterval demand period, in minutes, used in calculating the sliding window demand values. This value is fixed at 1 minute.

| Range |
|-------|
| 1     |

### Reset Demand – Holding Register no. 40214

Writing a value of 0xFFFF to this holding register clears the Minimum and Maximum KW Demand registers.

### Clear Energy – Holding Register no. 40215

Writing a value of 0xFFFF to this holding register clears the Energy registers.



**Status Input Names (8)**  
**– Holding Register nos. 40326-40389**

Defines the name of the eight Status Inputs (S1 – S8). The name consists of sixteen ASCII characters, which are assigned two characters per register.

| <i>Register Address</i> | <i>Register description<br/>(2 ASCII characters per register)</i> |
|-------------------------|---|
| Base                    | INPUT_NAME <sub>char1</sub> + INPUT_NAME <sub>char2</sub>         |
| Base + 1                | INPUT_NAME <sub>char3</sub> + INPUT_NAME <sub>char4</sub>         |
| Base + 2                | INPUT_NAME <sub>char5</sub> + INPUT_NAME <sub>char6</sub>         |
| Base + 3                | INPUT_NAME <sub>char7</sub> + INPUT_NAME <sub>char8</sub>         |
| Base + 4                | INPUT_NAME <sub>char9</sub> + INPUT_NAME <sub>char10</sub>        |
| Base + 5                | INPUT_NAME <sub>char11</sub> + INPUT_NAME <sub>char12</sub>       |
| Base + 6                | INPUT_NAME <sub>char13</sub> + INPUT_NAME <sub>char14</sub>       |
| Base + 7                | INPUT_NAME <sub>char15</sub> + INPUT_NAME <sub>char16</sub>       |

**Relay Output Names (4)**  
**– Holding Register nos. 40390-40421**

Defines the name of the four Relay Outputs (DO1 – DO4). The name consists of sixteen ASCII characters, which are assigned two characters per register.

| <i>Register Address</i> | <i>Register description<br/>(2 ASCII characters per register)</i> |
|-------------------------|---|
| Base                    | OUTPUT_NAME <sub>char1</sub> + OUTPUT_NAME <sub>char2</sub>       |
| Base + 1                | OUTPUT_NAME <sub>char3</sub> + OUTPUT_NAME <sub>char4</sub>       |
| Base + 2                | OUTPUT_NAME <sub>char5</sub> + OUTPUT_NAME <sub>char6</sub>       |
| Base + 3                | OUTPUT_NAME <sub>char7</sub> + OUTPUT_NAME <sub>char8</sub>       |
| Base + 4                | OUTPUT_NAME <sub>char9</sub> + OUTPUT_NAME <sub>char10</sub>      |
| Base + 5                | OUTPUT_NAME <sub>char11</sub> + OUTPUT_NAME <sub>char12</sub>     |
| Base + 6                | OUTPUT_NAME <sub>char13</sub> + OUTPUT_NAME <sub>char14</sub>     |
| Base + 7                | OUTPUT_NAME <sub>char15</sub> + OUTPUT_NAME <sub>char16</sub>     |

## Supported Function Codes for Group 5 Controller

### Function # 03 (03h) – Read Holding Registers

This function code allows the master to read one or more consecutive data registers from the Group 5 Controller. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 18 for details about the data register definitions of the Group 5 Controller.

The following example shows the format of a transmission between a master requesting device and the responding Group 5 Controller (slave device) at address 24 (24 decimal = 18 hex).. The master desires to read the three values of voltage,  $NV_{AB}$ ,  $NV_{BC}$ ,  $NV_{CA}$ ,  $I_{AVE}$ , beginning at Holding register location 40016 (16 decimal = 10 hexadecimal).

#### Master Transmission

| Packet Format                     | Example (in hex) |
|-----------------------------------|------------------|
| Slave address                     | 18               |
| Function code                     | 03               |
| Data starting address (high byte) | 00               |
| Data starting address (low byte)  | 10               |
| Number of registers (high byte)   | 00               |
| Number of registers (low byte)    | 03               |
| CRC16 (low byte)                  | 04               |
| CRC16 (high byte)                 | 0E               |

#### Slave Response

| Packet Format            | Example (in hex) |
|--------------------------|------------------|
| Slave address            | 18               |
| Function code            | 03               |
| Byte count               | 06               |
| Data word #1 (high byte) | 00               |
| Data word #1 (low byte)  | 78               |
| Data word #2 (high byte) | 00               |
| Data word #2 (low byte)  | 79               |
| Data word #3 (high byte) | 00               |
| Data word #3 (low byte)  | 77               |
| CRC16 (low byte)         | B7               |
| CRC16 (high byte)        | 10               |

The Group 5 Controller currently supports the following Read Holding Register addresses (decimal): 11-54, 100, 105-173. Maximum number of registers that can be read with a single 03H command is 12. Attempting to read more than 12 registers with a single 03H command will result in Exception Response from the Group 5 Controller.

### Function # 06 (06h) – Preset Single Register

This function code allows the master device to modify the contents of a single configuration register within the Group 5 Controller. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 18 for details

about the about the data register definitions of the Group 5 Controller.

The following example shows the format of a transmission between a master device and the responding Group 5 Controller (slave device) at address 24 (24 decimal = 18 hex). The master desires to set the time delay TDES at Holding register 40132 (132 decimal = 84 hex) to 5 seconds (data value 05).

#### Master Transmission

| Packet Format            | Example (in hex) |
|--------------------------|------------------|
| Slave address            | 18               |
| Function code            | 06               |
| Data address (high byte) | 00               |
| Data address (low byte)  | 84               |
| Data word (high byte)    | 00               |
| Data word (low byte)     | 05               |
| CRC16 (low byte)         | 0B               |
| CRC16 (high byte)        | E9               |

#### Slave Response

| Packet Format                   | Example (in hex) |
|---------------------------------|------------------|
| Slave address                   | 18               |
| Function code                   | 06               |
| Data address (high byte)        | 00               |
| Data address (low byte)         | 84               |
| Number of registers (high byte) | 00               |
| Number of registers (low byte)  | 05               |
| CRC16 (low byte)                | 0B               |
| CRC16 (high byte)               | E9               |

The Group 5 Controller currently supports the following Preset Single Register addresses (decimal): 44, 101-173.

### Function # 16 (10h) – Preset Multiple Registers

This function code allows the master device to modify the contents of consecutive configuration registers within the Group 5 Controller. The data registers are always 16 bit (two byte) values, transmitted high order byte first. Refer to *Register Map* on page 18 for details about the data register definitions of the Group 5 Controller.

The following example shows the format of a transmission between a master requesting device and the responding Group 5 Controller (slave device) at address 24 (24 decimal = 18 hex). The master desires to set the following parameters occupying consecutive register locations: NVDO at Holding register 40118 (118 decimal = 76 hex) to 85% (85 decimal = 55 hex), NVPU at Holding register 40119 to 90% (90 decimal = 5A hex) and NVTP at Holding register 40120 to 110% (110 decimal = 6E hex).

## Master Transmission

| <i>Packet Format</i>              | <i>Example (in hex)</i> |
|-----------------------------------|-------------------------|
| Slave address                     | 18                      |
| Function code                     | 10                      |
| Data starting address (high byte) | 00                      |
| Data starting address (low byte)  | 76                      |
| Number of registers (high byte)   | 00                      |
| Number of registers (low byte)    | 03                      |
| Byte count                        | 06                      |
| Data word #1 (high byte)          | 00                      |
| Data word #1 (low byte)           | 55                      |
| Data word #2 (high byte)          | 00                      |
| Data word #2 (low byte)           | 5A                      |
| Data word #3 (high byte)          | 00                      |
| Data word #3 (low byte)           | 6E                      |
| CRC16 (low byte)                  | 8A                      |
| CRC16 (high byte)                 | 1E                      |

## Slave Response

| <i>Packet Format</i>              | <i>Example (in hex)</i> |
|-----------------------------------|-------------------------|
| Slave address                     | 18                      |
| Function code                     | 10                      |
| Data starting address (high byte) | 00                      |
| Data starting address (low byte)  | 76                      |
| Number of registers (high byte)   | 00                      |
| Number of registers (low byte)    | 03                      |
| CRC16 (low byte)                  | 63                      |
| CRC16 (high byte)                 | DB                      |

The Group 5 Controller currently supports the following Preset Multiple Register addresses (decimal): 44, 101-173.

**Note:** To access the Log Events data at Holding Register addresses 40044-40053 first the selected Log Event number has to be written into Register 40044 using Function 06H command and then the data of that Event can be read from Registers 40045-40053 using Function 03H command.

Similarly, to access the Feature F11C Schedules data at Holding Registers addresses 40112-40117, first the selected Schedule number to access (read or write) has to be written into Register 40112 using Function 06H command and then the data of that Schedule can be accessed (read or written to) at Registers 40113-40117 using Function 03H, 06H, or 10H command.

## Exception Responses

If the Modbus master device sends an unsupported command, attempts to read an invalid holding register, or attempts to write invalid data, the Group 5 Controller (Modbus slave) issues an exception response. The format for the exception response is as follows:

1. SLAVE ADDRESS
2. FUNCTION CODE\*  
(with the most-significant-bit set to a 1)
3. ERROR CODE
4. CRC16 – low order byte
5. CRC16 – high order byte

\* Note: The high order bit of the function code has been set to one to indicate an exception response has been generated.

The following table is a list of the exception codes supported by the Group 5 Controller.

## Exception Response Error Codes

| <i>Error code</i> | <i>Error name</i>    | <i>Group 5 Controller implementation</i>   |
|-------------------|----------------------|--|
| 01                | Illegal function     | The slave does not support the function code contained in the master query packet.                               |
| 02                | Illegal data address | The slave does not support the Holding Register address referenced in the data field of the master query packet. |
| 03                | Illegal data value   | The slave does not support the data referenced in the data field of the master query packet.                     |
| 04                | Device failure       | The addresses slave is unable to perform the action requested due to an internal failure or malfunction.         |

The following example shows the format of a transmission between a master device and the responding Group 5 Controller (slave device) at address 24. The master device attempts to write data word 0015H to a Read Only Register at 40016 (16 decimal = 10 hex). The Group 5 Controller slave device responds with Error code 02.

## Master Transmission

| <i>Packet Format</i>              | <i>Example (in hex)</i> |
|-----------------------------------|-------------------------|
| Slave address                     | 18                      |
| Function code                     | 06                      |
| Data starting address (high byte) | 00                      |
| Data starting address (low byte)  | 10                      |
| Data (high byte)                  | 00                      |
| Data (low byte)                   | 15                      |
| CRC16 (low byte)                  | 4B                      |
| CRC16 (high byte)                 | C9                      |

## Slave Response

| <i>Packet Format</i> | <i>Example (in hex)</i> |
|----------------------|-------------------------|
| Slave address        | 18                      |
| Function code        | 86                      |
| Error code           | 02                      |
| CRC16 (low byte)     | 12                      |
| CRC16 (high byte)    | 66                      |

## Register Map for Power Manager Xp

The following table describes the mapping of the registers within the Power Manager Xp to Holding Registers defined in the Modbus protocol.

Note: The addresses in the format of 4xxxx follow the MODICON MODBUS protocol for point addressing.  
The actual address sent is the Register Address shown in the map minus the value **40001**.

| Register Address | Register Type | Parameter Name      | Parameter Description             | Data Range             | Implemented in Firmware Version |
|------------------|---------------|---------------------|-----------------------------------|------------------------|---------------------------------|
| 40001-40010      |               |                     | Undefined                         |                        |                                 |
| 40011            | RO            | V <sub>AN</sub>     | Phase A line to neutral voltage   | 0 – 59,999             | FS611842-006                    |
| 40012            | RO            | V <sub>BN</sub>     | Phase B line to neutral voltage   | 0 – 59,999             | FS611842-006                    |
| 40013            | RO            | V <sub>CN</sub>     | Phase C line to neutral voltage   | 0 – 59,999             | FS611842-006                    |
| 40014            | RO            | V <sub>AVE</sub>    | Line to neutral average voltage   | 0 – 59,999             | FS611842-006                    |
| 40015            | RO            | V <sub>AB</sub>     | A-B line to line voltage          | 0 – 59,000             | FS611842-006                    |
| 40016            | RO            | V <sub>BC</sub>     | B-C line to line voltage          | 0 – 59,000             | FS611842-006                    |
| 40017            | RO            | V <sub>CA</sub>     | C-A line to line voltage          | 0 – 59,000             | FS611842-006                    |
| 40018            | RO            | V <sub>LAVE</sub>   | Line to line average voltage      | 0 – 59,000             | FS611842-006                    |
| 40019            | RO            | V <sub>LUNBAL</sub> | Line to line voltage unbalance    | 0 – 100%               | FS611842-006                    |
| 40020            | RO            | V <sub>UNBAL</sub>  | Line to neutral voltage unbalance | 0 – 100%               | FS611842-006                    |
| 40021            | RO            | I <sub>A</sub>      | Phase A current                   | 0 – 29,999             | FS611842-006                    |
| 40022            | RO            | I <sub>B</sub>      | Phase B current                   | 0 – 29,999             | FS611842-006                    |
| 40023            | RO            | I <sub>C</sub>      | Phase C current                   | 0 – 29,999             | FS611842-006                    |
| 40024            | RO            | I <sub>AVE</sub>    | Average current                   | 0 – 29,999             | FS611842-006                    |
| 40025            | RO            | I <sub>UNBAL</sub>  | Current unbalance                 | 0 – 100%               | FS611842-006                    |
| 40026            | RO            | I <sub>N</sub>      | CT4 or neutral current            | 0 – 29,999             | FS611842-006                    |
| 40027-40030      |               |                     | Undefined                         |                        |                                 |
| 40031            | RO            | kW <sub>A</sub>     | Active Power phase A              | -29,999 to +29,999     | FS611842-006                    |
| 40032            | RO            | kW <sub>B</sub>     | Active Power phase B              | -29,999 to +29,999     | FS611842-006                    |
| 40033            | RO            | kW <sub>C</sub>     | Active Power phase C              | -29,999 to +29,999     | FS611842-006                    |
| 40034            | RO            | kW <sub>T</sub>     | Active Power total                | -29,999 to +29,999     | FS611842-006                    |
| 40035            | RO            | kVAR <sub>A</sub>   | Reactive Power phase A            | -29,999 to +29,999     | FS611842-006                    |
| 40036            | RO            | kVAR <sub>B</sub>   | Reactive Power phase B            | -29,999 to +29,999     | FS611842-006                    |
| 40037            | RO            | kVAR <sub>C</sub>   | Reactive Power phase C            | -29,999 to +29,999     | FS611842-006                    |
| 40038            | RO            | kVAR <sub>T</sub>   | Reactive Power total              | -29,999 to +29,999     | FS611842-006                    |
| 40039            | RO            | Pf <sub>A</sub>     | Power Factor phase A              | (-.99 to +1.00) * 100  | FS611842-006                    |
| 40040            | RO            | Pf <sub>B</sub>     | Power Factor phase B              | (-.99 to +1.00) * 100  | FS611842-006                    |
| 40041            | RO            | Pf <sub>C</sub>     | Power Factor phase C              | (-.99 to +1.00) * 100  | FS611842-006                    |
| 40042            | RO            | Pf <sub>T</sub>     | Power Factor total                | (-.99 to +1.00) * 100  | FS611842-006                    |
| 40043            | RO            | kVA <sub>A</sub>    | volt-ampere Power phase A         | 0 – 29,999             | FS611842-006                    |
| 40044            | RO            | kVA <sub>B</sub>    | volt-ampere Power phase B         | 0 – 29,999             | FS611842-006                    |
| 40045            | RO            | kVA <sub>C</sub>    | volt-ampere Power phase C         | 0 – 29,999             | FS611842-006                    |
| 40046            | RO            | kVA <sub>T</sub>    | volt-ampere Power total           | 0 – 29,999             |                                 |
| 40047            |               |                     | Undefined                         |                        |                                 |
| 40048            | RO            | Freq.               | Frequency on phase V <sub>A</sub> | (40.00 to 80.00) * 100 | FS611842-006                    |

|             |    |                          |                                   |                                   |              |
|-------------|----|--------------------------|-----------------------------------|-----------------------------------|--------------|
| 40049-40050 |    |                          | Undefined                         |                                   |              |
| 40051       | RO | NormkWH <sub>IMP</sub>   | Normal kWh Import (LO word)       | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40052       | RO | NormkWH <sub>IMP</sub>   | Normal kWh Import (HO word)       |                                   | FS611842-006 |
| 40053       | RO | NormkWH <sub>EXP</sub>   | Normal kWh Export (LO word)       | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40054       | RO | NormkWH <sub>EXP</sub>   | Normal kWh Export (HO word)       |                                   | FS611842-006 |
| 40055       | RO | NormkWH <sub>NET</sub>   | Normal kWh Net (LO word)          | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40056       | RO | NormkWH <sub>NET</sub>   | Normal kWh Net (HO word)          |                                   | FS611842-006 |
| 40057       | RO | NormkVarH <sub>IMP</sub> | Normal kVarH Import (LO word)     | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40058       | RO | NormkVarH <sub>IMP</sub> | Normal kVarH Import (HO word)     |                                   | FS611842-006 |
| 40059       | RO | NormkVarH <sub>EXP</sub> | Normal kVarH Export (LO word)     | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40060       | RO | NormkVarH <sub>EXP</sub> | Normal kVarH Export (HO word)     |                                   | FS611842-006 |
| 40061       | RO | NormkVarH <sub>NET</sub> | Normal kVarH Net (LO word)        | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40062       | RO | NormkVarH <sub>NET</sub> | Normal kVarH Net (HO word)        |                                   | FS611842-006 |
| 40063       | RO | NormkVAH <sub>NET</sub>  | Normal kVAH Net (LO word)         | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40064       | RO | NormkVAH <sub>NET</sub>  | Normal kVAH Net (HO word)         |                                   | FS611842-006 |
| 40065       | RW | Nom_Volt                 | Nominal Voltage                   | 115-59999                         | AS629262-004 |
| 40066       | RW | Nom_Amps                 | Nominal Current                   | 0-29999                           | AS629262-004 |
| 40067       | RW | kW_Capacity              | Nominal kW Capacity               | 0-24999                           | AS629262-004 |
| 40068       | RW | Nom_Freq                 | Nominal Freq 0– 60Hz, 1–50Hz      | 0 or 1                            | AS629262-004 |
| 40069-40070 |    |                          | Undefined                         |                                   |              |
| 40071       | RO | EmerkWH <sub>IMP</sub>   | Emerg kWh Import (LO word)        | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40072       | RO | EmerkWH <sub>IMP</sub>   | Emerg kWh Import (HO word)        |                                   | FS611842-006 |
| 40073       | RO | EmerkWH <sub>EXP</sub>   | Emerg kWh Export (LO word)        | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40074       | RO | EmerkWH <sub>EXP</sub>   | Emerg kWh Export (HO word)        |                                   | FS611842-006 |
| 40075       | RO | EmerkWH <sub>NET</sub>   | Emerg kWh Net (LO word)           | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40076       | RO | EmerkWH <sub>NET</sub>   | Emerg kWh Net (HO word)           |                                   | FS611842-006 |
| 40077       | RO | EmerkVarH <sub>IMP</sub> | Emerg kVarH Import (LO word)      | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40078       | RO | EmerkVarH <sub>IMP</sub> | Emerg kVarH Import (HO word)      |                                   | FS611842-006 |
| 40079       | RO | EmerkVarH <sub>EXP</sub> | Emerg kVarH Export (LO word)      | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40080       | RO | EmerkVarH <sub>EXP</sub> | Emerg kVarH Export (HO word)      |                                   | FS611842-006 |
| 40081       | RO | EmerkVarH <sub>NET</sub> | Emerg kVarH Net (LO word)         | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40082       | RO | EmerkVarH <sub>NET</sub> | Emerg kVarH Net (HO word)         |                                   | FS611842-006 |
| 40083       | RO | EmerkVAH <sub>NET</sub>  | Emerg kVAH Net (LO word)          | -1,999,999,999 to + 1,999,999,999 | FS611842-006 |
| 40084       | RO | EmerkVAH <sub>NET</sub>  | Emerg kVAH Net (HO word)          |                                   | FS611842-006 |
| 40085-40086 |    |                          | Undefined                         |                                   |              |
| 40087       | RO | kW <sub>T</sub>          | Active Power (Watts) total        | -29,999 to +29,999                | FS611842-006 |
| 40088       | RO | kWDemand <sub>T</sub>    | Instantaneous Watt Demand         | -29,999 to +29,999                | FS611842-006 |
| 40089       | RO | MaxkWDemand              | Maximum Watt Demand               | -29,999 to +29,999                | FS611842-006 |
| 40090       | RO | kW <sub>T</sub>          | Active Power (Watts) total        | -29,999 to +29,999                | FS611842-006 |
| 40091       | RO | I <sub>AVE</sub>         | Average current                   | 0 – 29,999                        | FS611842-006 |
| 40092       | RO | V <sub>LAVE</sub>        | Line to line average voltage      | 0 – 59,999                        | FS611842-006 |
| 40093       | RO | Freq.                    | Frequency on phase V <sub>A</sub> | (40.00 to 80.00) * 100            | FS611842-006 |
| 40094       | RO | StatusInputs             | 8 General purpose digital inputs  | Bits 0 – 7 ⇒ S1–S8                | FS611842-006 |
| 40095       | RW | RelayOutputs             | 4 General purpose digital outputs | Bits 0 – 3 ⇒ DO1–DO4              | FS611842-006 |
| 40096       | RO | SwitchPosition           | Main & auxiliary Switch positions | 0:norm & 1:emer.                  | FS611842-006 |
| 40097       | RO | kW <sub>T</sub>          | Active Power total                | -29,999 to +29,999                | FS611842-006 |

|              |    |                       |   |                        |              |
|--------------|----|-----------------------|---|------------------------|--------------|
| 40098        | RO | kVAR <sub>T</sub>     | Reactive Power total                      | -29,999 to +29,999     | FS611842-006 |
| 40099        | RO | kVA <sub>T</sub>      | volt-ampere Power total                   | 0 – 29,999             | FS611842-006 |
| 40100        | RO | Pf <sub>T</sub>       | Power Factor total                        | (-0.99 to +1.00) * 100 | FS611842-006 |
| 40101        | RO | Freq.                 | Frequency on phase V <sub>A</sub>         | (40.00 to 80.00) * 100 | FS611842-006 |
| 40102-40107  | RO | V_String              | Software Version string                   | 12 ASCII characters    | FS611842-006 |
| 40108-40113  | RO | SW_Date               | Software build date string                | 12 ASCII characters    | FS611842-006 |
| 40114-40119  | RO | SerialNumber          | Device serial number                      | 12 ASCII characters    | FS611842-006 |
| 40120-40125  | RO | ModelNumber           | Device model number                       | 12 ASCII characters    | FS611842-006 |
| 40126        |    |                       | Undefined                                 |                        |              |
| 40127        | RO | H_STATUS              | Health status word                        |                        | FS611842-006 |
| 40128-Bit0   | RO | SP_STATUS             | Setpoint #1 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128-Bit1   | RO | SP_STATUS             | Setpoint #1 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit 2 | RO | SP_STATUS             | Setpoint #2 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit 3 | RO | SP_STATUS             | Setpoint #2 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit 4 | RO | SP_STATUS             | Setpoint #3 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit 5 | RO | SP_STATUS             | Setpoint #3 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit 6 | RO | SP_STATUS             | Setpoint #4 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit 7 | RO | SP_STATUS             | Setpoint #4 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit 8 | RO | SP_STATUS             | Setpoint #5 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit 9 | RO | SP_STATUS             | Setpoint #5 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit10 | RO | SP_STATUS             | Setpoint #6 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit11 | RO | SP_STATUS             | Setpoint #6 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit12 | RO | SP_STATUS             | Setpoint #7 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit13 | RO | SP_STATUS             | Setpoint #7 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40128- Bit14 | RO | SP_STATUS             | Setpoint #8 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40128- Bit15 | RO | SP_STATUS             | Setpoint #8 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40129- Bit 0 | RO | SP_STATUS             | Setpoint #9 Output Status Normal/Tripped  | 0 or 1                 | AS629262-004 |
| 40129- Bit 1 | RO | SP_STATUS             | Setpoint #9 Acknowledge State Ack/Pendg   | 0 or 1                 | AS629262-004 |
| 40129- Bit 2 | RO | SP_STATUS             | Setpoint #10 Output Status Normal/Tripped | 0 or 1                 | AS629262-004 |
| 40129- Bit 3 | RO | SP_STATUS             | Setpoint #10 Acknowledge State Ack/Pendg  | 0 or 1                 | AS629262-004 |
| 40129- Bit 4 | RO | SP_STATUS             | Setpoint #11 Output Status Normal/Tripped | 0 or 1                 | AS629262-004 |
| 40129- Bit 5 | RO | SP_STATUS             | Setpoint #11 Acknowledge State Ack/Pendg  | 0 or 1                 | AS629262-004 |
| 40129- Bit 6 | RO | SP_STATUS             | Setpoint #12 Output Status Normal/Tripped | 0 or 1                 | AS629262-004 |
| 40129- Bit 7 | RO | SP_STATUS             | Setpoint #12 Acknowledge State Ack/Pendg  | 0 or 1                 | AS629262-004 |
| 40129- Bit 8 | RO | SP_STATUS             | kW Demand Setpoint Status Normal/Trip     | 0 or 1                 | AS629262-004 |
| 40129        |    |                       | Not Used                                  | Bit 9:Bit 15           |              |
| 40130        | RO | kW <sub>T</sub>       | Active Power (Watts) total                | -29,999 to +29,999     | FS611842-006 |
| 40131        | RO | kWDemand <sub>T</sub> | Instantaneous Watt Demand                 | -29,999 to +29,999     | FS611842-006 |
| 40132        | RO | MaxkW                 | Maximum Watt Demand                       | -29,999 to +29,999     | FS611842-006 |
| 40133        | RO | kWD_Date              | Maximum Watt Demand Date                  | 1-31                   | FS611842-006 |
| 40134        | RO | kWD_Month             | Maximum Watt Demand Month                 | 1-12                   | FS611842-006 |
| 40135        | RO | kWD_Year              | Maximum Watt Demand Year                  | 1-99                   | FS611842-006 |
| 40136        | RO | kWD_Hour              | Maximum Watt Demand Hour                  | 1-23                   | FS611842-006 |
| 40137        | RO | kWD_Minute            | Maximum Watt Demand Minute                | 1-59                   | FS611842-006 |
| 40138-40140  |    |                       | Undefined                                 |                        |              |
| 40141        | RW | PM_TIME               | Power Manager Hours                       | 0-23                   | AS629262-004 |

|              |    |              |   |        |              |
|--------------|----|--------------|---|--------|--------------|
| 40142        | RW | PM_TIME      | Power Manager Minutes   | 0-59   | AS629262-004 |
| 40143        | RW | PM_DATE      | Power Manager Year  | 0-99   | AS629262-004 |
| 40144        | RW | PM_DATE      | Power Manager Month   | 1-12   | AS629262-004 |
| 40145        | RW | PM_DATE      | Power Manager Day of Month  | 1-31   | AS629262-004 |
| 40146        | RW | PM_DATE      | Power Manager Day of Week (0-S, 1-M, etc)   | 1-6    | AS629262-004 |
| 40147        |    |              | Undefined   |        |              |
| 40148-Bit 0  | WO | SP_ACK       | Setpoint #1 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 1 | WO | SP_ACK       | Setpoint #2 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 2 | WO | SP_ACK       | Setpoint #3 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 3 | WO | SP_ACK       | Setpoint #4 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 4 | WO | SP_ACK       | Setpoint #5 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 5 | WO | SP_ACK       | Setpoint #6 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 6 | WO | SP_ACK       | Setpoint #7 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 7 | WO | SP_ACK       | Setpoint #8 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 8 | WO | SP_ACK       | Setpoint #9 Output Alarm Acknowledge  | 0 or 1 | AS629262-004 |
| 40148- Bit 9 | WO | SP_ACK       | Setpoint #10 Output Alarm Acknowledge   | 0 or 1 | AS629262-004 |
| 40148- Bit10 | WO | SP_ACK       | Setpoint #11 Output Alarm Acknowledge   | 0 or 1 | AS629262-004 |
| 40148- Bit11 | WO | SP_ACK       | Setpoint #12 Output Alarm Acknowledge   | 0 or 1 | AS629262-004 |
| 40148- Bit12 |    |              | Not Used  |        |              |
| 40148- Bit13 |    |              | Not Used  |        |              |
| 40148- Bit14 |    |              | Not Used  |        |              |
| 40148- Bit15 |    |              | Not Used  |        |              |
| 40149        | RO | Event_LOG    | Number of Unread Event Log Entries  | 0-99   | AS629262-004 |
| 40150        | RO | Event_LOG#   | Event Number (0 – The Latest One)   | 0-255  | AS629262-004 |
| 40151        | RO | Event_Year   | Event Year  | 0-99   | AS629262-004 |
| 40152        | RO | Event_Month  | Event Month   | 1-12   | AS629262-004 |
| 40153        | RO | Event_Day    | Event Month Day   | 1-31   | AS629262-004 |
| 40154        | RO | Event_Week   | Event Week Day  | 0-6    | AS629262-004 |
| 40155        | RO | Event_Hour   | Event Hour  | 0-23   | AS629262-004 |
| 40156        | RO | Event_Minute | Event Minute  | 0-59   | AS629262-004 |
| 40157        | RO | Event_Second | Event Second  | 0-59   | AS629262-004 |
| 40158        | RO | Event_Event  | Event Parameter:<br>1-kW Prealarm,<br>2-kW Alarm,<br>3-Over Voltage,<br>4-Under Voltage,<br>5-OverFrequency,<br>6-UnderFrequency,<br>7-Reverse Power,<br>8-Reverse VARs,<br>9-Reverse Current,<br>10-Negative Sequence Current,<br>11-Negative Sequence Voltage,<br>12-Input#1,<br>13-Input#2,<br>14-Input#3, | 1-22   | AS629262-004 |

|              |    |                         |   |                              |              |
|--------------|----|-------------------------|---|------------------------------|--------------|
|              |    |                         | 15-Input#4,<br>16-Input#5,<br>17-Input#6,<br>18-Input#7,<br>19-Input#8,<br>20-Input#9(switch position),<br>21-None,<br>22-KW Demand |                              |              |
| 40159        | RO | Event_Cause             | Event Cause: 0-Reset, 1-Tripped, 2-Acknowled  | 0-2                          | AS629262-004 |
| 40160-Bit 0  | RW | DEVICE86                | Device 86 Active?   | 0-No or 1-Yes                | AS629262-004 |
| 40160-Bit 1  | RW | DEVICE86                | Device 86 State   | 0-No or 1-Tripped            | AS629262-004 |
| 40160-Bit 2  | RW | DEVICE86                | Device 86 Hold  | 0-Reset Ok or 1-Do Not Reset | AS629262-004 |
| 40161-40199  |    |                         | Undefined   |                              |              |
| 40200        | RW | TYPE <sub>SYSTEM</sub>  | System Type   |                              | FS611842-006 |
| 40201        | RW | MODE <sub>SOURCE</sub>  | Source Mode   |                              | FS611842-006 |
| 40202        | RW | PTR                     | Potential Transformer Ratio   |                              | FS611842-006 |
| 40203        | RW | CTR                     | Current Transformer Ratio   |                              | FS611842-006 |
| 40204        | RW | CT4R                    | 4 <sup>th</sup> Current Input Transformer Ratio   |                              | FS611842-006 |
| 40205        | RW | PROTOCOL <sub>SCI</sub> | SCI comm. port (J5) protocol  |                              | FS611842-006 |
| 40206        | RW | BAUD <sub>SCI</sub>     | SCI comm. port (J5) baud rate   |                              | FS611842-006 |
| 40207        | RW | ADDR <sub>SCI</sub>     | SCI comm. port (J5) device address  |                              | FS611842-006 |
| 40208        | RW | PROTOCOL <sub>485</sub> | 485 comm. port (J1) protocol  |                              | FS611842-006 |
| 40209        | RW | BAUD <sub>485</sub>     | 485 comm. port (J1) baud rate   |                              | FS611842-006 |
| 40210        | RW | ADDR <sub>485</sub>     | 485 comm. port (J1) device address  |                              | FS611842-006 |
| 40211        | RW | TYPE <sub>LANG</sub>    | Language selection  |                              | FS611842-006 |
| 40212        | RW | Window_Size             | Demand Window size (in minutes)   |                              | FS611842-006 |
| 40213        | RW | Subintl_Size            | Demand Subinterval size (fixed at 1 minute)   |                              | FS611842-006 |
| 40214        | WO | Reset_Demand            | Resets Inst. & Max. demand registers  |                              | FS611842-006 |
| 40215        | WO | Clear_Energy            | Clears Energy registers to 0  |                              | FS611842-006 |
| 40216-40229  |    |                         | Undefined   |                              |              |
| 40230-40235  | RW | SETPOINT                | Setpoint configuration settings   |                              |              |
| 40236-40242  | RW | SETPOINT <sub>1</sub>   | Setpoint#1 Configuration Settings:  |                              | AS629262-004 |
| 40236        | RW | #1                      | Setpoint Number   | 0-11                         |              |
| 40237        | RW | Parameter               | Setpoint Parameter  | 0-20                         |              |
| 40238        | RW | High_limit              | Setpoint Trip Level   | 0-500                        |              |
| 40239        | RW | TD_Operate              | Setpoint Trip Time Delay  | 0-600                        |              |
| 40240        | RW | Low_Limit               | Setpoint Reset Level  | 0-500                        |              |
| 40241        | RW | TD_Release              | Setpoint Reset Time Delay   | 0-600                        |              |
| 40242-Bit0-3 | RW | Output                  | Setpoint Digital Output :DO1 To DO4   | 0 or 1                       |              |
| 40242-Bit 4  | RW | --                      | Output No Acknowledg/Acknowledg   | 0 or 1                       |              |
| 40242-Bit 5  | RW | --                      | Output Status Normal/Tripped  | 0 or 1                       |              |
| 40242-Bit 6  | RW | --                      | Previous Acknowledge/Pending  | 0 or 1                       |              |
| 40242-Bit 7  | RW | --                      | Present Acknowledge/Pending   | 0 or 1                       |              |
| 40243-40249  | RW | SETPOINT <sub>2</sub>   | Setpoint#2 Configuration Settings   | Same Setting as SP#1         | AS629262-004 |
| 40250-40256  | RW | SETPOINT <sub>3</sub>   | Setpoint#3 Configuration Settings   | Same Setting as SP #1        | AS629262-004 |
| 40257-40263  | RW | SETPOINT <sub>4</sub>   | Setpoint#4 Configuration Settings   | Same Setting as SP #1        | AS629262-004 |
| 40264-40270  | RW | SETPOINT <sub>5</sub>   | Setpoint#5 Configuration Settings   | Same Setting as SP #1        | AS629262-004 |



|             |    |                          |                                    |                              |              |
|-------------|----|--------------------------|------------------------------------|------------------------------|--------------|
| 40271-40277 | RW | SETPOINT <sub>6</sub>    | Setpoint#6 Configuration Settings  | Same Setting as SP #1        | AS629262-004 |
| 40278-40284 | RW | SETPOINT <sub>7</sub>    | Setpoint#7 Configuration Settings  | Same Setting as SP #1        | AS629262-004 |
| 40285-40291 | RW | SETPOINT <sub>8</sub>    | Setpoint#8 Configuration Settings  | Same Setting as SP #1        | AS629262-004 |
| 40292-40298 | RW | SETPOINT <sub>9</sub>    | Setpoint#9 Configuration Settings  | Same Setting as SP #1        | AS629262-004 |
| 40299-40305 | RW | SETPOINT <sub>10</sub>   | Setpoint#10 Configuration Settings | Same Setting as SP #1        | AS629262-004 |
| 40306-40312 | RW | SETPOINT <sub>11</sub>   | Setpoint#11 Configuration Settings | Same Setting as SP #1        | AS629262-004 |
| 40313-40319 | RW | SETPOINT <sub>12</sub>   | Setpoint#12 Configuration Settings | Same Setting as SP #1        | AS629262-004 |
| 40320-40321 |    |                          | Undefined                          |                              |              |
| 40322-40325 | RW | PM-Name                  | Power Manager Name                 | 8 ASCII chars                | AS629262-004 |
| 40326-40333 | RW | Status <sub>1</sub> Name | S1 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40334-40341 | RW | Status <sub>2</sub> Name | S2 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40342-40349 | RW | Status <sub>3</sub> Name | S3 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40350-40357 | RW | Status <sub>4</sub> Name | S4 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40358-40365 | RW | Status <sub>5</sub> Name | S5 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40366-40373 | RW | Status <sub>6</sub> Name | S6 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40374-40381 | RW | Status <sub>7</sub> Name | S7 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40382-40389 | RW | Status <sub>8</sub> Name | S8 Status Input name               | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40390-40397 | RW | Relay <sub>1</sub> Name  | DO1 Relay Output name              | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40398-40405 | RW | Relay <sub>2</sub> Name  | DO2 Relay Output name              | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40406-40413 | RW | Relay <sub>3</sub> Name  | DO3 Relay Output name              | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40414-40421 | RW | Relay <sub>4</sub> Name  | DO4 Relay Output name              | 15 chars+ 1 byte eng. alarms | FS611842-006 |
| 40422-40431 | RW | PM-Location              | Power Manager Location             | 20 ASCII chars               | AS629262-004 |
| 40432       |    |                          | Undefined                          |                              |              |

## Register Map for Group 5 Controller

The following table describes the mapping of the registers within the Group 5 Controller to Holding Registers defined in the Modbus protocol.

Note: The addresses in the format of 4xxxx follow the MODICON MODBUS protocol for point addressing.  
The actual address sent is the Register Address shown in the map minus the value **40001**.

### Real Time Data Registers

| Register Address | Register Type | Parameter Name     | Parameter Description                  | Data Range      | Implemented in Firmware Version |
|------------------|---------------|--------------------|--|-----------------|---------------------------------|
| 40001- 40011     |               |                    | Undefined                              |                 |                                 |
| 40012            | RO            | PHASE 0            | Phase Shift between Normal & Emergency | -1800 – 1800    | 607540-023                      |
| 40013            | RO            | NFRQ 0             | Normal Frequency                       | 0 – 7000        | 607540-023                      |
| 40014            | RO            | EFRQ 0             | Emergency Frequency                    | 0 – 7000        | 607540-023                      |
| 40015-Bit 0      | RO            | I MAIN ON N        | Main on Normal                         | Boolean         | 607540-023                      |
| 40015-Bit 1      | RO            | I MAIN ON E        | Main on Emergency                      | Boolean         | 607540-023                      |
| 40015-Bit 2      | RO            | I AUX ON N         | Auxiliary on Normal                    | Boolean         | 607540-023                      |
| 40015-Bit 3      | RO            | I AUX ON E         | Auxiliary on Emergency                 | Boolean         | 607540-023                      |
| 40015-Bit 4      | RO            | N.SrcAvl           | Normal Source Available                | Boolean         | 607540-023                      |
| 40015-Bit 5      | RO            | E.SrcAvl           | Emergency Source Available             | Boolean         | 607540-023                      |
| 40016-Bit 0      | RO            | STATPHR.NABC       | Normal Phase Rotation is ABC           | Boolean         | 607540-023                      |
| 40016-Bit 1      | RO            | STATPHR.NCBA       | Normal Phase Rotation is CBA           | Boolean         | 607540-023                      |
| 40016-Bit 2      | RO            | STATPHR.EABC       | Emergency Phase Rotation is ABC        | Boolean         | 607540-023                      |
| 40016-Bit 3      | RO            | STATPHR.ECBA       | Emergency Phase Rotation is CBA        | Boolean         | 607540-023                      |
| 40016-Bit 4      | RO            | XRQ F11C LX        | Engine Exerciser with Load Active      | Boolean         | 607540-023                      |
| 40016-Bit 5      | RO            | SComFeat.XfrCommOn | Serial F17 is Active                   | Boolean         | 607540-023                      |
| 40016-Bit 6      | RO            | I F17 ON           | External F17 is Active                 | Boolean         | 607540-023                      |
| 40017            | RO            | NV AB              | Normal Voltage Phase AB                | 0 to 28200      | 607540-023                      |
| 40018            | RO            | NV BC              | Normal Voltage Phase BC                | 0 to 28200      | 607540-023                      |
| 40019            | RO            | NV CA              | Normal Voltage Phase CA                | 0 to 28200      | 607540-023                      |
| 40020            | RO            | NVUnblCur          | Normal Voltage Unbalance               | 0 to 99 %       | 607540-023                      |
| 40021            | RO            | EV AB              | Emergency Voltage Phase AB             | 0 to 28200      | 607540-023                      |
| 40022            | RO            | EV BC              | Emergency Voltage Phase BC             | 0 to 28200      | 607540-023                      |
| 40023            | RO            | EV CA              | Emergency Voltage Phase CA             | 0 to 28200      | 607540-023                      |
| 40024            | RO            | EVUnblCur          | Emergency Voltage Unbalance            | 0 to 99 %       | 607540-023                      |
| 40025            | RO            | I NOM V            | Nominal Voltage                        | 0 to 15         | 607540-023                      |
| 40026-Bit 0      | RO            | I FRQ 60           | Nominal Frequency                      | Bool (60-50 Hz) | 607540-023                      |
| 40026-Bit 1      | RO            | I N3PHASE          | Normal Source 3 Phase sensing          | Boolean         | 607540-023                      |
| 40026-Bit 2      | RO            | I E3PHASE          | Emergency Source 3 Phase sensing       | Boolean         | 607540-023                      |
| 40026-Bit3-4     | RO            | TSType             | Transfer Switch Type (CTTS, OTTS,DTTS) | 0 to 3          | 607540-023                      |
| 40026-Bit 5      | RO            | TSBypass           | Transfer Switch Bypass or not          | Boolean         | 607540-023                      |
| 40026-Bit 6      | RO            | ATS/DualBreaker    | Transfer Switch or Dual Breaker        | Boolean         | 607540-033                      |
| 40027            | RO            | TSamp              | Transfer Switch Amp rating             | 0 to 15         | 607540-023                      |
| 40028-40033      | RO            | LCD CP VER         | Control Panel Software version         | 10 char. string | 607540-023                      |
| 40034-40039      | RO            | LCD CP DATE        | Control Panel Software date            | 10 char. string | 607540-023                      |
| 40040-Bit 0      | RO            | OPSave.b.ATSLout   | Transfer Switch Locked Out             | Boolean         | 607540-023                      |

|              |    |                    |  |            |            |
|--------------|----|--------------------|--|------------|------------|
| 40040-Bit 1  | RO | OPSave.b.XtdPriAI  | CTTS extended parallel alarm                     | Boolean    | 607540-023 |
| 40040-Bit 2  | RO | OPSave.b.SyncFail  | CTTS failure to synch alarm                      | Boolean    | 607540-023 |
| 40040-Bit 3  | RO | DTTSLoadDisc       | DTTS Load Disconnect                             | Boolean    | 607540-023 |
| 40040-Bit 4  | RO | I_EXT_PLOCK_ON     | External parameter lock is active                | Boolean    | 607540-023 |
| 40040-Bit 5  | RO | Relay.NR           | Engine running                                   | Boolean    | 607540-023 |
| 40040-Bit 6  | RO | NBrkrTipped        | Normal Breaker Tripped                           | Boolean    | 607540-033 |
| 40040-Bit 7  | RO | EBrkrTipped        | Emergency Breaker Tripped                        | Boolean    | 607540-033 |
| 40041        | RO | CPState            | Control Panel State                              | 0 to 255   | 607540-023 |
| 40042        | RO | CPStateData        | Control Panel Status State Data (→lookup table)  | 0 to 65535 | 607540-023 |
| 40043-Bit 0  | RO | F.F6BOn            | Feature 6B                                       | Boolean    | 607540-023 |
| 40043-Bit 1  | RO | F.F6COn            | Feature 6C                                       | Boolean    | 607540-023 |
| 40043-Bit 2  | RO | I_F17_ON           | Feature 17                                       | Boolean    | 607540-023 |
| 40043-Bit 3  | RO | SComFeat.XfrCommOn | Feature 17 Serial                                | Boolean    | 607540-023 |
| 40043-Bit 4  | RO | F.F29On            | Feature 29                                       | Boolean    | 607540-023 |
| 40043-Bit 5  | RO | F.F30On            | Feature 30                                       | Boolean    | 607540-023 |
| 40043-Bit 6  | RO | F.F34AOn           | Feature 34A                                      | Boolean    | 607540-023 |
| 40043-Bit 7  | RO | F.F34BOn           | Feature 34B                                      | Boolean    | 607540-023 |
| 40044-Bit 0  | RO | F.F89On            | Feature 89                                       | Boolean    | 607540-023 |
| 40044-Bit 1  | RO | F.CTBypsOn         | Feature CT Bypass                                | Boolean    | 607540-023 |
| 40044-Bit 2  | RO | I_ALARM_RST        | Feature Alarm Reset                              | Boolean    | 607540-023 |
| 40044-Bit 3  | RO | I_F6D_MAN_ON       | Feature 6D                                       | Boolean    | 607540-023 |
| 40044-Bit 4  | RO | F.F5On             | Feature 5  | Boolean    | 607540-023 |
| 40044-Bit 5  | RO | I_F5F6Z_ON         | Feature 6Z                                       | Boolean    | 607540-023 |
| 40044-Bit 6  | RO | F.SComF17Off       | Feature 34T                                      | Boolean    | 607540-023 |
| 40045        | RW | LogNum             | Event number                                     | 0 to 99    | 607540-023 |
| 40046        | RO | LogYear            | Event year                                       | 0 to 99    | 607540-023 |
| 40047        | RO | LogMonth           | Event month                                      | 1 to 12    | 607540-023 |
| 40048        | RO | LogDayM            | Event day of month                               | 1 to 31    | 607540-023 |
| 40049        | RO | LogDayW            | Event day of week                                | 0 to 6     | 607540-023 |
| 40050        | RO | LogHour            | Event hour                                       | 0 to 23    | 607540-023 |
| 40051        | RO | LogMin             | Event minute                                     | 0 to 59    | 607540-023 |
| 40052        | RO | LogSec             | Event second                                     | 0 to 59    | 607540-023 |
| 40053        | RO | LogType            | Event type                                       | 1 to 6     | 607540-023 |
| 40054        | RO | LogCause           | Event cause                                      | 0 to 8     | 607540-023 |
| 40055-Bit0-6 | RO | LogEntNr           | Number of entries in the control panel event log | 0 to 99    | 607540-023 |
| 40056-40100  |    |                    | Undefined  |            |            |
| 40101-Bit0-5 | RO | SlcMode            | Soft Load Controller mode                        | 0 to 3     | 607540-023 |
| 40101-Bit 6  | RO | SlcStat.NBrOpn     | SLC Normal Breaker status                        | Boolean    | 607540-023 |
| 40101-Bit 7  | RO | SlcStat.EBrOpn     | SLC Emergency Breaker status                     | Boolean    | 607540-023 |